



Instruction Manual

TIME DELTA-C ULTRASONIC FLOWMETER

TYPE: FSV (Flow transmitter)
FLS, FLW, FLD (Detector)
FLY (Signal cable)

Introduction

We thank you very much for purchasing Fuji Electric's ultrasonic flow meter. The instruction manual concerns the installation, operation, checkup and maintenance of the Flow transmitter (FSV), Detector (FLS/FLW/FLD) and Signal cable (FLY) of ultrasonic flow meter. Read it carefully before operation.

- First read this instruction manual carefully until an adequate understanding is acquired, and then proceed to installation, operation and maintenance of the flow meter. Improper handling may result in an accident or a failure.
- The specifications of this flow meter are subject to change without prior notice for improvement of the product.
- Do not attempt to modify the flow meter without permission. Fuji will not bear any responsibility for a trouble caused by such a modification. If it becomes necessary to modify the flow meter, contact our office in advance.
- This instruction manual should always be kept on hand by the operator.
- After reading the manual, be sure to store it at a place easier to access.
- This instruction manual should be delivered to the end user without fail.
- If the instruction manual has been lost, request another one (with charge) to our local business office.

Note

- Reproduction of any part or the whole of this manual without permission is strictly prohibited by laws.
- Contents of the manual are subject to change without prior notice.



Fuji Electric Systems Co., Ltd.©


Issued in June, 2007



SAFETY PRECAUTIONS


Before using this product, read the following safety precautions and use the product correctly.

The following items are important for safe operation and must be fully observed. These safety precautions are ranked in 2 levels; "DANGER" and "CAUTION".

Warning/Symbol	Meaning
 DANGER	Incorrect handling of the device may result in death or serious injury.
 CAUTION	Incorrect handling may lead to a risk of medium or light injury, or to a risk of physical damage.

The items noted under "  CAUTION " may also result in serious trouble depending on circumstances. All the items are important and must be fully observed.

Caution on mounting and piping	
 DANGER	<ul style="list-style-type: none"> ● This unit is not explosion-proof type. Do not use it in a place with explosive gases. Otherwise, it may result in serious accidents such as explosion, fire, etc.
 CAUTION	<ul style="list-style-type: none"> ● The unit should be installed in a place conforming to the installation requirements noted in this instruction manual. Otherwise, it may cause electric shocks, fire or malfunction of the unit. ● Install the flow meter according to the following steps to prevent it from falling, and to avoid error or malfunction. ● During installation, make sure that the inside of the unit is free from cable chips and other foreign objects. Otherwise, it may cause fire, failure or malfunction. ● The items under "Caution on Installation" noted in the manual must be fully observed. Careless installation may result in trouble or malfunction of the unit.

Cautions in wiring	
 CAUTION	<ul style="list-style-type: none"> ● When performing wiring termination to prevent output trouble caused by moisture, dew condensation or water leak, follow "Section 3.4. Flow transmitter wiring" described in this manual. ● Before performing the wiring work, be sure to turn OFF the main power. Otherwise, it may cause electric shock. ● Do not perform wiring work outdoors in rainy days to prevent insulation deterioration and dew condensation. Otherwise, it may result in trouble, malfunction, etc. ● Be sure to connect a power source of correct rating. Use of power source out of rating may cause fire. ● The unit must be earthed as specified. Otherwise, it may cause electric shocks, malfunction, etc. ● The signal cable and analog output signal cable should be wired as far away as possible from high-voltage lines to prevent entry of noise signals as it will cause malfunction of the unit. ● To prevent malfunction of the unit, the analog output signal cable and power cable should be wired using separate conduits.

Caution on maintenance and inspection



CAUTION

- The unit should be inspected everyday to always obtain good results of measurements.
- When measuring the insulation resistance between the power/output terminal and the case, follow “Section 6.2.3. How to measure the insulation resistance” described in this manual.
- If the fuse is blown, detect and eliminate the cause, and then replace the fuse with a spare. If there are no spares, replace the fuse with the one specified in this manual (that must be prepared by customer). Use of a fuse other than specified or its short-circuit may cause an electric shock or fire. The fuse should be replaced according to “Section 6.3. How to replace the fuse” described in this manual.

CAUTION ON INSTALLATION LOCATION



CAUTION

- (1) A place that provides enough space for periodic inspection and wiring work.
- (2) A place not exposed to direct sunshine nor weathering.
- (3) A place free from excessive vibration, dust, dirt and moisture.
- (4) A place not subjected to radiated heat from a heating furnace, etc.
- (5) A place not subjected to corrosive atmosphere.
- (6) A place not to be submerged.
- (7) A place remote from electrical devices (motor, transformer, etc.) which generate electromagnetic induction noise, electrostatic noise, etc.
- (8) A place not subjected to excessive fluid pulsation such as pump discharge side.
- (9) A place that provides enough place for the length of the straight pipe.
- (10) A place where ambient temperature and humidity are -20 to +50°C and 95% RH or less for flow transmitter (FSV), -20 to +80°C and 100% RH or less for detector (FLW) and -20 to +60°C and 90% RH or less for detector (FLS/FLD).

Contents

Introduction	j	4.9. Output Setting	36
SAFETY PRECAUTIONS	ii	4.9.1. Setting of flow rate range	36
CAUTION ON INSTALLATION LOCATION	iv	4.9.1.1. Setting of flow rate range (single range)	36
1. PRODUCT OUTLINE	1	4.9.1.2. Setting of analog output at error (Burnout)	37
1.1. Checking delivered items	1	4.9.1.3. Output limit	38
1.2. Check on type and specifications	2	4.9.2. Setting the total	39
1.3. NAME AND FUNCTION OF EACH PART	6	4.9.2.1. Setting the total pulse (pulse value, pulse width)	39
1.3.1. Flow Transmitter (FSV)	6	4.9.2.2. Setting the preset value	41
1.3.2. Small diameter/small size detector (FLS)	7	4.9.2.3. TOTAL mode	42
1.3.3. Small/middle size detector (FLW)	7	4.9.2.4. Determining how to dispose of total at error (BURNOUT)	43
1.3.4. Large size detector (FLW)	8	4.9.3. Setting the DO output	44
1.3.5. Small diameter/High temperature detector (FLD)	9	4.9.3.1. How to validate the total pulse output	44
2. INSTALLATION AND BEFORE START OF OPERATION OF THE FLOW TRANSMITTER	10	4.9.4. Setting the LCD indication	46
2.1. Outline of installation procedure	10	4.9.5. Setting the damping	47
3. INSTALLATION	11	4.9.6. Setting the low flow rate cutting	48
3.1. Installation location of flow transmitter	11	4.10. Application operation of parameter	49
3.2. Installation location of detector	12	4.10.1. Setting automatic 2 ranges	49
3.2.1. Length of straight pipe	13	4.10.2. Setting the Bi-directional range	51
3.2.2. Mounting position	14	4.10.3. Setting the Bi-directional auto 2 range	53
3.3. Installation of flow transmitter	15	4.10.4. Rate limit	55
3.3.1. Wall mounting	15	4.10.5. Setting the DO output	57
3.3.2. 2B bypass stand mounting	15	4.10.5.1. How to validate outputting the FULL SCALE 2	57
3.4. Flow transmitter wiring	16	4.10.5.2. How to validate the alarm output	58
3.4.1. Cautions in wiring	16	4.10.5.3. Setting the flow switch	59
3.4.2. Applicable wires	16	4.10.5.4. How to validate the total switch	61
3.4.3. Treatment of wiring port	16	4.10.5.5. How to validate the range over output and pulse range over output	62
3.4.4. Wiring to each terminal	17	4.10.5.6. How to validate the output at the minus direction action	63
4. Parameter	18	4.10.6. Setting the DI input	64
4.1. Description of display/setting unit	18	4.10.6.1. Invalidating the DI input	64
4.2. Composition of key operation	19	4.10.6.2. How to validate the total preset with the external contact.	65
4.3. Parameter initial value list	24	4.10.6.3. How to validate the zero adjustment with the external contact.	66
4.4. Parameter protection	26	4.10.7. How to compensate the measurement value	67
4.4.1. Parameter protection ON/OFF	26	4.10.8. Setting of the operation mode	68
4.5. Display language	27	4.11. MAINTENANCE MODE	69
4.5.1. How to select the language	27	4.11.1. How to calibrate the analog output	69
4.6. Checking and Setting of Piping Specifications/Detector	28	4.11.2. How to set the constant current output	70
4.6.1. Checking piping parameter	28	4.11.3. How to check the action of total pulses	71
4.6.2. Piping parameter setting method	29	4.11.4. How to check the status output	72
4.7. Zero Adjustment	32	4.11.5. How to check the DI input	73
4.8. Setting of unit	33	4.11.6. How to validate the test mode (simulated flow rate output)	74
4.8.1. How to set the unit system	33	4.11.7. How to validate a serial transmission (RS- 232C/RS-485)	76
4.8.2. How to set the flow rate unit	34	4.11.8. How to set the ID No.	78
4.8.3. How to set the total unit	35	4.11.9. How to confirm the software version	78
		4.11.10. Initializing setting parameters	79
		4.11.11. How to set the detailed setting	80

5. Mounting of detector	82	7. Appendix	121
5.1. Detector mounting procedure	82	7.1. Specifications	121
5.1.1. Mounting of detector	83	7.2. OUTLINE DIAGRAM	123
5.1.2. Image figure of mounting dimension	83	7.3. ORDERING INFORMATION	127
5.2. Selection of mounting position	84	7.4. How to make gauge paper	128
5.3. Selection of mounting method	85	7.5. Piping data	129
5.4. Processing of mounting surface	86		
5.5. How to determine the mounting position	87		
5.6. Selection of acoustic coupler	88		
5.7. Cable end treatment	89		
5.7.1. Cable end treatment for FLS, FLD	89		
5.7.2. Cable end treatment for FLW	89		
5.8. Mounting small-diameter and small size detector (FLSS12, FLSS22)	90		
5.8.1. Frame mounting method	90		
5.8.2. Mounting of sensor unit	91		
5.9. Mounting small-diameter and medium size sensor (FLW11, FLW12, FLW41)	93		
5.9.1. Connection of sensor cable	93		
5.9.2. Assembling procedure of the sensor	95		
5.9.3. Mounting method on the pipe	96		
5.9.3.1. In case of V method	96		
5.9.3.2. In case of Z method	98		
5.10. Mounting large size detector (FLW50, FLW51)	99		
5.10.1. Connection of sensor cable	99		
5.10.2. Mounting method on the pipe	100		
5.11. Mounting small diameter detector (FLD22)	101		
5.12. Mounting high temperature detector (FLD32)	102		
5.12.1. Mounting of detector (in case of V method)	102		
5.12.2. Mounting of detector (in case of Z method)	103		
6. CHECK AND MAINTENANCE	104		
6.1. Daily Check	104		
6.2. Periodic Inspection	104		
6.2.1. Checking zero point	104		
6.2.2. Reapplying grease	104		
6.2.3. How to measure the insulation resistance	105		
6.3. How to replace the fuse	106		
6.4. How to replace the relay	107		
6.5. How to replace the LCD	108		
6.6. ERROR AND REMEDY	109		
6.6.1. Display error	109		
6.6.1.1. Checking the LCD/LED	109		
6.6.1.2. Checking the LED lit in red	110		
6.6.1.3. Checking the RAS information	111		
6.6.2. Displaying the data in maintenance mode	112		
6.6.3. Keying is abnormal	113		
6.6.4. Error in measured value	114		
6.6.5. Error in analog output	116		
6.6.6. Checking received waveforms	117		
6.6.6.1. How to connect the oscilloscope	117		
6.6.6.2. Checking sending/receiving	118		
6.6.7. Remedying a hardware fault	120		

1. PRODUCT OUTLINE

1.1. Checking delivered items

<p>Flow transmitter (FSV) Flow transmitter main unit 1 set Waterproof gland (Built into the main unit) 1 set Wall mount frame (Built into the main unit) 1 set Panel mounting bracket (option) (U bolt, support fixture, butterfly nut 2 pieces, spring washer 2 pieces, plain washer 2 pieces) 1 set</p> <p>Detector (FLSS12, FLSS22) Frame 1 piece Sensor unit × 2 1 set Stainless steel belt (FLSS12: 2 pieces, FLSS22: 4 pieces) 1 set Optional silicon rubber, silicon-free grease or silicon grease 1 piece</p> <p>Detector (FLW11, FLW12) Small size detector 1 set Chain × 2 1 set Silicon rubber, optional silicon-free grease or silicon grease 1 piece</p> <p>Detector (FLW41) Middle size detector × 2 1 set Wire rope × 2 1 set Mounting spring × 2 1 set Silicon rubber, optional silicon-free grease or silicon grease 1 piece</p>	<p>Detector (FLW50, FLW51) Large size detector × 2 1 set Wire rope × 2 1 set Mounting spring × 2 1 set Detector mounting set 1 set</p> <p>Detector (FLD22) Small diameter detector 1 set Stainless steel belt 1 set Silicon rubber, optional silicon-free grease or silicon grease 1 piece</p> <p>Detector (FLD32) High temperature detector 1 set Stainless steel belt 1 set Silicon grease (for high temperature detector) 1 piece</p> <p>Signal cable (for FLS) (FLY3: length specified) × 2 1 set Signal cable (for FLW) (FLY8: length specified) × 2 1 set Signal cable (for FLD) (FLY9: length specified) × 2 1 set Communication cable (for RS-232c) 1 set CD-ROM (Instruction manual and loader software) 1 piece</p> <p>Out of delivery Power cable Output signal cable RS-485 communication cable</p>
--	---



1.2. Check on type and specifications

The type and specifications of product are indicated on the specifications plate mounted on the flow transmitter and detector frame. Check that they represent the type you ordered, referring to the following code symbols.

<Flow transmitter (FSV)>

1	2	3	4	5	6	7	8	9	10	11	12	13	14	Contents
F	S	V					1							
			S											<Type> Standard (Japanese) Standard (English)
			E											<Communication> Without RS-232c + DI (for cable only) RS-485 + DI
			Y											<Application> Single-path
			A											<Power supply> 100 to 240V AC, 50/60Hz 20 to 30V DC
			B											Modification No. (8th digit)
				1										<Case structure> Immersion-proof structure (IP66)
				4										<Wiring connection port> G1/2 and G3/8 (female screw) with water-proof connection
					1									<Used in combination with the explosion-proof detector> Without
						S								<Parameter setting> Without With setting With setting and tag plate Tag plate
							Y							<Mounting method> Pipe mounting Wall mounting
								Y						
									Y					
										Y				
											Y			
												Y		
													A	
													B	




FE	
Ultrasonic Flow Meter	CE
Type _____	
Output DC4-20mA	
Power Supply <input type="checkbox"/> AC100-240V 50/60Hz	
<input type="checkbox"/> DC20-30V	
Ser.No. _____	Mfd. _____
Fuji Electric Systems Co.,Ltd. Made in Japan	

<Detector (FLS)>

1	2	3	4	5	6	7	8	9	10	Contents	
F	L	S	S				2	-	Y		Specification (4th digit)
			S								Standard
				1	2						Type (5th to 6th digit)
				2	2						Small diameter detector (Φ25 to Φ100mm)
											Small size detector (Φ50 to Φ225mm) } V method
						Y					Acoustic coupler (7th digit) (Note)
						A					Without
						B					Silicon rubber
											Silicon-free grease
							2				Modification No. (8th digit)
											Optional specifications (10th digit)
								Y			Without
								B			Tag plate

Note) Select silicone rubber (A) for the acoustic coupler in ordinary cases. Silicone rubber is supplied in a tube (100g). If two or more instruments are ordered, you can select a tube of silicon rubber for every 5 units. Select silicon-free grease (B) if the instrument is to be used in an environment where generation of silicon is not desirable such as semiconductor manufacturing facilities. The grease, which is soluble in water, should not be used in an environment where water may be splashed onto it or condensation may occur on the surface of the piping. Since it does not harden, periodic maintenance (cleaning and refilling of approximately once every 6 months in room temperature) is required.

FLSS12.22



FE	Type.
	Ser.No.
Sensor No.	Mfd.
Fuji Electric Systems Co.,Ltd	CE Made in Japan

<Detector (FLW)>

1	2	3	4	5	6	7	8	9	10	11	Contents	
F	L	W					2	-	Y	Y		
1	2	0										Type (4th to 6th digit)
1	1	0										Small size detector (Φ50 to Φ300) } V method
4	1	0										Small size detector ^{*2} (Φ50 to Φ300) } V method
5	1	0										Middle size detector (Φ200 to Φ1200) } V method or Z method
5	0	0										Large size detector (Φ200 to Φ6000) } V method or Z method
												Large size detector ^{*2} (Φ200 to Φ6000) } V method or Z method
												Optional specifications (7th digit)
												Without
												With Tag display
												Mounting method (11th digit)
												Standard
												Z method mounting (for small size detector)

*2) For aging pipes, cast iron pipes or pipes with mortar lining that will interrupt the propagation of ultrasonic signals, Model FLW11 or FLW50 is recommended, where applicable.

*3) Provide type FLY for the signal cable.

Note) Silicone rubber is attached to the acoustic coupler.

1	2	3	4	5	6	7	8	9	10	11	Contents	
F	L	W					2	-				
1	2	0										Type (4th, 5th, 6th digit)
1	1	1										Submersible small size detector (Φ50 to Φ300) } V method
4	1	1										Submersible small size detector ^{*2} (Φ50 to Φ300) } V method
5	1	1										Submersible middle size detector (Φ200 to Φ1200) } V method or Z method
5	0	1										Submersible large size detector (Φ200 to Φ6000) } V method or Z method
												Submersible large size detector ^{*2} (Φ200 to Φ6000) } V method or Z method
												Optional specifications (7th digit)
												Without
												With Tag display
												Dedicated signal cable (9th, 10th digit)
												B Y --- 10m
												C Y --- 20m
												D Y --- 30m
												E Y --- 40m
												F Y --- 50m
												G Y --- 60m
												H Y --- 70m
												J Y --- 80m
												K Y --- 90m
												L Y --- 100m
												M Y --- 110m
												N Y --- 120m
												P Y --- 130m
												Q Y --- 140m
												R Y --- 150m
												Z Y --- Others
												Mounting method (11th digit)
												Standard
												Z method mounting (for small size detector)

*2) For aging pipes, cast iron pipes or pipes with mortar lining that will interrupt the propagation of ultrasonic signals, Model FLW11 or FLW50 is recommended, where applicable.

Note) Silicone rubber is attached to the acoustic coupler.

FLW1, FLW41



Ultrasonic Flow Meter	FE
Type _____	
Ser.No. _____	CE
Mfd. _____	
Fuji Electric Systems Co.,Ltd.	
Made in Japan	

<Detector (FLD)>

1	2	3	4	5	6	7	8	9	Contents	
F	L	D					1	-		Type (4th, 5th, 6th digit)
			2	2	0					Small diameter detector (Φ13 to Φ100) V method
			3	2	0					High temperature detector (Φ50 to Φ400) V method or Z method
						S				Belt, coupler (7th digit)
										For mount type
								Y		Coaxial cable (9th digit)
										Without

Note) Silicone rubber is attached to the acoustic coupler.




FE	Type.	Ser.No.
	Mfd. Fuji Electric Systems Co., Ltd. CE Made in Japan	

<Signal cable (FLY)>

1	2	3	4	5	6	7	8	9	10	11	12	13	14	Contents	
F	L	Y					1							Type (4th digit)	
			3											For FLS (Max.60m)	
			8											Provided with one-side waterproof BNC connector	
			9											For FLW (Max.300m)	
														For FLD	
				0	0	5								Cable length (5th to 7th digit)	
				0	1	0								5m	
				0	1	5								10m	
				0	1	5								15m	
				0	2	0								20m	} Note) 20 to 150m is treated in the unit of 10m.
				0	3	0								30m	
				.											
				.											
				1	5	0								150m	
				Z	Z	Z								Others (Please contact us.)	
													Z	-	Modification No.


1.3. NAME AND FUNCTION OF EACH PART

1.3.1. Flow Transmitter (FSV)



No.	Name	Key	Description
(1)	Wiring connection port, large		Wiring connection port for power cable and output cable.
(2)	Wiring connection port, small		Wiring connection port for signal cable only.
(3)	Indication and setting unit		Indicates and sets the flow rate, etc.
(4)	Received wave diagnostic indication (LED)		Indicates whether received wave is normal (green) or abnormal (red).
(5)	Escape key	ESC	Returns to the next-higher layer or cancels the set status.
(6)	UP key	△	Selects items, numeric values and symbols.
(7)	Shift key	▶	Moves the cursor and selects decimal place.
(8)	Entry key	ENT	Enters a selection or registers a setting.
(9)	LCD display		Indicates the flow rate or setting.
(10)	Power terminal		Connects the power cable.
(11)	Input/output terminal		Connects signal cable, analog output or DO output cable.
(12)	Communication board terminal		Connects communication cable. (A communication board is optional)
(13)	Fuse holder		Fuse holder
(14)	Relay		Relay contact for DO3 output
(15)	Communication board		Mounted if communication synchronization is optionally designated.


1.3.2. Small diameter/small size detector (FLS)




FLSS12, 22

No.	Name	Description
(1)	Frame for small size	Fastens the sensor unit on pipe.
(2)	Sensor unit	Sends and receives an ultrasonic wave.
(3)	Stainless steel belt	Fastens the frame on pipe.
(4)	Scale	Reads the sensor mounting spacing.
(5)	Fastening hole	Makes a position and fastens the sensor units.
(6)	Signal cable	Transmits send/receive signals.

1.3.3. Small/middle size detector (FLW)




FLW1□



FLW41

No.	Name	Description
(1)	Signal cable	Transmits send/receive signals.
(2)	Detector	Sends and receives an ultrasonic wave.
(3)	Chain	Fastens the detector on pipe.
(4)	Wire rope	Fastens the detector on pipe.
(5)	Mounting spring	Removes the play of wire rope.


1.3.4. Large size detector (FLW)




FLW5□

No.	Name	Description
(1)	Signal cable	Transmits send/receive signals.
(2)	Detector	Sends and receives an ultrasonic wave.
(3)	Wire rope	Fastens the detector on pipe.
(4)	Mounting spring	Removes the play of wire rope.

1.3.5. Small diameter/High temperature detector (FLD)



FLD22




FLD32

No.	Name	Description
(1)	Signal cable	Transmits the send/receive signals.
(2)	Sensor unit	Sends and receives an ultrasonic wave.
(3)	Element holder	Attaches the sensor unit firmly to the pipe.
(4)	Lock nut	Fixes the sensor unit mounting position.
(5)	Scale	Reads the spacing between the sensor units.
(6)	Frame	Fastens the sensor unit on pipe.
(7)	High temperature detector	Sends and receives an ultrasonic wave.
(8)	Stainless steel belt	Fastens the sensor frame on pipe.

2. INSTALLATION AND BEFORE START OF OPERATION OF THE FLOW TRANSMITTER

2.1. Outline of installation procedure



3. INSTALLATION

Select an installation location that satisfies the following conditions, with ease of maintenance and inspection, service life of the instrument, and assurance of reliability taken into consideration.




CAUTION

- (1) A place where ambient temperature and humidity are -20 to +55°C and 90% RH or less for flow transmitter (FSV), -20 to +80°C and 90% RH or less for detector (FLW) and -20 to +60°C and 90% RH or less for detector (FLS/FLD).
- (2) A place not exposed to direct sunshine nor weathering.
- (3) Space for periodic inspection and wiring work is available.
- (4) A place not subjected to radiated heat from a heating furnace, etc.
- (5) A place not subjected to corrosive atmosphere.
- (6) A place not to be submerged.
- (7) A place free from excessive vibration, dust, dirt and moisture.

3.1. Installation location of flow transmitter


Secure at least 100 mm of space between the flow transmitter and nearby wall. Also secure a space of opening the front cover for maintenance.

Secure a cable wiring space under the case.



3.2. Installation location of detector

The measuring accuracy is considerably affected by the detector mounting place, i.e., status of piping for measuring a flow rate. Select a place which clears the condition in section 3.2.1. (Length of straight pipe). Also, sufficiently secure a space for installation and maintenance referring to the following diagram.














An ample space for the installation location of detector

3.2.1. Length of straight pipe

The length of upstream and downstream straight pipe of the ultrasonic detector should be long enough to ensure accurate measurements.

(D is nominal diameter for a pipe)


Type	Length of upstream straight pipe	Length of downstream straight pipe
90° vending		
Tee		
Extension pipe		
Contraction pipe		
Individual valves	 When adjusting flow rate by the valve on the upstream side	 When adjusting flow rate by the valve on the downstream side
Pump		

Note) Source: Japan Electric Measuring Instruments Manufacturers' Association (JEMIS-032)


3.2.2. Mounting position

The detector can be installed vertical, horizontal or at any posture provided that attention is paid to the following things.


- (1) The piping must completely be filled with fluid when it flows.



- (2) Where a horizontal pipe is used, install the sensor within $\pm 45^\circ$ from the horizontal plane. Otherwise, the measurement could be impossible if bubbles stay in the upper part of piping or if deposits are accumulated in the lower part of piping. In case of vertical piping, the detector may be mounted at any position on its periphery provided that the flow is upward.



- (3) Avoid installing the sensor on a deformed portion of pipe or welded portion of pipe, or on flange.




3.3. Installation of flow transmitter

The flow transmitter may be mounted on a wall or 2B pipe stand (option).

3.3.1. Wall mounting

For wall mounting, use two M8 bolts.

Drill holes according to the mounting hole dimensions shown below, and fasten the flow transmitter using the M8 bolts.



Norminal	Standard tightening torque
M8	12.5 [N·m]

3.3.2. 2B bypass stand mounting

⚠ CAUTION

When mounting on 2B pipe, be sure to use a complete set of fixtures (U bolt, support fixture, plain washer, spring washer, wing nut) furnished if optionally designated. Tighten the wing nut by hand. If any support fixture is not used or if the altogether is excessively tightened by tool, the wall mounting fixture may be deformed, thereby breaking the resin case.

Mount the instrument on 2B pipe stand as illustrated below.



3.4. Flow transmitter wiring

3.4.1. Cautions in wiring

CAUTION

- (1) Use a special coaxial cable (FLY3, FLY8 or FLY9) as a signal cable between the detector (FLS/FLW/FLD) and flow transmitter (FSV). Do not provide a junction of the signal cable midway.
- (2) The signal cable between the sensor and converter should be run in metallic conduits. Upstream and downstream signal cables may be put in the same conduit but, to avoid interference, do not put the power cable together.
- (3) For output signal, use a shield cable, where possible.
- (4) To avoid ingress of noise, do not put the cables together with heavy duty line or the like into the same duct.
- (5) If a ground wire is included in the power cable, connect it to ground as it is.
- (6) A power switch is not provided on the instrument and must be mounted separately.
- (7) Hermetically cover unused wiring ports by furnished caps.

3.4.2. Applicable wires

Use the following cables.

- Power cable : 3-wire or 2-wire cabtyre cable
Nominal sectional area 0.75mm² or more
Finish outside diameter Φ11mm
- Output signal cable : 2-wire or multi-wire cabtyre cable as required
Finish outside diameter Φ11mm
- Detector-flow transmitter cable : Signal cable by type designation
 - In case of FLS : Heat-resisting high-frequency coaxial cable having 50Ω of characteristics impedance.
With one-side waterproof BNC connector
Finish outside diameter Φ5mm
 - In case of FLW : In case of FLW: High-frequency coaxial double shield cable with characteristic impedance of 50Ω
Finish outside diameter Φ7.3mm
 - In case of FLD : In case of FLW: High-frequency coaxial double shield cable with characteristic impedance of 50Ω
With one-side waterproof BNC connector
Finish outside diameter Φ7.3mm

3.4.3. Treatment of wiring port


The casing of the flow transmitter is of watertight type (IP66). However, if installed in a humid place, the wiring ports must be made airtight to avoid ingress of moisture, condensation, etc. Be sure to use the waterproof glands furnished with the instrument in order to ensure the waterproof means. A gland, which is not ready to be used, should be sealed by supplied cover.

CAUTION

Do not install the instrument where there is a risk of inundation.

3.4.4. Wiring to each terminal

Carry out wiring to each terminal according to the following figure.



Note 1) All screws are M3 on the terminal block. Use crimp-style terminals for M3 and whose outer diameter is $\Phi 5.8$ or smaller.

Note 2) Be sure to connect ground terminal to external ground terminal. (Class D grounding)

Note 3) For output signal, use multiple core cable as required.

4. Parameter


4.1. Description of display/setting unit

Display unit and setting unit are as shown below.







- LCD display: Displays the measurement and setting (indication in 16 digits, 2 line).
"Measurement display"

Up to 8 digits including the decimal point are displayed in the data field. When the displayed digits exceed, display digits over "<" is displayed at the first digit. When the range exceeds, "OVERFLOW" or "UNDERFLOW" is displayed blinking on the Display 2.




- LED display: Indicates whether the received wave is normal or not.
(Green) : Received wave is normal.
(Red) : Received wave is abnormal.


Set the parameter by setting switches.

-  ESCAPE key : Return to the next-higher layer or cancels the set status.
-  UP key : Selects items, numeric values and symbols.
-  SHIFT key : Moves the cursor and selects decimal place.
-  ENTRY key : Enters a selection or registers a setting.


Note) For changing the parameter, enter the changed value, and press this key to confirm that it is registered.


4.2. Composition of key operation











4.3. Parameter initial value list

Factory-set value is shown below. (When parameter setting is not provided.)

	Setting unit	Setting range	Initial value	Setting value		
1	Parameter protection	No. of menu: 2	PROTECTION ON	PROTECTION ON, PROTECTION OFF		
2	ID No	0000 to 9999	0000	ID No. is invalid when 0000 is selected.		
3	Language	No. of menu: 5	English *1	English, Japanese, German, French and Spanish		
4	Measuring condition	System unit	No. of menu: 2	Metric	Metric or inch	
5		Flow unit	No. of menu: 18	m ³ /h	L/s, L/min, L/h, L/d, kL/d, ML/d, m ³ /s, m ³ /min, m ³ /h, m ³ /d, km ³ /d, Mm ³ /d, BBL/s, BBL/min, BBL/h, BBL/d, kBBL/d, MBBL/d	
6		Total unit	No. of menu: 8	m ³	mL, L, m ³ , km ³ , Mm ³ , mBBL, BBL, kBBL	
7		Outer diameter	6.00 to 6200.00mm	60.00mm	[mm, in]	
8		Pipe material	No. of menu: 13 Sound velocity: 1000 to 3700m/s	PVC pipe	Carbon steel, stainless steel, PVC, Copper, Cast iron, Aluminum, FRP, Ductile iron, PEEK, PVDF, Acrylic, and PP Pipe sound velocity (Sound velocity: [m/s, ft/s])	
9		Wall thickness	0.10 to 100.00mm	4.00mm	[mm, in]	
10		Lining material	No. of menu: 8 Sound velocity: 1000 to 3700m/s	No lining	No lining, Tar epoxy, Mortar, Rubber, Teflon, Pyrex glass, PVC Lining S.V. (Sound velocity: [m/s, ft/s])	
11		Lining thickness	0.01 to 100.00mm	—	[mm, in]	
12		Kind of fluid	No. of menu: 18 Sound velocity: 300 to 2500m/s	Water	Seawater, dist. water, ammonia, alcohol, benzene, bromide, ethanol, glycol, kerosene, milk, methanol, toluol, lube oil, fuel oil, petrol and refrigerant R410 Fluid S.V. (Sound velocity: [m/s, ft/s])	
13		Dynamic viscosity coefficient	0.001 to 999.999 ×10 ⁻⁶ m ² /s	1.0038 ×10 ⁻⁶ m ² /s	[×10 ⁻⁶ m ² /s, ft ² /s]	
14		Sensor mounting method	No. of menu: 2	V method	V method, Z method	
15		Sensor type	No. of menu: 10	FLS_12	FLS_12, FLS_22, FLW11/FSG_31, FLW12/FSG_32, FLW41/FSG_41, FLW50/FSG_50, FLW51/FSG51, FLD12, FLD22, FLD32	
16		Transmission voltage	No. of menu: 4	80Vpp	20Vpp, 40Vpp, 80Vpp, 160Vpp	
17		Output condition	Zero adjustment	No. of menu: 2	Clear (unadjusted)	Clear, adjustment (Clear has been factory-set.)
18			Damping	0.0 to 100.0sec	5.0sec	sec
19	Low flow cut		0 to 5m/s in terms of flow velocity	0.150m ³ /h	[(5) unit]	
20	Display		Content of display 1st line	No. of menu: 7	Flow velocity (m/s)	Flow velocity, Flow rate, Flow rate (%), +Total (Actual), +Total pulse, -Total (Actual) and -Total pulse
21			Decimal point position of display 1st line		****.***	□□□□□□□□ (Fill in the specified digit)
22			Content of display 2nd line	No. of menu: 7	Flow rate (m/s)	Flow velocity, Flow rate, Flow rate (%), +Total (Actual), +Total pulse, -Total (Actual) and -Total pulse
23			Decimal point position of display 2nd line		****.***	□□□□□□□□ (Fill in the specified digit)
24	Analog output		Range type	No. of menu: 4	Single range	Single range, Auto 2 range, Bi-dir range and Bi-dir Auto 2 range
25			Full scale 1	0, ±0.3 to ±32m/s in terms of flow velocity	15.000m ³ /h	[(5) unit]
26			Full scale 2	0, ±0.3 to ±32m/s in terms of flow velocity	0.000m ³ /h	[(5) unit]
27			Hysteresis	0.00 to 20.00	10.00%	%
28			Burnout (current)	No. of menu: 5	Hold	Not used, Hold, Lower, Upper and Zero
29		Burnout timer	0 to 900sec	10sec	sec	
30		Output limit low	-20 to 0%	-20%	%	
31		Output limit high	100 to 120%	120%	%	
32		Rate limit	0 to 5m/s in terms of flow velocity	0.000m ³ /h	[(5) unit]	
33		Rate limit timer	0 to 900sec	0sec	sec	
34	Total output	Total mode	No. of menu: 3	Stop	Start, Stop and Reset	
35		Pulse value	0.000000 to 99999999	0m ³	[(6) unit]	
36		Total preset	0.000000 to 99999999	0m ³	[(6) unit]	
37		Pulse width	No. of menu: 5	50.0msec	5.0msec, 10.0msec, 50.0msec, 100.0msec, 200.0msec	
38		Burnout (total)	No. of menu: 2	Hold	Not used, hold	
39	Burnout timer	0 to 900sec	10sec	sec		

	Setting unit	Setting range	Initial value	Setting value	
40	Output condition	DO1 output type	No. of output content menu: 10 No. of alarm menu: 3 Flow switch range 0 to 32m/s in terms of flow velocity Total switch range 0.000000 to 99999999	Not used <input type="checkbox"/> Not used <input type="checkbox"/> +Total pulse <input type="checkbox"/> -Total pulse <input type="checkbox"/> Range full scale 2 <input type="checkbox"/> Alarm [All, Device error, Process error] <input type="checkbox"/> Flow rate switch <input type="checkbox"/> Flow SW high [(5) unit] <input type="checkbox"/> Flow SW low [(5) unit] <input type="checkbox"/> Total switch [(6) unit] <input type="checkbox"/> Range over <input type="checkbox"/> Pulse range over <input type="checkbox"/> -Flow direction	
41		DO1 Output operation	No. of menu: 2	Active ON	Active ON, Active OFF
42		DO2 Output type	No. of output content menu: 10 No. of alarm menu: 3 Flow switch range 0 to 32m/s in terms of flow velocity Total switch range 0.000000 to 99999999	Not used	 <input type="checkbox"/> Not used <input type="checkbox"/> +Total pulse <input type="checkbox"/> -Total pulse <input type="checkbox"/> Range full scale 2 <input type="checkbox"/> Alarm [All, Device error, Process error] <input type="checkbox"/> Flow rate switch <input type="checkbox"/> Flow SW high [(5) unit] <input type="checkbox"/> Flow SW low [(5) unit] <input type="checkbox"/> Total switch [(6) unit] <input type="checkbox"/> Range over <input type="checkbox"/> Pulse range over <input type="checkbox"/> -Flow direction
43		DO2 Output operation	No. of menu: 2	Active ON	Active ON, Active OFF
44		DO3 Output type	No. of output content menu: 10 No. of alarm menu: 3 Flow switch range 0 to 32m/s in terms of flow velocity Total switch range 0.000000 to 99999999	Not used	 <input type="checkbox"/> Not used <input type="checkbox"/> +Total pulse <input type="checkbox"/> -Total pulse <input type="checkbox"/> Range full scale 2 <input type="checkbox"/> Alarm [All, Device error, Process error] <input type="checkbox"/> Flow rate switch <input type="checkbox"/> Flow SW high [(5) unit] <input type="checkbox"/> Flow SW low [(5) unit] <input type="checkbox"/> Total switch [(6) unit] <input type="checkbox"/> Range over <input type="checkbox"/> Pulse range over <input type="checkbox"/> -Flow direction
45		DO3 Output operation	No. of menu: 2	Active ON	Active ON, Active OFF
46		DI1 Input type	No. of input content menu: 3	Not used	<input type="checkbox"/> Not used <input type="checkbox"/> Total reset <input type="checkbox"/> Zero adjustment
47		DI1 Input operation	No. of menu: 2	Active ON	Active ON, Active OFF
48		Zero calibration	-5 to 5m/s in terms of flow velocity	0.000m ³ /h	[(5) unit]
49		Span calibration	-200.00 to 200.00%	100.00%	%
50	Operation mode	No. of menu: 2	Standard	Standard, High speed	
51	Communication	Communication mode	No. of menu: 2	RS-232C	RS-232C, RS-485
52		Baud rate	No. of menu: 3	9600bps	9600bps, 19200bps, 38400bps
53		Parity	No. of menu: 3	Odd	None, Odd, Even
54		Stop bit	No. of menu: 2	1 bit	1 bit, 2 bits
55		Station No.	1 to 31	1	(In case of RS-485)
56		Communication protocol	No. of menu: 2	MODBUS	MODBUS, M-Flow

*1) English is set when 4th digit of the type is "E".

FSV : Japanese

FSV : English

4.4. Parameter protection

4.4.1. Parameter protection ON/OFF

Description

- Parameters can be protected so that the flow meter settings will not carelessly be changed.
- Parameters can be protected by setting the "ID No." (Note) in the maintenance mode.
 Note) 4 digits are factory set at "0000". (Refer to Section 4.11.8.)

Setting range: PROTECTION ON : Parameter cannot be changed.
 PROTECTION OFF: Parameter can be changed.

- * 1 hour after "PROTECTION OFF" is set, "PROTECTION ON" is automatically set.
- * Parameter protection is set after turning power on.

For concrete keying, refer to the typical operation indicated below.

Operation (example)	Change the parameter protection from ON to OFF (suppose ID No. is "2234").	
Key operation	Description	Display
△	Press the △ key in the measurement mode once to indicate "PAR. PROTECTION".	<div style="border: 1px solid black; padding: 2px;"> PAR.PROTECT ----- PROTECTION ON </div>
▼		
ENT	Press the ENT key once to blink the 2nd line.	<div style="border: 1px solid black; padding: 2px;"> PAR.PROTECT ----- PROTECTION ON </div>
▼		
△	Press the △ key once to display "PROTECTION OFF".	<div style="border: 1px solid black; padding: 2px;"> PAR.PROTECT ----- PROTECTION OFF </div>
▼		
ENT	Press the ENT key once to display "PAR.PROTECTION".	<div style="border: 1px solid black; padding: 2px;"> PAR.PROTECT ----- ** COMPLETE ** </div>
▼		↓
▼		
▼		
▼		
ENT	Press the ENT key once to indicate "0000" and blink the cursor.	<div style="border: 1px solid black; padding: 2px;"> INPUT ID NO. ----- **** </div>
▼		
▼		
ENT	Press the ENT key once to indicate "0000" and blink the cursor.	<div style="border: 1px solid black; padding: 2px;"> INPUT ID NO. ----- 0000 </div>
▼		
▼		
△ ▶	Enter ID No. "2234" by the △ key or the ▶ key.	<div style="border: 1px solid black; padding: 2px;"> INPUT ID NO. ----- 2234 </div>
▼		
ENT	Press the ENT key once.	<div style="border: 1px solid black; padding: 2px;"> INPUT ID NO. ----- ** COMPLETE ** </div>
	* If ID No. does not coincide, "INPUT ERROR!" appears, and the input screen is resumed.	↓
	----- Parameter protection canceled. -----	<div style="border: 1px solid black; padding: 2px;"> PAR.PROTECT ----- PROTECTION OFF </div>

4.5. Display language

4.5.1. How to select the language

Description

- Indication language (English, Japanese, German, French, Spanish) is selectable.

Setting contents

English (default setting), Japanese, German, French, Spanish

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Select English for the display language.	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 8 times to display "SYSTEM LAUGUAGE".	SYSTEM LANGUAGE JAPANESE
	Press the key once to blink on the 2nd line.	SYSTEM LANGUAGE JAPANESE
	Press the key for 4 times to display "ENGLISH".	SYSTEM LANGUAGE ENGLISH
	Press the key once to register.	SYSTEM LANGUAGE ** COMPLETE **
		↓
	----- English has been registered. -----	SYSTEM LANGUAGE ENGLISH
	Press the key or the key to display the measurement mode.	0.000 m/s 0.000 m3/h

Operation (example)	Select Japanese for the display language.	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 8 times to display "SYSTEM LAUGUAGE".	SYSTEM LANGUAGE ENGLISH
	Press the key once to blink on the 2nd line.	SYSTEM LANGUAGE ENGLISH
	Press the key for 4 times to display "JAPANESE".	SYSTEM LANGUAGE JAPANESE
	Press the key once to register.	SYSTEM LANGUAGE ** トリコ **
		↓
	----- Japanese has been registered. -----	トリコ (LANGUAGE) ニホンゴ (JAPANESE)
	Press the key or the key to display the measurement mode.	0.000 m/s 0.000 m3/h

4.6. Checking and Setting of Piping Specifications/Detector

4.6.1. Checking piping parameter

Key operation	Description	Display
		<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0.000 m/s ----- 0.000 m3/h </div>
△	Press the △ key for 3 times to display "MEASURE SETUP".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> MEASURE SETUP ----- </div>
ENT	Press the ENT key once to display "SYSTEM UNIT".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> SYSTEM UNIT ----- ENGLISH </div>
△	Press the △ key for 3 times to display "PROCESS SETTING".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> PROCESS SETTING ----- S= 31(93mm) </div>
ENT	Press the ENT key once to display "OUTER DIAMETER".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> OUTER DIAMETER ----- 60.00 mm </div>
△	Press the △ key once to display "PIPE MATERIAL".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> PIPE MATERIAL ----- PVC </div>
△	Press the △ key once to display "WALL THICKNESS".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> WALL THICKNESS ----- 4.00 mm </div>
△	Press the △ key once to display "LINING MATERIAL".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> LINING MATERIAL ----- NO LINING </div>
△	Press the △ key once to display "KIND OF FLUID".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> KIND OF FLUID ----- WATER </div>
△	Press the △ key once to display "VISCOSITY".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> VISCOSITY ----- 1.003800 E-6m2/s </div>
△	Press the △ key once to display "SENSOR MOUNT".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> SENSOR MOUNT ----- V METHOD </div>
△	Press the △ key once to display "SENSOR TYPE".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> SENSOR TYPE ----- FLS_12 </div>
△	Press the △ key once to display "TRANS. VOLTAGE".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> TRANS. VOLTAGE ----- 80 Vpp </div>
ESC △	Press the ESC key twice, and press the △ key twice to return to the measurement mode.	<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0.000 m/s ----- 0.000 m3/h </div>

4.6.2. Piping parameter setting method

Description

- Set the parameters of piping and fluid to be measured to determine the sensor mounting spacing.
- The mounting dimension of the sensor is automatically calculated. Refer to "5.1.1. Mounting of detector".



CAUTION

Be sure to set the following parameters before mounting the sensor on the pipe. Mount the sensor to match the sensor mounting length.

- Unless the sensor units are spaced accurately, the measurement error will be excessive.
- Also, the received wave may be abnormal.

Setting items

- Pipe outer diameter : 6.00 to 6200.00 [mm] (factory set at 60.00 [mm]).
- Piping material : CARBON STEEL, STAINLESS STEEL, PVC (factory set), COPPER, CAST IRON, ALUMINIUM, FRP, DUCTILE IRON, PEEK, PVDF, ACRYLIC, PP, Others (Sound velocity: 1000 to 3700[m/s])
- Wall thickness : 0.10 to 100.00 [mm] (factory set at 4.00 [mm]).
- Lining material : NO LINING (factory set), TAR EPOXY, MORTAR, RUBBER, TEFLON, PYREX GLASS, PVC, Others (Sound velocity: 1000 to 3700[m/s])
- Lining thickness : 0.10 to 100.00 [mm]
- Measuring fluid : WATER, SEAWATER, DIST.WATER, AMMONIA, ALCOHOL, BENZENE, ETHANOL, GLYCOL, KEROSENE, MILK, METHANOL, TOLUOL, LUBE OIL, FUEL OIL, PETROL, REFRIGERANT R410, Others (Sound velocity: 300 to 2500[m/s])
- Dynamic viscosity coefficient : 0.0010 to 999.999×10^{-6} [m^2/s] (factory set at 1.0038×10^{-6} [m^2/s])
- Detector mounting method : V method (factory set), Z method
- Detector type : FLS_12 (factory set), FLS_22, FLW11/FSG_31, FLW12/FSG_32, FLW41/FSG_41, FLW50/FSG_50, FLW51/FSG_51, FLD12, FLD22 and FLD32
- Transmission voltage : 20Vpp, 40Vpp, 80Vpp (factory set), 160Vpp
Normally, select "80Vpp" for the transmission voltage.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

(1) Setting method when sensor type is "FLS_12" or "FLS_22".

Operation (example)	Carry out setting for measuring the flow rate of water flowing through PVC pipe (for tap water) using FLS_12 detector.	
Key operation	Description	Display
		<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0.000 m/s ----- 0.000 m³/h </div>
	Press the key for 3 times to display "MEASURE SETUP".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> MEASURE SETUP ----- </div>
	Press the key once to display "SYSTEM UNIT".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> SYSTEM UNIT ----- METRIC </div>
	Press the key for 3 times to display "PROCESS SETTING".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> PROCESS SETTING S= 16 (48mm) </div>
	Press the key once to display "OUTER DIAMETER".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> OUTER DIAMETER ----- 60.00 mm </div>
	Press the key once to blink the cursor.	<div style="border: 1px solid black; padding: 2px; text-align: center;"> OUTER DIAMETER ----- 0160.00 mm </div>
		<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0160.00 mm </div>
		<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0160.00 mm </div>
		<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0110.00 mm </div>
		<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0110.00 mm </div>
	Move the cursor by the key, and change the numeric value by the key. Operated to compose "114" because, from Piping data in Section 7.5., the outer diameter of polyvinyl chloride pipe (tap water size) is 114 mm.	<div style="border: 1px solid black; padding: 2px; text-align: center;"> OUTER DIAMETER ----- 114.00 mm </div>

ENT



△



△



ENT



△ ▶



ENT



△



△



△



ESC



ESC △

Press the **ENT** key once to register the outer diameter.

----- Outer diameter has been registered. -----

Press the **△** key once to display "PIPE MATERIAL".

Because PVC (factory set) is already registered, go to the next step.

Note) If the pipe is made of another material, press **ENT** key, and select

a corresponding menu by the **△** key.

Press the **△** key once to display "WALL THICKNESS".

Press the **ENT** key once to blink the cursor.

Move the cursor by the **▶** key, and change the numeric value by the **△** key.

Operated to compose "7" because, from Piping data in Section 7.5., the wall thickness of polyvinyl chloride pipe (tap water size) is 7.0mm.

Press the **ENT** key once to register the wall thickness.

----- Wall thickness has been registered. -----

Press the **△** key once to display "LINING MATERIAL".

"NO LINING" (factory set) is already registered. Because there is no lining, go to the next step.

Note) If lining is provided, press the **ENT** key and **△** key to select the material or enter the sound velocity. Further, go to "LINING THICKNESS", and input a lining thickness. Nothing is indicated in case of "NO LINING".

Press the **△** key once to display "KIND OF FLUID". Because, likewise, "WATER" (factory set) is already registered, go to the next step.

Note) If fluid to be measured is other than water, press the **ENT** key, and select the menu or enter the sound velocity.

Press the **△** key once to display "VISCOSITY".

Input the kinematic viscosity of the fluid to be measured. Because the kinematic viscosity $1.0038E^{-6}$ [m²/s] of water at 20°C is already registered, go to the next step.

In case of fluid other than water, input the kinematic viscosity at a measurement status of fluid to be measured referring to data in Section 7.5., etc.

Press the **ESC** key once to display "PROCESS SETTING".

"S=31" is indicated on the 2nd line.

After mounting the frames on piping, insert into it 2 sensor units spaced at 31 divisions.

Press the **ESC** key once and the **△** key twice to return to the measurement mode.

OUTER DIAMETER
** COMPLETE **



OUTER DIAMETER
114.00 mm

PIPE MATERIAL
PVC

WALL THICKNESS
4.00 mm

WALL THICKNESS
04.00 mm

004.00 mm

WALL THICKNESS
007.00 mm

WALL THICKNESS
** COMPLETE **



WALL THICKNESS
7.00 mm

LINING MATERIAL
NO LINING










































KIND OF FLUID
WATER

VISCOSITY
1.0038 E-6m2/s

PROCESS SETTING
S= 31 (93mm)

0.000 m3/h
0.000 m3

(2) Setting method when sensor type is “FLW11/FSG_31”, “FLW12/FSG_32”, “FLW41/FSG_41”, “FLW50/FSG_50”, “FLW51/FSG_51”, “FLD12”, “FLD22” or “FLD32”

Operation (example)	Carry out setting for measuring the flow rate of water flowing through PVC pipe (for tap water) having 100 mm of nominal diameter, using FLS_12 detector. * Settings of piping and fluid to be measured are omitted, since it is same as “(1) Setting method when sensor type is “FLS_12” or “FLS_22””.	
Key operation	Description	Display
	Press the  key for 3 times to display “MEASURE SETUP”.	
 	Press the  key once to display “SYSTEM UNIT”.	
	Press the  key for 3 times to display “PROCESS SETTING”.	
 	Press the  key once to display “OUTER DIAMETER”.	
	Press the  key for 7 times to blink the cursor.	
 	Press the  key once to blink the cursor.	
	Press the  key for 3 times to display “FLW12/FSG_32” on the 2nd line.	
 	Press the  key once to register “FLW12/FSG_32”.	
  	<p style="text-align: center;">----- “FLW12/FSG_32” has been registered. -----</p>	<p style="text-align: center;">↓</p> 
	Press the  key once to display “PROCESS SETTING”.	
	“S=76.30mm” is displayed on the 2nd line. Align the sensor mounting spacing to 76.3mm, and attach the sensor to the pipe.	
 	Press the  key once and the  key twice to return to the measurement mode.	

4.7. Zero Adjustment

Description

- Zero point is calibrated.

Settable range:

CLEAR : Clears the zero point calibration value to "0".

Used in case the flow cannot be stopped when calibrating the zero point.

Note 1) Where possible, stop the flow and carry out "SET ZERO" stated below.

Otherwise, an error may slip in the zero point.

SET ZERO: A point where "SET ZERO" is carried out is regarded as zero.

Used in case the flow cannot be stopped when calibrating the zero point.

Note 2) The flow must completely be stopped.

Otherwise, the flowing status is regarded as zero, thereby causing an error.

It takes ten seconds to several tens of seconds to complete adjustment, depending on pipe diameter.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Completely fill the piping, close the upstream and downstream valves, and proceed to zero point calibration.	
Key operation	Description	Display
△	Press the △ key twice to display "OUTPUT SETTING".	<div style="border: 1px solid black; padding: 2px;"> ----- OUTPUT SETTING ----- </div>
▼		
ENT	Press the ENT key twice to display "ZERO ADJUSTMENT" and blink the cursor.	<div style="border: 1px solid black; padding: 2px;"> ----- ZERO ADJUSTMENT ----- CLEAR </div>
▼		
△	Press the △ key once, and select "SET ZERO".	<div style="border: 1px solid black; padding: 2px;"> ----- ZERO ADJUSTMENT ----- SET ZERO </div>
▼		
ENT	Press the ENT key once to carry out "SET ZERO".	<div style="border: 1px solid black; padding: 2px;"> ----- ZERO ADJUSTMENT ----- ** COMPLETE ** ----- </div>
▼		
▼		
▼		
▼		
▼		
ESC △	Press the ESC key once, and the △ key for 3 times to enter the measurement mode.	<div style="border: 1px solid black; padding: 2px;"> ----- ZERO ADJUSTMENT ----- SET ZERO ----- ----- 0.000 m/s 0.000 m³/h ----- </div>

4.8. Setting of unit

4.8.1. How to set the unit system

Description

- Measurement unit can be selected from metric or inch system.

- Metric system (factory set)

Length mm

Flow velocity m/s

Flow rate L/s, L/min, L/h, L/d, kL/d, ML/d, m³/s, m³/min, m³/h, m³/d, km³/d, Mm³/d, BBL/s, BBL/min, BBL/h,
BBL/d, kBBL/d, MBBL/d

Total unit mL, L, m³, km³, Mm³, mBBL, BBL, kBBL

Dynamic viscosity coefficient E⁻⁶m²/s

<Note> When setting, stop status should be set at total mode. (See Section 4.9.2.)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Change the unit system from inch system to metric system.	
Key operation	Description	Display
	Press the key for 3 times to display "MEASURE SETUP".	MEASURE SETUP
	Press the key once to display "SYSTEM UNIT".	SYSTEM UNIT INCH
	Press the key once to blink the cursor.	SYSTEM UNIT INCH
	Press the key once to display "METRIC".	SYSTEM UNIT METRIC
	Press the key once to register.	SYSTEM UNIT ** COMPLETE **
	----- METRIC has been registered. -----	SYSTEM UNIT METRIC
	Press the key once and key twice to return to the measurement mode.	0.000 % 0.000 m3/h

4.8.2. How to set the flow rate unit

Description

- Select the unit of flow rate.
- Metric system

Flow rate:..... L/s, L/min, L/h, L/d, kL/d, ML/d, m³/s, m³/min, m³/h (factory set), m³/d, km³/d, Mm³/d, BBL/s, BBL/min, BBL/h, BBL/d, KBBL/d, MBBL/d

<Note> First, set the unit system (metric) according to Section 4.8.1.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set a flow rate unit to "L/min".	
Key operation	Description	Display
	Press the key for 3 times to display "MEASURE SETUP".	MEASURE SETUP
	Press the key once to display "SYSTEM UNIT".	SYSTEM UNIT METRIC
	Press the key once to display "FLOW UNIT".	FLOW UNIT m ³ /h
	Press the key once to blink the cursor.	FLOW UNIT m ³ /h
	Press the key several times to display "L/min".	FLOW UNIT L/min
	Press the key once to register.	FLOW UNIT ** COMPLETE **
		↓
	----- "L/min" has been registered. -----	FLOW UNIT L/min
	Press the key once and the key twice to return to the measurement mode.	0.000 m/s 0.000 L/min

4.8.3. How to set the total unit

Description

- Select the unit of total volume.
- Metric system
Total unitmL, L, m³ (factory set), km³, Mm³, mBBL, BBL, kBBL

<Note> First, set the unit system (metric) according to Section 4.8.1.
When setting, stop status should be set at total mode. (See Section 4.9.2.)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set a flow rate unit to "L".	
Key operation	Description	Display
△	Press the △ key for 3 times to display "MEASURE SETUP".	MEASURE SETUP
▼		
ENT	Press the ENT key once to display "SYSTEM UNIT".	SYSTEM UNIT METRIC
▼		
△	Press the △ key once to display "TOTAL UNIT".	TOTAL UNIT m3
▼		
ENT	Press the ENT key once to blink the cursor.	TOTAL UNIT m3
▼		
△	Press the △ key twice to display "L".	TOTAL UNIT L
▼		
ENT	Press the ENT key once to register.	TOTAL UNIT ** COMPLETE **
▼		↓
▼		
▼	----- "L" has been registered. -----	TOTAL UNIT L
▼		
ESC △	Press the ESC key once and the △ key twice to return to the measurement mode.	0.000 L 0.000 L/min

4.9. Output Setting


4.9.1. Setting of flow rate range

4.9.1.1. Setting of flow rate range (single range)

Description

- The range (full scale) of flow rate to measure is set.
 - * The analog output (4-20mA) corresponds to the range setting.
- Settable range: 0.3 to 32 [m/s] in terms of flow velocity in piping
 - * The piping parameters and FLOW UNIT must be set beforehand.
 - * If a value beyond the settable range is inputted, "INPUT ERROR" appears and then last setting is resumed.
 - * If "piping parameters" or "FLOW UNIT" has been changed after setting the range, recommence the range setting.

<Note> The flow rate unit is as selected by "FLOW UNIT" in the "MEASURE SETUP" mode.
(Refer to Section 4.8.2.)



For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
Key operation	Set 60m3/h to range type, SINGLE/FULL SCALE1. * Set the piping parameters and "FLOW UNIT" beforehand.	
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key to enter the "ZERO ADJUSTMENT" mode.	ZERO ADJUSTMENT SET ZERO
	Press the key for 4 times to display "RANGE".	RANGE
	Press the key once to display "RANGE TYPE". Because SINGLE (factory set) is already registered, go to the next step.	RANGE TYPE SINGLE
	Press the key once to display "FULL SCALE1".	FULL SCALE1 15.000 m3/h
	Press the key once to blink the cursor.	FULL SCALE1 00015.000 m3/h
	Move the cursor by the key, and change the numeric value by the key.	00015.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
		00065.000 m3/h
	Press the key once to register. ----- FULL SCALE1 has been registered. -----	FULL SCALE1 ** COMPLETE ** ↓ FULL SCALE1 60.000 m3/h
	Press the key for 3 times and then press the key for 3 times to enter the measurement mode.	0.000 m/s 0.000 m3/h

4.9.1.2. Setting of analog output at error (Burnout)

Description

- Determine how to set the analog output when received wave error, etc. due to device error, accidental drain of piping or ingress of bubbles.
 - Settable range
 - (1) Analog output (4-20mA) at error
 - HOLD (factory set): Outputs a current intensity preceding the error.
 - UPPER : Sets analog output to upper of the output limit (over scale).
 - LOWER : Sets analog output to lower of the output limit (under scale).
 - ZERO : Outputs 4mA.
 - (2) BURNOUT TIMER (time from error detection to BURNOUT processing) 0 to 900 seconds (factory set at 10 sec).
- * Perform BURNOUT processing as shown below.
 1. LCD display Measured value operates with analog output.


For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set "UPPER" to BURNOUT. Set "20sec" to BURNOUT TIMER. * Set the piping parameters and "FLOW UNIT" beforehand.	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 4 times to display "RANGE".	RANGE
	Press the key once to display "RANGE TYPE".	RANGE TYPE SINGLE
	Press the key for 4 times to display "BURNOUT" (CURRENT).	BURNOUT (CURRENT) HOLD
	Press the key once to blink on the 2nd line.	BURNOUT (CURRENT) HOLD
	Press the key once to display "UPPER".	BURNOUT (CURRENT) UPPER
	Press the key once to register.	BURNOUT (CURRENT) ** COMPLETE **
	----- UPPER has been registered. -----	BURNOUT (CURRENT) UPPER
	Press the key once to display "BURNOUT TIMER".	BURNOUT TIMER 10 sec
	Press the key once to blink the cursor.	BURNOUT TIMER 010 sec
	Press the key once to align the cursor to "1".	BURNOUT TIMER 010 sec
	Press the key once to set "2".	BURNOUT TIMER 020 sec
	Press the key once to register.	BURNOUT TIMER ** COMPLETE **
	----- BURNOUT TIMER has been registered. -----	BURNOUT TIMER 20 sec
	Press the key twice and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.9.1.3. Output limit

Description

- Upper and lower limits can be set within the range of analog output 0.8mA to 23.2mA (-20% to 120%).
- Settable range
 - (1) Output lower limit: -20% to 0% (0.8mA to 4mA)
 - (2) Output upper limit: 100% to 120% (20mA to 23.2mA)



For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
	Set "-10% (2.4mA)" to lower limit, and "110% (21.6mA)" to upper limit. * Set the piping parameters and "FLOW UNIT" beforehand.	
Key operation	Description	Display
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
△	Press the △ key for 4 times to display "RANGE".	RANGE
ENT	Press the ENT key once to display "RANGE TYPE".	RANGE TYPE SINGLE
△	Press the △ key for 6 times to display "OUTPUT LIMIT LOW".	OUTPUT LIMIT LOW -20 %
ENT	Press the ENT key once to blink the cursor.	OUTPUT LIMIT LOW 20 %
▶	Press the ▶ key once to align the cursor to "2".	OUTPUT LIMIT LOW 20 %
△	Press the △ key several times to set "1".	OUTPUT LIMIT LOW 10 %
ENT	Press the ENT key once to register.	OUTPUT LIMIT LOW ** COMPLETE **
	----- OUTPUT LIMIT LOW has been registered. -----	↓ OUTPUT LIMIT LOW -10 %
△	Press the △ key once to display "OUTPUT LIM. HIGH".	OUTPUT LIM. HIGH 120 %
ENT	Press the ENT key once to blink the cursor.	OUTPUT LIM. HIGH 120 %
▶	Press the ▶ key once to align the cursor to "2".	OUTPUT LIM. HIGH 120 %
△	Press the △ key several times to set "1".	OUTPUT LIM. HIGH 110 %
ENT	Press the ENT key once to register.	OUTPUT LIM. HIGH ** COMPLETE **
	----- OUTPUT LIM. HIGH has been registered. -----	↓ OUTPUT LIM. HIGH 110 %
ESC △	Press the ESC key twice and then press the △ key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.9.2. Setting the total

4.9.2.1. Setting the total pulse (pulse value, pulse width)

Description

- Set for total a process variable (flow rate) by total meter, etc. according to total pulse output.
- Pulse value: Total amount (volume) per pulse.
A pulse is outputted when the total volume has attained an amount set by the pulse value, and adds to the total pulse count (in case of total pulse indication). Settable range: 0.000001 to 99999999
* Set the total unit before setting the pulse value. (See Section 4.8.3.)
- Pulse width: Width of total pulse output.
Select a pulse width according to a corresponding total meter out of menus. Settable range: 5ms, 10ms, 50ms, 100ms, 200ms
Note) If the output is through DO2 (relay contact), select 50ms or longer. (See Section 4.9.3.)
- Restrictions in the setup
Output of total pulses involves the following restrictions depending on the DO output port (DO1, DO2, DO3).

DO output port	Frequency range of pulse output (at full scale flow rate)	Pulse width
DO1, DO2: Transistor, open collector	100 pulse/sec	5ms, 10ms, 50ms, 100ms, 200ms
DO3: Relay contact	1 pulse/sec	50ms, 100ms, 200ms

Furthermore, the maximum output frequency is restricted also by the setup of the pulse width. Therefore, set the pulse width and pulse value so that both of condition 1 and condition 2 indicated below are satisfied. Correct motions may not occur, if any setup that does not satisfy both of condition 1 and condition 2 is made.

Condition 1:

$$\frac{\text{FULL SCALE}^{\text{Note1)}} [\text{m}^3/\text{s}]}{\text{TOTAL RATE} [\text{m}^3]} \leq \begin{matrix} 100[\text{Hz}] & (\text{In case of DO1, DO2}) \\ 1[\text{Hz}] & (\text{In case of DO3}) \end{matrix}$$

Condition 2:

$$\frac{\text{FULL SCALE}^{\text{Note1)}} [\text{m}^3/\text{s}]}{\text{TOTAL RATE} [\text{m}^3]} \leq \frac{1000}{2 \times \text{PULSE WIDTH} [\text{ms}]}$$

Note 1) The range of FULL SCALE1 or FULL SCALE2, whichever is larger, is the object in the case of automatic 2-range setup, forward and reverse range setup or forward and reverse automatic 2-range setup.

Note 2) Restrictions in the maximum output frequency of each output port is also applied when the flow rate exceeds the set range. Therefore, if such a setup that the maximum frequency occurs at the time of 100% flow rate of the set range is made, there is a possibility where the total pulse output is incapable of following when the flow rate exceeds 100% and accurate total value cannot be obtained if over-range continues for a long time. If there are cases where the flow rate exceeds 100%, therefore, review the range and pulse value so that the maximum frequency will not exceed the restricted level.

Example of calculation

Calculate the range that permits setup of the total value under the range and pulse width indicated below.
When the range and the pulse width are as follows.

FLOW SPAN -1: 36[m³/h] (=0.01[m³/s]), Pulse width:50[ms]

i) In case of DO1/DO2 output

Condition 1

$$\text{TOTAL RATE} \geq \frac{\text{FULL SCALE} [\text{m}^3/\text{s}]}{100[\text{Hz}]} = \frac{0.01 [\text{m}^3/\text{s}]}{100 [\text{Hz}]} = 0.0001 [\text{m}^3] = 0.1 [\text{L}]$$

As above:

$$0.1 [\text{L}] \leq \text{TOTAL RATE} \dots\dots\dots \text{A}$$

Condition 2

$$\text{TOTAL RATE} \geq \text{FULL SCALE} [\text{m}^3/\text{s}] \times \frac{2 \times \text{PULSE WIDTH} [\text{ms}]}{1000} = 0.01 [\text{m}^3/\text{s}] \times \frac{2 \times 50 [\text{ms}]}{1000} = 0.001 [\text{m}^3] = 1 [\text{L}] \dots\dots\dots \text{B}$$

The settable range of the total value that satisfies both of condition 1 and condition 2 is as follows from results of calculation A and B.
1 [L] ≤ TOTAL RATE

ii) In case of DO3 output

Condition 1

$$\text{TOTAL RATE} \geq \frac{\text{FULL SCALE} [\text{m}^3/\text{s}]}{1 [\text{Hz}]} = \frac{0.01 [\text{m}^3/\text{s}]}{1 [\text{Hz}]} = 0.01 [\text{m}^3] = 10 [\text{L}] \dots\dots\dots \text{C}$$

Condition 2 is same as that of the case of DO1 output indicated above.

Therefore, the settable range of the total value is as follows from results of calculation B and C.

$$\underline{10 [\text{L}] \leq \text{PULSE VALUE} \leq 864 [\text{m}^3]}$$

Note) When the total setting value is "0", total pulse is not output.

Note) When setting, stop status is set at the total mode.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set total value to 0.1m ³ /pulse, and pulse width to 100ms. * Set the total value beforehand.	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 5 times to display "TOTAL".	TOTAL
	Press the key once to display "TOTAL MODE".	TOTAL MODE STOP
	Press the key once to display "TOTAL RATE".	TOTAL RATE 0 m3
	Press the key once to display the cursor.	TOTAL RATE 00000000 m3
	Press the key for 7 times to move the cursor.	TOTAL RATE 00000000 m3
	Press the key several times to display decimal point.	TOTAL RATE 000000.0 m3
	Press the key once to move the cursor.	TOTAL RATE 000000.0 m3
	Press the key once to display "1".	TOTAL RATE 000000.1 m3
	Press the key once to register.	TOTAL RATE ** COMPLETE **
	----- TOTAL RATE has been registered. -----	TOTAL RATE 0.1 m3
	Press the key twice to display "PULSE WIDTH".	PULSE WIDTH 50.0 msec
	Press the key once to blink the cursor.	PULSE WIDTH 50.0 msec
	Press the key twice, and select "100.0msec".	PULSE WIDTH 100.0 msec
	Press the key once to register.	PULSE WIDTH ** COMPLETE **
	----- PULSE WIDTH has been registered. -----	PULSE WIDTH 100.0 msec
	Press the key for 3 times to display "TOTAL MODE".	TOTAL MODE STOP
	Press the key once to blink the cursor.	TOTAL MODE STOP
	Press the key once, and select "TOTAL PRESET".	TOTAL MODE TOTAL PRESET
	Press the key once to register.	TOTAL MODE ** COMPLETE **
	----- TOTAL MODE has been registered. -----	TOTAL MODE TOTAL PRESET
	Press the key twice and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.9.2.2. Setting the preset value

Description


- Preset value: Value which appears on the total counter when the total value has been reset.

Settable range: 0 to 99999999

<Note> A resetting action simultaneously resets both forward total memory and reverse total memory.

Set the total unit beforehand in the MEASURE SETUP mode. (Refer to 4.8.3.)

When setting, stop status is set at the total mode.



For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
Key operation	Set the preset value to 100m ³ . * Set the total unit beforehand.	
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
▼		
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
▼		
△	Press the △ key for 5 times to display "TOTAL".	TOTAL
▼		
ENT	Press the ENT key once to display "TOTAL MODE".	TOTAL MODE STOP
▼		
△	Press the △ key twice to display "TOTAL PRESET".	TOTAL PRESET 0 m3
▼		
ENT	Press the ENT key once to display the cursor.	TOTAL PRESET 00000000 m3
▼		
▶	Press the ▶ key for 6 times to move the cursor. * Note that, it cannot be entered on the first digit (leftmost).	TOTAL PRESET 00000000 m3
▼		
△	Press the △ key once to display "1".	TOTAL PRESET 00000100 m3
▼		
ENT	Press the ENT key once to register.	TOTAL PRESET ** COMPLETE **
▼		
▼	----- "TOTAL PRESET" has been registered. -----	TOTAL PRESET 100 m3
▼		
△	Press the △ key for 4 times to display "TOTAL MODE".	TOTAL MODE STOP
▼		
ENT	Press the ENT key once to blink the cursor.	TOTAL MODE STOP
▼		
△	Press the △ key once, and select "TOTAL PRESET".	TOTAL MODE TOTAL PRESET
▼		
ENT	Press the ENT key once to register.	TOTAL MODE ** COMPLETE **
▼		
▼	----- "TOTAL MODE" has been registered. -----	TOTAL MODE TOTAL PRESET
▼		
ESC △	Press the ESC key twice and then press the △ key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.9.2.3. TOTAL mode (total reset, start, stop)

Description

- The total is started, stopped or reset.
- Settable range: START, STOP, TOTAL RESET
- START: Starts totalizing. Totalizes continuously from the stopped status.
- STOP : Stops totalizing. Setting cannot be changed when it is not stopped.
- RESET: Resets the total memory to the preset value, and starts totalizing.
- <Note> A resetting action simultaneously resets both forward total memory and reverse total memory.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Reset the total value (preset value 0m ³), and restart a total.	
Key operation	Description	Display
		<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0.00 m3/h ----- + 127.26 m3 </div>
△	Press the △ key twice to display "OUTPUT SETTING".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> OUTPUT SETTING ----- </div>
▼		
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> ZERO ADJUSTMENT ----- SET ZERO </div>
▼		
△	Press the △ key for 5 times to display "TOTAL".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> TOTAL ----- </div>
▼		
ENT	Press the ENT key once to display "TOTAL MODE".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> TOTAL MODE ----- START </div>
▼		
ENT	Press the ENT key once to blink the cursor.	<div style="border: 1px solid black; padding: 2px; text-align: center;"> TOTAL MODE ----- START </div>
▼		
△	Press the △ key twice to display "TOTAL RESET".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> TOTAL MODE ----- TOTAL PRESET </div>
▼		
ENT	Press the ENT key twice to execute "TOTAL RESET".	<div style="border: 1px solid black; padding: 2px; text-align: center;"> TOTAL MODE ----- ** COMPLETE ** ↓ </div>
▼		
▼	----- The total operation is started. -----	<div style="border: 1px solid black; padding: 2px; text-align: center;"> TOTAL MODE ----- TOTAL PRESET </div>
▼		
▼		
ESC △	Press the ESC key twice and then press the △ key for 3 times to enter the measurement mode.	<div style="border: 1px solid black; padding: 2px; text-align: center;"> 0.00 m3/h ----- 0.00 m3 </div>

4.9.2.4. Determining how to dispose of total at error (BURNOUT)

Description

BURNOUT (TOTAL)

- Determines how to dispose of the total when the measurement status is abnormal on account of an empty pipe interior or bubbles mixed in fluid (common to total indication and total pulse output).
- Settable range:
 HOLD : Stops the total (as factory set).
 NOT USED: Continues the total according to a flow rate marked immediately before the error occurrence.

BURNOUT TIMER

- Sets the time from error occurrence to error processing.
- Settable range: 0 to 900sec (factory set: 10sec)
 The total continues until the burnout timer is actuated.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Change the processing from "BURNOUT" to "HOLD", and change the burnout timer setting from 10 seconds to 15 seconds.	
Key operation	Description	Display
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
▼		
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
▼		
△	Press the △ key for 5 times to display "TOTAL".	TOTAL
▼		
ENT	Press the ENT key once to display "TOTAL MODE".	TOTAL MODE START
▼		
△	Press the △ key for 4 times to display "BURNOUT(TOTAL)".	BURNOUT(TOTAL) HOLD
▼	Because HOLD (factory set) is already registered, go to the next step.	
▼	Note) For setting "NOT USED", press the //ENT key, and the /// key to select "NOT USED".	
▼		
△	Press the △ key once to display "BURNOUT TIMER".	BURNOUT TIMER 10sec
▼		
ENT	Press the ENT key once to blink the cursor.	BURNOUT TIMER 010sec
▼		
▶	Press the ▶ key twice to move the cursor.	BURNOUT TIMER 010sec
▼		
△	Press the △ key for 5 times to set "5".	BURNOUT TIMER 015sec
▼		
ENT	Press the ENT key once to register.	BURNOUT TIMER ** COMPLETE **
▼		
▼	----- BURNOUT TIMER has been registered. -----	BURNOUT TIMER 15sec
▼		
ESC △	Press the ESC key twice and then press the △ key for 3 times to enter the measurement mode.	0.00 m3/h + 0.00 m3

4.9.3. Setting the DO output

Description

- Selects the output of total pulses and statuses (of alarm, flow switch, total switch, etc.).
- Settable range (common to DO1, DO2 and DO3)
 - NOT USED : Does not use the contact output.
 - +TOTAL PULSE : Outputs the forward total pulses.
 - TOTAL PULSE : Outputs total pulse in reverse direction.
 - FULL SCALE 2 : Selects a contact output as FULL SCALE 2 measurement status.
(forward automatic 2 ranges, forward and reverse range, forward/reverse automatic 2 ranges)
- ALARM
 - ALL : Selects a contact output at HARDWARE FAULT or PROCESS ERROR status.
 - HARDWARE FAULT : Selects a contact output when circuit error such as memory occurred.
 - PROCESS ERROR : Selects a contact output when no waves are received, or waves are unstable.
- FLOW SWITCH
 - FLOW SW HIGH : Selects a contact output when flow rate is above the setting.
 - FLOW SW LOW : Selects a contact output when flow rate is below the setting.
- TOTAL SWITCH : Selects a contact output when total value exceeds the setting.
- AO RANGE OVER : Selects a contact output when the lower and upper limits of range are above the setting.
- PULSE RANGE OVER : Selects a contact output when the total pulse output exceeds the maximum output frequency.
- FLOW DIRECTION : Selects a contact output when the flow is in reverse direction.
- CONTACT ACTION
 - ACTIVE ON : Normally off (DO1/DO2) or normal open (DO3).
 - ACTIVE OFF : Normally on (DO1/DO2) or normal close (DO3).



- If the contact action is set to "ACTIVE OFF", DO output is provided when the power is turned on.
- Check if DO output can be modified before setting.

<Note> DO output specifications

- DO1/DO2 : Open collector, Contact capacity 30V DC, 0.1A
When total pulse output is selected (Note: See 4.9.2.1)
100 pulses/s or less (at full scale flow rate)
Pulse width: 5, 10, 50, 100 or 200ms.
- DO3 : Relay contact, Contact capacity 220V AC/30V DC, 1A
Service life 200,000 times (under rated load), Can be replaced if provided with a socket. (See 6.4. How to replace the relay)
When total pulse output is selected (Note: See 4.9.2.1)
1 pulse/s or less (at full scale flow rate)
Pulse width: 50, 100 or 200ms.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)






















4.9.3.1. How to validate the total pulse output

Description

- Validates the total pulse output for DO1 OUT, DO2 OUT and/or DO3 OUT.
- +TOTAL PULSE: Outputs flow rate total pulse in forward direction.
- TOTAL PULSE : Reverse flow rate total pulse output.
- Note) Referring to Section 4.9.2.1., set the pulse value, pulse width, etc.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
Key operation	Set the DO1 output to "+ TOTAL PULSE". Also, set the contact to "ACTIVE ON".	
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 6 times to display "DO1 OUT".	DO1 OUT NOT USED
	* Press the key again to display "DO2 OUT".	
	* Press the key once again to display "DO3 OUT".	
	Press the key once to blink the cursor.	DO1 OUT NOT USED

 	<p>Press the  key once to display "+TOTAL PULSE" on the 2nd line.</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="border-bottom: 1px dashed black;">DO1 OUT</td> <td style="border-bottom: 1px dashed black; text-align: right;">+TOTAL PULSE</td> </tr> </table>	DO1 OUT	+TOTAL PULSE		
DO1 OUT	+TOTAL PULSE					
	<p>Press the  key again to select "-TOTAL PULSE".</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="border-bottom: 1px dashed black;">DO1 OUT</td> <td style="border-bottom: 1px dashed black; text-align: center;">** COMPLETE **</td> </tr> </table>	DO1 OUT	** COMPLETE **		
DO1 OUT	** COMPLETE **					
  	<p>Press the  key once to register "+TOTAL PULSE".</p> <p style="text-align: center;">----- "+TOTAL PULSE" has been registered. -----</p>	<p style="text-align: center;">↓</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="border-bottom: 1px dashed black;">STATUS OUT</td> <td style="border-bottom: 1px dashed black; text-align: right;">CONTACT ACTION</td> </tr> </table>	STATUS OUT	CONTACT ACTION		
STATUS OUT	CONTACT ACTION					
	<p>Press the  key once to display "CONTACT ACTION".</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="border-bottom: 1px dashed black;">CONTACT ACTION</td> <td style="border-bottom: 1px dashed black; text-align: right;">ACTIVE ON</td> </tr> </table>	CONTACT ACTION	ACTIVE ON		
CONTACT ACTION	ACTIVE ON					
	<p>Press the  key once to register "ACTIVE ON" (normally off).</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="border-bottom: 1px dashed black;">CONTACT ACTION</td> <td style="border-bottom: 1px dashed black; text-align: center;">** COMPLETE **</td> </tr> </table>	CONTACT ACTION	** COMPLETE **		
CONTACT ACTION	** COMPLETE **					
  	<p>* To select normally on, press the  key.</p> <p style="text-align: center;">----- "ACTIVE ON" has been registered. -----</p>	<p style="text-align: center;">↓</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="border-bottom: 1px dashed black;">STATUS OUT</td> <td style="border-bottom: 1px dashed black; text-align: right;">CONTACT ACTION</td> </tr> </table>	STATUS OUT	CONTACT ACTION		
STATUS OUT	CONTACT ACTION					
 	<p>Press the  key twice and then press the  key for 3 times to enter the measurement mode.</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="border-bottom: 1px dashed black; text-align: center;">0.000</td> <td style="border-bottom: 1px dashed black; text-align: right;">%</td> </tr> <tr> <td style="border-bottom: 1px dashed black; text-align: center;">0.000</td> <td style="border-bottom: 1px dashed black; text-align: right;">m3/h</td> </tr> </table>	0.000	%	0.000	m3/h
0.000	%					
0.000	m3/h					

4.9.4. Setting the LCD indication

Description

- Flow velocity indication

Selectable flow velocity units: m/s (if SYSTEM UNIT was set to METRIC) (See 4.8.1)

<Note> The decimal point position is fixed. (Decimal point 3 digits)

- Flow rate indication

Selectable flow rate indications: Actual value reading, % reading.

<Note> The indication unit is as selected by FLOW UNIT. (See 4.8.2.)

- Total indication

Selectable total indications: Actual total value reading (forward/reverse flow), total pulse count (forward/reverse flow).

<Note> The indication unit is as selected by TOTAL UNIT. (See 4.9.4.)

- How to validate the indication

Set the DISPLAY setting mode to 1st ROW (for indication on 1st line) or 2nd ROW (for indication on 2nd line), and further select indication contents.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Display the 1st line of LCD indication in percentages (%).	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	
	Press the key once to display "ZERO ADJUSTMENT".	
	Press the key for 3 times to display "DISPLAY".	
	Press the key once to blink the cursor.	
	Press the key again, and select "1ST LOW".	
	Press the key twice to display "FLOW RATE(%)".	
	Press the key once, and select and fix "FLOW RATE(%)" to display "1:DECIMAL POINT".	
	Press the key once to shift the decimal point position to next place.	
	Press the key once to register.	
	——— FLOW RATE(%) indication has been set. ——	
	Press the key twice and then press the key for 3 times to enter the measurement mode.	

4.9.5. Setting the damping

Description

- Used for attenuating the variation of measured value.
A time constant is set (response time of about 63%).

Settable range: 0.0 to 100.0sec in 0.1 sec steps

Note) In case you set to 0 sec, response time become as below.

- System cycle 0.2sec
- Dead time 0.2sec or less, time constant 0.1sec

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Change the damping from 5 to 20 sec.	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	
	Press the key once to display "ZERO ADJUSTMENT".	
	Press the key once to display "DAMPING".	
	Press the key once to blink the cursor.	
	Set "20" by the key and the key.	
	Press the key once to register.	
	Press the key once and then press the key for 3 times to enter the measurement mode.	

4.9.6. Setting the low flow rate cutting

Description


- The output can be cut when the flow rate is too small.
- Effective for indication, analog output (4-20mA) and total operation.

Settable range: 0 to 5 [m/s] in terms of flow velocity.
(Factory set: 0.150 [m³/h])

Note 1) As required, set the low flow rate cut because the flow meter may read a flow rate when the fluid in the piping is moving on account of convection, etc. even if the valves are closed.

Note 2) The flow rate unit is as selected by "FLOW UNIT" in "MEASURE SETUP".
(See 4.8.2.)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)




Operation (example)	Set the low flow rate cut point to 0.5 [m ³ /h].	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key twice to display "CUT OFF".	CUT OFF 0.150 m3/h
	Press the key once to blink the cursor.	CUT OFF 0000.150 m3/h
		0000.150 m3/h
		0000.550 m3/h
		0000.550 m3/h
	Set "0.5" by the key and the key.	CUT OFF 0000.500 m3/h
	Press the key once to register.	CUT OFF ** COMPLETE **
	—— CUT OFF has been registered. ——	CUT OFF 0.500 m3/h
	Press the key once and then press the key for 3 times to enter the measurement mode.	0.000 m/s 0.000 m3/h

4.10. Application operation of parameter

4.10.1. Setting automatic 2 ranges

Description




































- The function carries out a measurement while changing over the range according to the flow rate.
- The current output changes with the action range as illustrated on the right.
- The hysteresis can be set to between 0 and 20% of the smaller range.
- Upon setting DO1, DO2 or DO3 to "FULL SCALE 2", a contact outputs "FULL SCALE 2" action. Select "ACTIVE ON" or "ACTIVE OFF" separately. (See 4.10.5.)
- Settable range: 0.3 to 32 [m/s] in terms of flow velocity in piping for any of FULL SCALE1 and FULL SCALE2.
 - * Preset PIPE PARAMETER and FLOW UNIT.
 - * If a value beyond the settable range is inputted, "INPUT ERROR" appears and then last setting is resumed.
 - * If "FLOW UNIT" has been changed after setting the range, recommence the range setting.
 - * When FULL SCALE2 is not used (in the case of single range), set "0" to FULL SCALE2.



<Note> The flow rate unit is as selected by "FLOW UNIT". Before range setting, set the "FLOW UNIT". (See 4.8.2.)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)


Operation (example)	Set "AUTO 2" to "RANGE TYPE", 10[m ³ /h] to "FULL SCALE1", and 60[m ³ /h] to "FULL SCALE2". Set "RANGE HYS." to 7%. * Preset "PIPE PARAMETER" and "FLOW UNIT".	
Key operation	Description	Display
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
△	Press the △ key for 4 times to display "RANGE".	RANGE
ENT	Press the ENT key twice to blink the cursor.	RANGE TYPE SINGLE
△	Press the △ key once, and select "AUTO 2".	RANGE TYPE AUTO 2
ENT	Press the ENT key once to display "RANGE TYPE".	RANGE TYPE AUTO 2
△	Press the △ key once to display "FULL SCALE1".	FULL SCALE1 20.0000 m3/h
ENT	Press the ENT key once to blink the cursor on the 2nd line.	FULL SCALE1 0020.0000 m3/h
▶	Press the ▶ key several times to align the cursor to "2".	FULL SCALE1 0020.0000 m3/h
△	Press the △ key several times to change to "1". Note) To change the decimal point position, align the cursor with a place to change to, and press the △ key likewise.	FULL SCALE1 0010.0000 m3/h
ENT	Press the ENT key once to register.	FULL SCALE1 ** COMPLETE **
△	Press the △ key once to display "FULL SCALE2".	FULL SCALE1 10.0000 m3/h
△		FULL SCALE2 0.0000 m3/h

                       	<p>Press the  key once to blink the cursor.</p> <p>Press the  key twice to move the cursor.</p> <p>Press the  key for 6 times to set "6".</p> <p>Press the  key once to register.</p> <p style="text-align: center;">----- FULL SCALE2 has been registered. -----</p> <p>Press the  key once to display "RANGE HYS.".</p> <p>Press the  key once to blink the cursor.</p> <p>Press the  key once to move the cursor.</p> <p>Press the  key twice to set "7".</p> <p>Press the  key once to register.</p> <p style="text-align: center;">----- RANGE HYS. has been registered. -----</p> <p>Press the  key twice and then press the  key for 3 times to enter the measurement mode.</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">FULL SCALE2</td> </tr> <tr> <td style="text-align: center;">0000.0000 m3/h</td> </tr> <tr> <td style="text-align: center;">FULL SCALE2</td> </tr> <tr> <td style="text-align: center;">0000.0000 m3/h</td> </tr> <tr> <td style="text-align: center;">FULL SCALE2</td> </tr> <tr> <td style="text-align: center;">0060.0000 m3/h</td> </tr> <tr> <td style="text-align: center;">FULL SCALE2</td> </tr> <tr> <td style="text-align: center;">** COMPLETE **</td> </tr> <tr> <td style="text-align: center;">↓</td> </tr> <tr> <td style="text-align: center;">FULL SCALE2</td> </tr> <tr> <td style="text-align: center;">60.0000 m3/h</td> </tr> <tr> <td style="text-align: center;">RANGE HYS.</td> </tr> <tr> <td style="text-align: center;">5.00 %</td> </tr> <tr> <td style="text-align: center;">RANGE HYS.</td> </tr> <tr> <td style="text-align: center;">05.00 %</td> </tr> <tr> <td style="text-align: center;">RANGE HYS.</td> </tr> <tr> <td style="text-align: center;">05.00 %</td> </tr> <tr> <td style="text-align: center;">RANGE HYS.</td> </tr> <tr> <td style="text-align: center;">07.00 %</td> </tr> <tr> <td style="text-align: center;">RANGE HYS.</td> </tr> <tr> <td style="text-align: center;">** COMPLETE **</td> </tr> <tr> <td style="text-align: center;">↓</td> </tr> <tr> <td style="text-align: center;">RANGE HYS.</td> </tr> <tr> <td style="text-align: center;">7.00 %</td> </tr> <tr> <td style="text-align: center;">0.000 %</td> </tr> <tr> <td style="text-align: center;">0.000 m3/h</td> </tr> </table>	FULL SCALE2	0000.0000 m3/h	FULL SCALE2	0000.0000 m3/h	FULL SCALE2	0060.0000 m3/h	FULL SCALE2	** COMPLETE **	↓	FULL SCALE2	60.0000 m3/h	RANGE HYS.	5.00 %	RANGE HYS.	05.00 %	RANGE HYS.	05.00 %	RANGE HYS.	07.00 %	RANGE HYS.	** COMPLETE **	↓	RANGE HYS.	7.00 %	0.000 %	0.000 m3/h
FULL SCALE2																												
0000.0000 m3/h																												
FULL SCALE2																												
0000.0000 m3/h																												
FULL SCALE2																												
0060.0000 m3/h																												
FULL SCALE2																												
** COMPLETE **																												
↓																												
FULL SCALE2																												
60.0000 m3/h																												
RANGE HYS.																												
5.00 %																												
RANGE HYS.																												
05.00 %																												
RANGE HYS.																												
05.00 %																												
RANGE HYS.																												
07.00 %																												
RANGE HYS.																												
** COMPLETE **																												
↓																												
RANGE HYS.																												
7.00 %																												
0.000 %																												
0.000 m3/h																												

4.10.2. Setting the Bi-directional range

Description

- The function measures the flow rate of either forward or reverse flow while changing over the range corresponding to the flow direction.
- The current output changes with the action range as illustrated on the right.
- The hysteresis can be set to between 0 and 20% of the action range.
- Upon setting DO1, DO2 or DO3 to "FULL SCALE2", a contact outputs "FULL SCALE2" action.
Select "ACTIVE ON" or "ACTIVE OFF" separately. (See 4.10.5.)
- Settable range: ± 0.3 to 32 [m/s] in terms of flow velocity in piping for any of FULL SCALE1 and FULL SCALE2.
* Preset PIPE PARAMETER and FLOW UNIT.
* If a value beyond the settable range is inputted, "INPUT ERROR" appears and then last setting is resumed.
* If "FLOW UNIT" has been changed after setting the range, recommence the range setting.
* When FULL SCALE2 is not used (in the case of single range), set "0" to FULL SCALE2.



<Note> The flow rate unit is as selected by "FLOW UNIT" in "MEASURE SETUP" mode. Before range setting, set the "FLOW UNIT". (See 4.8.2.)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)


Operation (example)	Set "BI-DIR" to "RANGE TYPE", 20[m ³ /h] to "FULL SCALE1", and -10[m ³ /h] to "FULL SCALE2". Set "RANGE HYS." to 7%. * Preset "PIPE PARAMETER" and "FLOW UNIT".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 4 times to display "RANGE".	RANGE
	Press the key twice to blink the cursor.	RANGE SINGLE
	Press the key twice, and select "BI-DIR".	RANGE TYPE BI-DIR
	Press the key for 4 times to display "RANGE TYPE".	RANGE TYPE BI-DIR
	Press the key once to display "FULL SCALE1".	FULL SCALE1 50.0000 m3/h
	Press the key once to blink the cursor.	FULL SCALE1 0050.0000 m3/h
	Press the key several times to align the cursor to "5".	FULL SCALE1 0050.0000 m3/h
	Press the key several times to set "2".	FULL SCALE1 0020.0000 m3/h
	Note) To change the decimal point position, align the cursor with a place to change to, and press the key likewise.	
	Press the key once to register.	FULL SCALE1 ** COMPLETE **
	----- FULL SCALE1 has been registered. -----	FULL SCALE1 20.0000 m3/h
	Press the key once to display "FULL SCALE2".	FULL SCALE2 0.0000 m3/h
	Press the key once to register.	FULL SCALE2 0000.0000 m3/h
	Press the key several times to display "-" on the 1st line.	FULL SCALE2 -000.0000 m3/h

▶	Press the ▶ key twice to move the cursor.	FULL SCALE2 ----- -000.0000 m3/h
▼		
▲	Press the ▲ key once to set "1".	FULL SCALE2 ----- -010.0000 m3/h
▼		
ENT	Press the ENT key once to register.	FULL SCALE2 ----- ** COMPLETE **
▼		↓
▼	----- FULL SCALE2 has been registered. -----	FULL SCALE2 ----- -10.0000 m3/h
▼		
▲	Press the ▲ key once to display "RANGE HYS.".	RANGE HYS. ----- 5.00 %
▼		
ENT	Press the ENT key once to blink the cursor.	RANGE HYS. ----- 05.00 %
▼		
▶	Press the ▶ key once to move the cursor.	RANGE HYS. ----- 05.00 %
▼		
▲	Press the ▲ key twice to set "7".	RANGE HYS. ----- 07.00 %
▼		
ENT	Press the ENT key once to register.	RANGE HYS. ----- ** COMPLETE **
▼		↓
▼	----- RANGE HYS. has been registered. -----	RANGE HYS. ----- 7.00 %
▼		
ESC ▲	Press the ESC key twice and then press the ▲ key for 3 times to enter the measurement mode.	0.000 % ----- 0.000 m3/h

4.10.3. Setting the Bi-directional auto 2 range

Description

- The function measures the flow rate of either forward or reverse flow while changing over the range corresponding to the flow direction.
- The current output changes with the action range as illustrated on the right.
- The hysteresis can be set to between 0 and 20% of either range of FULL SCALE1 or FULL SCALE2 and FULL SCALE3 or FULL SCALE4 whichever the span is smaller.
- Upon setting DO1, DO2 or DO3 to "FULL SCALE2", a contact outputs "FULL SCALE2" action. Select "ACTIVE ON" or "ACTIVE OFF" separately. (See 4.10.5.)
- Settable range: ± 0.3 to 32[m/s] in terms of flow velocity in piping for any of FULL SCALE1 and FULL SCALE2. When FULL SCALE1 and FULL SCALE2 are set, FULL SCALE3 and FULL SCALE4 are automatically set. FULL SCALE1 and FULL SCALE3, FULL SCALE2 and FULL SCALE4 are related as follows.
 $|FULL\ SCALE1| = |FULL\ SCALE3|$
 $|FULL\ SCALE2| = |FULL\ SCALE4|$
 * Preset PIPE PARAMETER and FLOW UNIT.
 * If a value beyond the settable range is inputted, "INPUT ERROR" appears and then last setting is resumed.
 * If "FLOW UNIT" has been changed after setting the range, recommence the range setting.
 * When FULL SCALE2 is not used (in the case of single range), set "0" to FULL SCALE2.



<Note> The flow rate unit is as selected by "FLOW UNIT" in "MEASURE SETUP" mode. Before range setting, set the "FLOW UNIT". (See 4.8.2.)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set "BI-DIR AUTO 2" to "RANGE TYPE", 10[m ³ /h] to "FULL SCALE1", and 60[m ³ /h] to "FULL SCALE2". Set "RANGE HYS." to 7%. * Preset "PIPE PARAMETER" and "FLOW UNIT".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 4 times to display "RANGE".	RANGE
	Press the key twice to blink the cursor.	RANGE TYPE SINGLE
	Press the key for 3 times, and select "BI-DIR AUTO 2".	RANGE TYPE BI-DIR AUTO 2
	Press the key once to display "RANGE TYPE".	RANGE TYPE BI-DIR AUTO 2
	Press the key once to display "FULL SCALE1".	FULL SCALE1 20.0000 m3/h
	Press the key once to blink the cursor on the 2nd line.	FULL SCALE1 0020.0000 m3/h
	Press the key several times to align the cursor to "2".	FULL SCALE1 0020.0000 m3/h
	Press the key several times to set "1".	FULL SCALE1 0010.0000 m3/h
	Note) To change the decimal point position, align the cursor with a place to change to, and press the key likewise.	
	Press the key once to register.	FULL SCALE1 ** COMPLETE **
	----- FULL SCALE1 has been registered. -----	FULL SCALE1 10.0000 m3/h



Press the key once to display "FULL SCALE2".



Press the key once to blink the cursor.



Press the key twice to move the cursor.



Press the key for 6 times to set "6".



Press the key once to register.

----- FLOW SPAN2 has been registered. -----



Press the key once to display "RANGE HYS.".



Press the key once to blink the cursor.



Press the key once to move the cursor.



Press the key twice to set "7".



Press the key once to register.

----- RANGE HYS. has been registered. -----



Press the key twice and then press the key for 3 times to enter the measurement mode.

FULL SCALE2

0.0000 m3/h

FULL SCALE2

0000.0000 m3/h

FULL SCALE2

0000.0000 m3/h

FULL SCALE2

0060.0000 m3/h

FULL SCALE2

** COMPLETE **



FULL SCALE2

60.0000 m3/h

RANGE HYS.

5.00 %

RANGE HYS.

05.00 %

RANGE HYS.

05.00 %

RANGE HYS.

07.00 %

RANGE HYS.

** COMPLETE **



RANGE HYS.

7.00 %


0.000 %

0.000 m3/h

4.10.4. Rate limit

Description

- Spike noise input such as slurry fluid can be cut and output.
- Settable range
 - (1) RATE LIMIT 0 to 5 [m/s] in terms of flow velocity. Absolute value is input (Factory set: 0[m³/h])
 - (2) RATE TIMER Enter in the range of 0 to 900 sec. (Factory set: 0sec)



(Note 1) When input exceeding a limit value continues more than limit time, it is output as a true signal.

(Note 2) When the limit time is set to 0sec, this function does not operate.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set 5m ³ /h to RATE LIMIT, and 10sec to RATE LIMIT TIMER. * Preset "PIPE PARAMETER" and "FLOW UNIT".	Display
Key operation	Description	
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
▼		
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
▼		
△	Press the △ key for 4 times to display "RANGE".	RANGE
▼		
ENT	Press the ENT key once to display "RANGE TYPE".	RANGE TYPE SINGLE
▼		
△	Press the △ key for 8 times to display "RATE LIMIT".	RATE LIMIT 0.000 m3/h
▼		
ENT	Press the ENT key once to blink the cursor.	RATE LIMIT 00000.000 m3/h
▼		
▶	Press the ▶ key for 4 times to align the cursor.	RATE LIMIT 00000.000 m3/h
▼		
△	Press the △ key several times to set "5".	RATE LIMIT 00005.000 m3/h
▼		
ENT	Press the ENT key once to register.	RATE LIMIT ** COMPLETE **
▼		
▼	——— RATE LIMIT has been registered. ———	RATE LIMIT 5.000 m3/h
▼		
△	Press the △ key once to display "RATE LIMIT TIMER".	RATE LIMIT TIMER 0 sec
▼		
ENT	Press the ENT key once to blink the cursor.	RATE LIMIT TIMER 000 sec
▼		
▶	Press the ▶ key once to align the cursor.	RATE LIMIT TIMER 000 sec
▼		
△	Press the △ key several times to set "1".	RATE LIMIT TIMER 010 sec
▼		


ENT



ESC 

Press the ENT key once to register.

----- RATE LIMIT TIMER has been registered. -----

Press the ESC key twice and then press the  key for 3 times to enter the measurement mode.

RATE LIMIT TIMER

** COMPLETE **



RATE LIMIT TIMER

10 sec

0.000 %

0.000 m3/h

4.10.5. Setting the DO output

4.10.5.1. How to validate outputting the FULL SCALE 2

Description
 ● Select a contact output as DO1, DO2 and/or DO3 at FULL SCALE2 measurement status.
 For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
	Set the DO1 output to "FULL SCALE2". Also, set the contact to "ACTIVE ON".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 6 times to display "DO1 OUT".	DO1 OUT NOT USED
	* Press the key again to display "DO2 OUT".	
	* Press the key once again to display "DO3 OUT".	
	Press the key once to blink the cursor.	DO1 OUT NOT USED
	Press the key for 3 times to display "FULL SCALE2" on the 2nd line.	DO1 OUT FULL SCALE2
	Press the key once to register "FULL SCALE2".	DO1 OUT ** COMPLETE **
	----- "FULL SCALE2" has been registered. -----	STATUS OUT CONTACT ACTION
	Press the key once to display "CONTACT ACTION".	CONTACT ACTION ACTIVE ON
	Press the key once to register "ACTIVE ON"(normally off).	CONTACT ACTION ** COMPLETE **
	* To select normally on, press the key.	
	----- ACTIVE ON has been registered. -----	STATUS OUT CONTACT ACTION
	Press the key twice and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.10.5.2. How to validate the alarm output

Description

- Select a contact output as DO1 and/or DO2 when received wave or E²PROM is abnormal.
- Settable range
 ALL : Select a contact output when hardware and received wave (nothing, unstable) are abnormal.
 HARDWARE FAULT : Select a contact output when circuit is abnormal.
 PROCESS ERROR : Select a contact output when received wave is abnormal.


For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
Key operation		
	Set the DO1 output to "PROCESS ERROR". Also, set the contact to "ACTIVE ON".	
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
▼		
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
▼		
△	Press the △ key for 6 times to display "DO1 OUT".	DO1 OUT NOT USED
▼		
△	* Press the △ key again to display "DO2 OUT".	
▼		
△	* Press the △ key once again to display "DO3 OUT".	
▼		
ENT	Press the ENT key once to blink the cursor.	DO1 OUT NOT USED
▼		
△	Press the △ key for 4 times to display "ALARM" on the 2nd line.	DO1 OUT ALARM
▼		
ENT	Press the ENT key once to display the ALARM select panel.	ALARM ALL
▼		
△	Press the △ key twice to display "PROCESS ERROR".	ALARM PROCESS ERROR
▼		
ENT	Press the ENT key once to register.	ALARM ** COMPLETE **
▼		
▼	----- "PROCESS ERROR" has been registered. -----	STATUS OUT CONTACT ACTION
▼		
ENT	Press the ENT key once to display "CONTACT ACTION".	CONTACT ACTION ACTIVE ON
▼		
ENT	Press the ENT key once to register "ACTIVE ON"(normally off).	CONTACT ACTION ** COMPLETE **
▼		
▼	* To select normally on, press the △ key.	
▼	----- "ACTIVE ON" has been registered. -----	STATUS OUT CONTACT ACTION
▼		
ESC △	Press the ESC key twice and then press the △ key for 3 times to enter the measurement mode.	0.000 m/s 0.000 m3/h

4.10.5.3. Setting the flow switch

Description

- Select a contact output as DO1, DO2 and/or DO3 when the flow rate has exceeded a setting.



● Settable range

Flow rate : 0 to 32m/s in terms of flow velocity.

Action : FLOW SW HIGH or FLOW SW LOW

Contact action: ACTIVE ON : DO1/DO2: Normally off DO3: Normally open

ACTIVE OFF: DO1/DO2: Normally on DO3: Normally close

Note) The hysteresis value set in Section 4.9.1 "Setting of flow rate range" is applied to the action range.


For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set the DO1 output to "FLOW SW HIGH", and upper limit flow rate to 12 [m ³ /h]. Also, set the contact to "ACTIVE ON".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 6 times to display "DO1 OUT".	DO1 OUT NOT USED
	* Press the key again to display "DO2 OUT".	
	* Press the key once again to display "DO3 OUT".	
	Press the key once to blink the cursor.	DO1 OUT NOT USED
	Press the key for 5 times to display "FLOW SWITCH" on the 2nd line.	DO1 OUT FLOW SWITCH
	Press the key once to display the flow rate setting screen of "FLOW SW HIGH".	FLOW SW HIGH 10.0000 m3/h
	* Press the key once to display the flow rate setting screen of "FLOW SW LOW".	
	Press the key once to blink the cursor.	FLOW SW HIGH 0010.0000 m3/h
	Press the key for 3 times to move the cursor.	FLOW SW HIGH 0010.0000 m3/h
	Press the key twice to set "2".	FLOW SW HIGH 0012.0000 m3/h
	Press the key once to register.	FLOW SW HIGH ** COMPLETE **
	----- "FLOW SW HIGH" has been registered. -----	↓ STATUS OUT CONTACT ACTION
	Press the key once to display "CONTACT ACTION".	CONTACT ACTION ACTIVE ON

ENT




Press the ENT key once to register "ACTIVE ON"(normally off).

* To select normally on, press the  key.

----- "ACTIVE ON" has been registered. -----

ESC 


Press the ESC key twice and then press the  key for 3 times to enter the measurement mode.

CONTACT ACTION	
** COMPLETE **	
↓	
STATUS OUT	CONTACT ACTION
0.000	%
0.000	m3/h

4.10.5.4. How to validate the total switch

Description

- Select a contact output as DO1, DO2 and/or DO3 when the total value exceeds a setting.
- Settable range: 0.000001 to 99999999
 Contact action:
 ACTIVE ON : DO1/DO2: Normally off DO3: Normally open
 ACTIVE OFF: DO1/DO2: Normally on DO3: Normally close
 Note) Different values can be assigned to DO1, DO2 and DO3.



For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set the DO1 output to "TOTAL SWITCH", and change the setting value from 10000[m ³] to 100[m ³]. Also, set the contact to "ACTIVE ON".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 6 times to display "DO1 OUT".	DO1 OUT NOT USED
	* Press the key again to display "DO2 OUT".	
	* Press the key once again to display "DO3 OUT".	
	Press the key once to blink the cursor.	DO1 OUT NOT USED
	Press the key for 6 times to display "TOTAL SWITCH" on the 2nd line.	DO1 OUT TOTAL SWITCH
	Press the key once to display the setting screen of "TOTAL SWITCH".	TOTAL SWITCH 10000 m3
	Press the key once to blink the cursor.	TOTAL SWITCH 00010000 m3
	Press the key for 3 times to move the cursor.	TOTAL SWITCH 00010000 m3
	Press the key for 10 times to set "0".	TOTAL SWITCH 00000000 m3
	Press the key twice to move the cursor.	TOTAL SWITCH 00000000 m3
	Press the key once to set "1".	TOTAL SWITCH 00000100 m3
	Press the key once to register.	TOTAL SWITCH ** COMPLETE **
	----- "TOTAL SWITCH" has been registered. -----	STATUS OUT CONTACT ACTION
	Press the key once to display "CONTACT ACTION".	CONTACT ACTION ACTIVE ON
	Press the key once to register "ACTIVE ON"(normally off).	CONTACT ACTION ** COMPLETE **
	* To select normally on, press the key.	
	----- "ACTIVE ON" has been registered. -----	STATUS OUT CONTACT ACTION
	Press the key twice and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.10.5.5. How to validate the range over output and pulse range over output

Description

- **AO RANGE OVER** : Select a contact output as DO1, DO2 and/or DO3 when the upper limit and lower limit output are above the setting.
- **PULSE RANGE OVER**: Select a contact output as DO1, DO2 and/or DO3 when the total pulse output exceeds the maximum output frequency value.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set the DO1 output to "AO RANGE OVER". Also, set the contact to "ACTIVE ON".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 6 times to display "DO1 OUT".	DO1 OUT NOT USED
	* Press the key again to display "DO2 OUT".	
	* Press the key once again to display "DO3 OUT".	
	Press the key once to blink the cursor.	DO1 OUT NOT USED
	Press the key for 7 times to display "AO RANGE OVER" on the 2nd line.	DO1 OUT AO RANGE OVER
	* Press the key again to display "PULSE RANGE OVER".	
	Press the key once to register "RANGE OVER".	DO1 OUT ** COMPLETE **
	----- "RANGE OVER" has been registered. -----	STATUS OUT CONTACT ACTION
	Press the key once to display "CONTACT ACTION".	CONTACT ACTION ACTIVE ON
	Press the key once to register "ACTIVE ON"(normally off).	CONTACT ACTION ** COMPLETE **
	* To select normally on, press the key.	
	----- "ACTIVE ON" has been registered. -----	STATUS OUT CONTACT ACTION
	Press the key twice and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.10.5.6. How to validate the output at the minus direction action

Description

- Select a contact output as DO1, DO2 and/or DO3 when the flow is in reverse direction.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
Key operation		
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
▼		
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
▼		
△	Press the △ key for 6 times to display "DO1 OUT".	DO1 OUT NOT USED
▼		
△	* Press the △ key again to display "DO2 OUT".	
▼		
△	* Press the △ key once again to display "DO3 OUT".	
▼		
ENT	Press the ENT key once to blink the cursor.	DO1 OUT NOT USED
▼		
△	Press the △ key for 9 times to display "-:FLOW DIRECTION" on the 2nd line.	DO1 OUT -:FLOW DIRECTION
▼		
ENT	Press the ENT key once to register "-:FLOW DIRECTION".	DO1 OUT ** COMPLETE **
▼		
▼		
▼		
▼	----- "-:FLOW DIRECTION" has been registered. -----	STATUS OUT CONTACT ACTION
▼		
ENT	Press the ENT key once to display "CONTACT ACTION".	CONTACT ACTION ACTIVE ON
▼		
ENT	Press the ENT key once to register "ACTIVE ON"(normally off).	CONTACT ACTION ** COMPLETE **
▼		
▼		
▼		
▼	* To select normally on, press the △ key.	
▼		
▼	----- "ACTIVE ON" has been registered. -----	STATUS OUT CONTACT ACTION
▼		
ESC △	Press the ESC key twice and then press the △ key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.10.6. Setting the DI input

Description

- Zero adjustment or total preset can be performed by no-voltage contact input signal.
Note 1) To use the DI input, communication board (option) is required.
- Settable range
NOT USED : Contact input is not used.
TOTAL RESET : Total value becomes the preset value.
ZERO ADJUSTMENT : Zero adjustment can be performed.

CONTACT ACTION

- ACTIVE ON : Normally off. Activated when a contact is closed.
- ACTIVE OFF : Normally on. Activated when a contact is open.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

4.10.6.1. Invalidating the DI input

Description

- Select not to use the contact input of the DI1 INPUT.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Change the DI1 setting from "ZERO ADJUSTMENT" to "NOT USED".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 9 times to display "NOT USED" on the 2nd line.	DI1 INPUT ZERO ADJUSTMENT
	Press the key once to blink the cursor.	DI1 INPUT ZERO ADJUSTMENT
	Press the key once to display "NOT USED" on the 2nd line.	DI1 INPUT NOT USED
	Press the key once to register "NOT USED".	DI1 INPUT ** COMPLETE **
	----- "NOT USED" has been registered. -----	DI1 INPUT NOT USED
	Press the key once and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.10.6.2. How to validate the total preset with the external contact.

Description

- The total value becomes the preset value by closing or opening the contact.
 - The contact should be closed or open for about 1 second.
 - When total presetting, "TOTAL PRESET" is indicated on the 2nd line of the LCD display (for about 4 seconds).
 - Related setting items: 4.9.2.2. Setting the preset value", "4.9.2.3. TOTAL mode"
- Note 1) This function is valid when the LCD display is measurement screen. When the display is setting screen, it becomes invalid.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set the DO1 output to "TOTAL RESET".	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 9 times to display "NOT USED" on the 2nd line.	DI1 INPUT NOT USED
	Press the key once to blink the cursor.	DI1 INPUT NOT USED
	Press the key for once to display "TOTAL RESET" on the 2nd line.	DI1 INPUT TOTAL RESET
	Press the key once to register "TOTAL RESET".	DI1 INPUT ** COMPLETE **
	----- "TOTAL RESET" has been registered. -----	↓ DI1 INPUT TOTAL RESET
	Press the key once and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.10.6.3. How to validate the zero adjustment with the external contact.

Description

- The zero adjustment can be performed by closing or opening the contact.
- The contact should be closed or open for about 1 second.
- During zero adjustment, "ZERO ADJUSTMENT" is indicated on the 2nd line of the LCD display (for about 4 seconds).
- Related setting items: "4.7. Zero Adjustment"

Note 1) This function is valid when the LCD display is measurement screen. When the display is setting screen, it becomes invalid.

Note 2) Even if the measuring fluid is supplied, zero adjustment is carried out by the contact input. Be sure to bring it to the still water status (upstream/downstream valves closed) before the contact input.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set the DI1 output to "ZERO ADJUSTMENT".	
Key operation	Description	Display
△	Press the △ key twice to display "OUTPUT SETTING".	OUTPUT SETTING
▼		
ENT	Press the ENT key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
▼		
△	Press the △ key 9 times to display "DI1 INPUT".	DI1 INPUT NOT USED
▼		
ENT	Press the ENT key once to blink the cursor.	DI1 INPUT NOT USED
▼		
△	Press the △ key for 2 times to display "ZERO ADJUSTMENT" on the 2nd line.	DI1 INPUT ZERO ADJUSTMENT
▼		
ENT	Press the ENT key once to register "ZERO ADJUSTMENT".	DI1 INPUT ** COMPLETE **
▼		
▼		
▼	----- "ZERO ADJUSTMENT" has been registered. -----	DI1 INPUT ZERO ADJUSTMENT
▼		
ESC △	Press the ESC key once and then press the △ key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h


4.10.7. How to compensate the measurement value

Description


- Measurement value can be calibrated arbitrarily.
Zero point and span adjustment can be made.
Settable range
(1) Zero point: -5 to +5 [m/s] in terms of flow velocity in piping.
(2) Span : ±200%

The output value (reading, analog output and total output) is computed by the following expression.

$$\text{Output} = \frac{\text{Measurement value} \times [\text{Span set value \%}]}{100} + \text{Zero point}$$



Zero adjustment movement



Span movement

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Compensate the zero point to 0.5m ³ /h, and the span by +1%.	
Key operation	Description	Display
	Press the key twice to display "OUTPUT SETTING".	OUTPUT SETTING
	Press the key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
	Press the key for 10 times to display "CALIBRATION ZERO".	CALIBRATION ZERO 0.000 m3/h
	Press the key once to blink the cursor.	CALIBRATION ZERO 00000.000 m3/h
	Press the key for 6 times to move the cursor.	CALIBRATION ZERO 00000.000 m3/h
	Press the key for 5 times to set "5".	CALIBRATION ZERO 00000.500 m3/h
	Press the key once to register.	CALIBRATION ZERO ** COMPLETE **
	----- "CALIBRATION ZERO" has been registered. -----	CALIBRATION ZERO 0.500 m3/h
	Press the key once to display "CALIBRATION SPAN".	CALIBRATION SPAN 100.0 %
	Press the key once to blink the cursor.	CALIBRATION SPAN 100.0 %
	Press the key twice to move the cursor.	CALIBRATION SPAN 100.0 %
	Press the key once to set "1".	CALIBRATION SPAN 101.0 %
	Press the key once to register.	CALIBRATION SPAN ** COMPLETE **
	----- "CALIBRATION SPAN" has been registered. -----	CALIBRATION SPAN 101.0 %
	Press the key once and then press the key for 3 times to enter the measurement mode.	0.000 % 0.000 m3/h

4.10.8. Setting of the operation mode

Description


























- Used to switch computation cycle and output cycle.

- **Settable range**

NORMAL : Standard mode (factory-set value), computation/output cycle is approximately 0.5 seconds.

HIGH SPEED: High speed response mode, computation/output cycle is approximately 0.2 seconds.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Switch the operation mode to the high speed response mode.	
Key operation	Description	Display
	Press the  key twice to display "OUTPUT SETTING".	OUTPUT SETTING
		
	Press the  key once to display "ZERO ADJUSTMENT".	ZERO ADJUSTMENT SET ZERO
		
	Press the  key for 12 times to display "OPERATION MODE".	OPERATION MODE NORMAL
		
	Press the  key once to blink the cursor.	OPERATION MODE NORMAL
		
	Press the  key for 6 times to move the cursor.	OPERATION MODE HIGH SPEED
		
	Press the  key once to register.	OPERATION MODE ** COMPLETE **
		
		
		
		
 	Press the  key once and then press the  key for 3 times to enter the measurement mode.	OPERATION MODE HIGH SPEED
		↓ 0.000 % 0.000 m3/h

Reference

The difference between standard mode and high speed mode



High speed mode is unfit for the measurement when foreign objects or air bubbles are contained.


Standard mode is about 10 times more resistant to entry of foreign objects or air bubbles than high speed mode.

4.11. MAINTENANCE MODE





































4.11.1. How to calibrate the analog output

Description

- The calibration is performed so as to obtain 4mA and 20mA when the analog signal (4-20mA DC) output is 0% and 100%, respectively.
- Connect an ammeter to lout terminals as shown below. In the CURRENT CALIBRATION mode, select 4mA or 20mA, and operate the  key (UP) or the  key (Down).



For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Adjust the 4mA and 20mA analog outputs.	
Key operation	Description	Display
	Press the  key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
		
	Press the  key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
		
	Press the  key once to display "CURRENT".	CURRENT
		CARIBRATION
	Press the  key twice to enter the calibration mode of 4mA output.	CARIBRATION
		4 mA
	Adjust the output to 4mA by the  (UP) and the  (down) key, while observing the output of calibration devices such as an ammeter.	
	Press the  key once to register the adjustment result.	CARIBRATION ** COMPLETE **
		↓
	----- 4mA adjustment result has been registered. -----	CARIBRATION 4 mA
		
	Press the  key once, and select 20mA.	CARIBRATION 20mA
		
	Press the  key twice to enter the calibration mode of 20mA output.	CARIBRATION
		20mA
	Adjust the output to 20mA by the  (UP) and the  (down) key.	
	Press the  key once to register the adjustment result.	CARIBRATION ** COMPLETE **
		↓
	----- 20mA adjustment result has been completed. -----	CARIBRATION 20mA
		
 	Press the  key twice and then press the  key once to enter the measurement mode.	0.000 % 0.000 m3/h

4.11.2. How to set the constant current output

Description

- Generates a fixed value output of analog signal.
- Application example: The operation of a connected receiver is checked by generating a fixed value output of analog signal.
- In the constant current setting mode (OUTPUT SETTING), set the constant current output value.
Settable range: -20%(0.8mA) to +120%(23.2mA)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set the constant current output of 50% (12mA).	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key twice to display "OUTPUT SETTING".	CURRENT OUTPUT SETTING
	Press the key once to display the setting screen.	OUTPUT SETTING 0 %
	Press the key once to blink the cursor.	OUTPUT SETTING 000 %
	Note) Start constant current output.	
	Enter "5" by the and the key.	OUTPUT SETTING +050 %
	Press the key once to output 12mA.	OUTPUT SETTING ** COMPLETE **
		↓
	----- Outputting 12mA. -----	OUTPUT SETTING 50 %
	Press the key once to stop constant current output.	CURRENT OUTPUT SETTING
	Note) Current output is in the measurement status.	
	Press the key once and then press the key once to enter the measurement mode.	0.000 % 0.000 m3/h

4.11.3. How to check the action of total pulses

Description

- Checks the action of total pulse output.

The output action can be checked upon designating the number of pulses to be outputted per second.

Settable range: 1 to 100 pulses/s (DO1/DO2 only)

Note 1) The output pulse width is as selected currently. (See 4.9.2.1.)

Set the frequency taking the pulse width into account referring to the following expression.

The number of setting pulses $\leq 1000 / (\text{Pulse width}[\text{ms}] \times 2)$

Example: If the pulse width is set at 50ms, select 10 pulses/s or less.

Note 2) DO1/DO2 (transistor open collector) and DO3 (relay contact) operate simultaneously.

Before checking the action, confirm whether proceeding to an action is all right or not.

Note 3) DO3 (relay contact) always operates at the rate of 1 pulse/sec regardless of setting.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Description	Display
Key operation		
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 3 times to display "TOTAL PULSE".	TOTAL PULSE 1 PULSE/s
	Press the key once to blink the cursor. Note) Start simulated pulse output.	TOTAL PULSE 001 PULSE/s
	Press the key twice to move the cursor.	TOTAL PULSE 001 PULSE/s
	Press the key for 4 times to set "5".	TOTAL PULSE 005 PULSE/s
	Press the key once to register.	TOTAL PULSE ** COMPLETE **
	----- 5 PULSE/s has been registered. -----	TOTAL PULSE 005 PULSE/s
	5 PULSE/s simulated pulse is output.	TOTAL PULSE 005 PULSE/s
	After checking the output, press the key once to stop simulated pulse output.	TOTAL PULSE 005 PULSE/s
	Press the key once and then press the key once to enter the measurement mode.	0.000 % 0.000 m3/h

4.11.4. How to check the status output

Description

- Check the status output.
 Setting content ON: Close the contact.
 OFF: Open the contact.



- This operation sets DO1, DO2 and DO3 the same contact action.
- Before operation, check whether DO output can be changed or not.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Check the contact action.	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 4 times to display "STATUS".	DO CHECK OFF
	Press the key once to blink the cursor. Note) Contact output is displayed at this time. "OFF" is given at right.	DO CHECK OFF
	Press the key once, and select "ON".	DO CHECK ON
	Press the key once to register "ON".	DO CHECK ** COMPLETE **
	----- "ON" has been registered. -----	DO CHECK ON
	* Check the contact output "ON".	
	Press the key once, and select "OFF".	DO CHECK OFF
	Press the key once to register "OFF".	DO CHECK ** COMPLETE **
	----- "OFF" has been registered. -----	DO CHECK OFF
	* Check the contact output "OFF".	
	Press the key once to stop the cursor from blinking.	DO CHECK OFF
	* It returns to contact output at the normal measurement status.	
	Press the key once and then press the key once to enter the measurement mode.	0.000 % 0.000 m3/h

4.11.5. How to check the DI input

Description

- Check the DI input.
























This is a function for checking the contact status on the LCD display by closing or opening the contact.

Check method ON: Close the contact.

OFF: Open the contact.

Note 1) To check the DI input, the communication board (option) is required.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Check the contact action.	
Key operation	Description	Display
	Press the  key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
		
	Press the  key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
		
	Press the  key for 5 times to display "DI CHECK".	DI CHECK
		
	Press the  key once to blink the cursor.	DI CHECK OFF
		
	Close the contact. * Check the contact input "ON".	DI CHECK ON
		
	Open the contact. * Check the contact input "ON".	DI CHECK OFF
		
	Press the  key once to stop the cursor from blinking.	DI CHECK
	* It returns to contact output at the normal measurement status.	↓
 	Press the  key once and then press the  key once to enter the measurement mode.	0.000 %s 0.000 m3/h

4.11.6. How to validate the test mode (simulated flow rate output)

Description

- Checks different outputs (LCD indication, analog output, DO output) upon simulating flow rate outputs.
With the output at the actuated time as an initial value, the output changes up to the input value (simulated flow rate target value) in a selected TRACKING TIME, and at the input value, the output value becomes constant.
So long as the test mode is valid, "T" blinks on the left end of the 1st line of LCD on the measurement mode screen.


Setting content

- TEST MODE : Validates or invalidates the test mode.
 INPUT DATA : Simulated flow rate target (percentage of MV full scale).
 TRACKING TIME : Time required to attain the simulated flow rate target (above input value).

Settable range

- TEST MODE validation: SETTING (valid), NOT USED (invalid)
 INPUT DATA : ±120%
 TRACKING TIME : 0 to 999 seconds

* For setting TRACKING TIME, 0sec is set to the damping (See 4.9.5).




⚠ CAUTION

- By performing the operation, the output of analog outputs, DO1, DO2, and DO3, varies depending on the setting. Check beforehand whether each output can be changed or not.
- Be sure to resume "NOT USED" after the end of test. Otherwise, the input value output status will be held until power is turned off.
- If "START/RESET" is selected as TOTAL MODE, the total value also changes. Select "STOP" not to make the total value change.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set the simulated flow rate target to 100%, and the tracking time to 100 [s].	
Key operation	Description	Display
△	Press the △ key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
▼		
ENT	Press the ENT key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
▼		
△	Press the △ key for 6 times to display "TEST MODE".	TEST MODE NOT USED
▼		
ENT	Press the ENT key once to blink the cursor.	TEST MODE NOT USED
▼		
△	Press the △ key once, and select "SETTING".	TEST MODE SETTING
▼		
ENT	Press the ENT key once to register "SETTING".	INPUT DATA 0 %
▼		
ENT	Press the ENT key once to blink the cursor on the 2nd line.	INPUT DATA +000 %
▼		
▶ △	Enter "100" by the ▶ and the △ key.	INPUT DATA +100 %
▼		
ENT	Press the ENT key once to register.	INPUT DATA ** COMPLETE **
▼		↓
▼	—— "INPUT DATA" has been registered. ——	INPUT DATA 100 %
▼		
△	Press the △ key once to display "TRACKING TIME".	TRACKING TIME 0 sec
▼		
ENT	Press the ENT key once to blink the cursor on the 2nd line.	TRACKING TIME 000 sec



Press the  key once to set "100".





Press the  key once to register.



----- "TRACKING TIME" has been registered. -----

* Simulating flow rate output is started.



Display the measurement mode by the  key and the  key.

"T" blinks on the left end of 1st line of LCD, and the output changes. In 100 seconds (at which tracking time is set), the output becomes stable at 10 [m³/h] (simulated flow rate target). (In case of full scale 10 [m³/h])

Note) Be sure to return the TEST MODE to "NOT USED" after checking the output.

TRACKING TIME

100 sec

TRACKING TIME

** COMPLETE **



TRACKING TIME

100 s

T 0.00 %

0.000 m3/h



T 100.00 %

10.000 m3/h

4.11.7. How to validate a serial transmission (RS-232C/RS-485)

Description

- Validates a transmission before using the transmission function.

Setting content

Transmission type, transmission rate, parity, stop bits and slave No.

Settable range

Transmission type : RS-232C (factory set) or RS-485.

Transmission rate (BAUD RATE) : 2400 BPS, 4800 BPS, 9600 BPS (factory set) or 19200 BPS.

Parity : NONE, EVEN (factory set), ODD

Stop bits : 1 BIT (factory set), 2 BITS


















Station No. : 1 to 31 (factory set: 1)

Communication protocol : MODBUS RTU mode (factory set) or M-Flow (Fuji Electric's M-Flow [Type: FLR] protocol)

Note) For the transmission specifications, refer to the separate instruction manual "Ultrasonic Flowmeter Communication functions" (INF-TN5A0177).

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Select the RS-485, and set the baud rate to 9600 BPS, the parity to "NONE", the stop bits to "1 BIT", and the slave No. to "5".	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 7 times to display "COMMUNICATION".	COMMUNICATION
	Press the key once to select, and press it once again to blink on the 2nd line.	MODE RS-232C
	Press the key once to display "RS-485".	MODE RS-485
	Press the key once to register.	MODE ** COMPLETE **
	----- RS-485 has been registered. -----	MODE RS-485
	Press the key once to display "BAUD RATE".	BAUD RATE 9600BPS
	Because "9600 BPS" is set, go to the next step.	
	To select other baud rate, press the key, and select by the key, and register by the key.	
	Press the key once to display "PARITY".	PARITY ODD
	Press the key once to blink on the 2nd line.	PARITY ODD
	Press the key once to display "NONE".	PARITY NONE
	Press the key once to register.	PARITY ** COMPLETE **
	----- "NONE" has been registered. -----	PARITY ODD
	Press the key once to display "STOP BIT".	STOP BIT 1 BIT
	Because "1 BIT" is set, go to the next step. To select "2 BITS", press the key, and select by the key, and register by the key.	
	Press the key once to display "STATION No.".	STATION NO. 01

 ▼   ▼  ▼ ▼ ▼ ▼  ▼  	<p>Press the  key once to blink the cursor.</p> <p>Set "5" by the  and the  key.</p> <p>Press the  key once to register.</p> <p style="text-align: center;">----- SLAVE No. has been registered. -----</p> <p>Press the  key once to display "PROTOCOL". Because "MODBUS" is set, setting is completed.</p> <p>To select other protocol, press the  key, and select a protocol by the  key, and register it by the  key.</p> <p>Display the measurement mode by the  key and the  key.</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">SLAVE NO.-----</td> <td style="text-align: right; padding: 2px;">01</td> </tr> <tr> <td style="padding: 2px;">SLAVE NO.-----</td> <td style="text-align: right; padding: 2px;">05</td> </tr> <tr> <td style="padding: 2px;">SLAVE NO.-----</td> <td style="text-align: center; padding: 2px;">** COMPLETE **</td> </tr> <tr> <td colspan="2" style="text-align: center; padding: 2px;">↓</td> </tr> <tr> <td style="padding: 2px;">SLAVE NO.-----</td> <td style="text-align: right; padding: 2px;">05</td> </tr> <tr> <td style="padding: 2px;">PROTOCOL-----</td> <td style="text-align: right; padding: 2px;">MODBUS</td> </tr> <tr> <td colspan="2" style="padding: 2px;"> </td> </tr> <tr> <td style="padding: 2px;">-----</td> <td style="padding: 2px;">0.000 m/s</td> </tr> <tr> <td style="padding: 2px;">-----</td> <td style="padding: 2px;">0.000 m3/h</td> </tr> </table>	SLAVE NO.-----	01	SLAVE NO.-----	05	SLAVE NO.-----	** COMPLETE **	↓		SLAVE NO.-----	05	PROTOCOL-----	MODBUS			-----	0.000 m/s	-----	0.000 m3/h
SLAVE NO.-----	01																			
SLAVE NO.-----	05																			
SLAVE NO.-----	** COMPLETE **																			
↓																				
SLAVE NO.-----	05																			
PROTOCOL-----	MODBUS																			
-----	0.000 m/s																			
-----	0.000 m3/h																			

4.11.8. How to set the ID No.

Description

- Set the ID No. for protection of parameters (Section 4.4.1).
If ID No. is set, the number must be inputted before canceling the parameter protection.
- To validate the parameter protection, set the parameter protection to "ON". (See Section 4.4.1.)

ID No. settable range: 0000 to 9999 (4-digit number)

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Set "1106" as the ID No.	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 9 times to display "REGISTER ID NO.".	REGISTER ID NO.
	Press the key twice to blink on the 2nd line.	REGISTER ID NO. 0000
	Set "1106" by the and the key.	REGISTER ID NO. 1106
	Press the key once to register.	REGISTER ID NO. ** COMPLETE **
	Display the measurement mode by the key and the key. Note) To validate the parameter protection, set the parameter protection to "PROTECT ON". (See Section 4.4.1.)	REGISTER ID NO. **** 0.000 % 0.000 m3/h

4.11.9. How to confirm the software version

Description

- Indicates the software version.

For concrete keying, refer to the typical operation indicated below.

Operation (example)	Check the software version.	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 10 times to display "VER. NO.".	* VER. NO. FSV1SYS00A 01
	After checking, display the measurement mode by the key or the key.	0.000 % 0.000 m3/h

* The indicated version number is display example.

4.11.10. Initializing setting parameters

Description

- Initializes the setting parameters saved in the memory.
- Initializes those other than the zero adjusted values or analog output calibration value.

Initialize code: 0100 (4-digit number)

<Note> When the parameter is initialized, display language is set to English.
To switch the display language, refer to "4.5. Display language".



- This parameter is intended for our service personnel.
- Do not attempt to initialize the setting parameters. Otherwise measurement is disabled.

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

Operation (example)	Initializes the setting parameters.	
Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 11 times to display "MEMORY INITIAL".	MEMORY INITIAL
	Press the key twice to blink on the 2nd line.	MEMORY INITIAL 0000
	Set "0100" by the and the key.	MEMORY INITIAL 0100
	Press the key once to register.	MEMORY INITIAL ** COMPLETE **
	— Flow transmitter is reset, and the measurement mode is displayed. —	↓ 0.000 m/s 0.000 m3/h

4.11.11. How to set the detailed setting

Description

- The data required for time difference measurement can be set as follows.



CAUTION

- This parameter is intended for our service personnel.
- Do not change the setting by yourself. Otherwise measurement may be disabled.
- Make the detailed setting only when a problem should arise in flow rate measurement with factory default settings. The setting need not be made in other cases.


Setting items

Item	Input method	Function, range or menu
Transmission count	Select	The number of transmission of ultrasonic signals per flow rate signal output ^{*1} . (Factory-set value: 128) When standard mode is selected for the operation mode: <ul style="list-style-type: none"> 8, 16, 32, 64, 128, 256 When high speed response mode is selected for the operation mode: <ul style="list-style-type: none"> 4, 8, 16, 32, 64, 128
Trigger control	Select Numeric value	Control method setting of the trigger level (detection point) of ultrasonic signals. (Factory-set value: AUTO) <ul style="list-style-type: none"> AUTO MANUAL Select the detection point according to the rate against the peak of receiving wave regarded as 100%. <ul style="list-style-type: none"> Trigger level: 10% to 90%.
Window control	Select Numeric value Numeric value	Setting of control method of measurement window that takes in signals (Factory-set value: AUTO) <ul style="list-style-type: none"> AUTO MANUAL Set the time of starting taking in signals (period from the start of transmission until the startup of window signals) <ul style="list-style-type: none"> U: open time: 1μs to 16383μs D: open time: 1μs to 16383μs Note) U: forward direction, D: reverse direction In case of MANUAL, set U and D.
Saturation (level)	Numeric value	The number of times that the amplitude of received signals fluctuates and exceeds ±1.0V (saturation) per 1 flow rate signal output ^{*1} . Used as the threshold value for judging the error status of signals. A signal error occurs if the specified number of times is exceeded. (Factory-set value: 128) <ul style="list-style-type: none"> 0 to 256
Measurement method	Select	Setting of measurement method for measuring transit time. (Factory-set value: method 2) <ul style="list-style-type: none"> Method 1: Strong against interference Method 2: Controls triggers on the plus side of the direction of voltage of received signals. Method 3: Controls triggers on the minus side of the direction of voltage of received signals.
Signal balance	Numeric value	Setting of threshold value used for judging the existence of transit time. A signal error occurs if the specified value is exceeded. (Factory-set value: 25%) <ul style="list-style-type: none"> 0% to 100% Note) Set to 50% or higher for Method 1.
Transmission pattern	Select	Setting of transmission pattern of ultrasonic signals (Factory-set value: BURST 3) <ul style="list-style-type: none"> Select from BURST 1, BURST 2, BURST 3, BURST 4, BURST 5, CHIRP 4 and CHIRP 8.
AGC gain	Select Numeric value Numeric value	Setting of control method of signal AGC gain (Factory-set value: AUTO) Signal peak is controlled to be kept at 1.5V _{pp} . <ul style="list-style-type: none"> AUTO MANUAL Make the setting so that the signal peak in both forward and reverse directions is kept at 1.5V _{pp} . <ul style="list-style-type: none"> Forward gain: 1.00% to 99.00% Reverse gain: 1.00% to 99.00%
Signal peak	Select	Setting of signal peak threshold value per 1 flow rate signal output ^{*1} . Used as the threshold value for judging the error status of signals. A signal error occurs if the value becomes lower than the specified value. (Factory-set value: 3072) <ul style="list-style-type: none"> 0.5V(4096) : Equivalent to 0.5V_{OP} 0.375V(3072) : Equivalent to 0.375V_{OP} 0.25V(2048) : Equivalent to 0.25V_{OP} 0.125V(1024) : Equivalent to 0.125V_{OP}
Transmission wait time	Numeric value	Transmission interval of ultrasonic signals. (Factory-set value: 5msec) <ul style="list-style-type: none"> 1msec to 30msec

For concrete keying, refer to the typical operation indicated below. Set the parameter protection to OFF beforehand. (See Section 4.4.1.)

*1) Forward-direction signals are taken in with forward total time measurement, while reverse-direction signals are taken in with reverse total time measurement. They are conducted alternately for the transmission count. Forward and reverse signal data is added for the transmission count and averaged. The result is 1 output of signal in forward/reverse direction.

[Outline drawing of signal processing]




Note) Make the setting, following the description in "6.6.6. Checking received waveforms".

Operation (example)	Set measurement method to "METHOD 1".	
Key operation	Description	Display
△	Press the △ key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
ENT	Press the ENT key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
△	Press the △ key for 14 times to display "DETAILS".	DETAILS
ENT	Press the ENT key once to display "TRANS.COUNT".	TRANS.COUNT 128
△	Press the △ key for 4 times to display "MEAS.METHOD".	MEAS.METHOD METHOD:2
ENT	Press the ENT key once to select, and press it once again to blink on the 2nd line.	MEAS.METHOD METHOD:2
△	Press the △ key twice to display "METHOD 1".	MEAS.METHOD METHOD:1
ENT	Press the ENT key once to register.	MEAS.METHOD ** COMPLETE **
↓	----- "METHOD 1" has been registered. -----	MEAS.METHOD METHOD:1
ESC △	Press the ESC key twice and then press the △ key once to enter the measurement mode.	0.000 m/s 0.000 m3/h

5. Mounting of detector

5.1. Detector mounting procedure

Mount the sensor on the pipe, and perform the following works in order before making measurement.










5.1.1. Mounting of detector

For sensor spacing, select either of method in advance.

- Calculate from flow transmitter
Turn ON the flow transmitter.
Enter the piping information, etc described in the Section 4.6.2, and display it.
Display example: PROCESS SETTING S=16 (48mm)
During wiring work, be sure to turn the power off.
- Calculate from our website.
Address <http://www.fic-net.jp/eng/products/flowmeter/top.html>
- Calculate from the CD attached to the equipment.

5.1.2. Image figure of mounting dimension

Type	FLSS12, 22	FLW11, 12, 41	
Mounting method	V method	V method	
Mounting dimension			
Type	FLW50, 51	FLD22, 32	
Mounting method	V method	V method	
Mounting dimension			
Type	FLW41	FLW50, 51	FLD32
Mounting method	Z method	Z method	Z method
Mounting dimension			

5.2. Selection of mounting position

Detector mounting location, i.e., the conditions of the pipe subjected to flow rate measurement exert a great influence on measurement accuracy. So select a location meeting the conditions listed below.

- (1) Straight piping greater than 10D must exist on the upstream side and greater than 5D on the downstream side.
- (2) Elements (pump, valve, etc) on the upstream side must be greater than 30D away to prevent disturbances.
- (3) The piping must be filled with fluid free from air bubbles and foreign objects.
- (4) Make sure that a maintenance space is provided around the piping where the sensor is mounted. (See Fig. 5-1.)

Note) A space should be provided so that maintenance work can be made with workers standing on both sides of the piping.






Fig. 5-1 Necessary space for the detector mounting position



- (1) Mount the detector within $\pm 45^\circ$ from the center plane in the case of horizontal pipe run.
For a vertical pipe, the detector can be mounted at any position on the outer circumference.



- (2) Avoid installing the sensor on a deformed portion of pipe or welded portion of pipe, or on flange.



5.3. Selection of mounting method

There are 2 methods for mounting the detector; V method and Z method. (See Fig. 5-2.)




Fig. 5-2 Mounting method

The Z method should be used in the following cases.

- Where a mounting space is not available. (As shown in the figure above, the mounting dimension with the Z method is about half of that with the V method).
- When measuring fluid of high turbidity such as sewage.
- When the pipe has a mortar lining.
- Piping is old and presumed to have a deposit of a thick layer of scales inside the piping.

Selection standard

The Z method for large size sensor is recommended for outer diameter 300mm or more.



Type	Standard	Submersible	High temp.	Mounting method																		
					13	25	50	100	200	250	300	400	1000	3000	6000							
FLSS12 FLSS22	○	×	×	V V V	25	P		100	50	M		100	50	P, M		225						
FLW12 FLW11	○	○	×	V	50	Px, P, M		300														
FLW41	○	○	×	V	200	Px, P, M		600														
				Z	200	Px, P, M		1200														
FLW51 FLW50	○	○	×	V	200	Px, P, M		3000														
				Z	200	Px, P, M		6000														
FLD22	○	×	×	V	13	Px, P, M		100														
FLD32	○	×	○	V	50	Px, P, M		250														
				Z	150	Px, P, M		400														

Piping material type {
Px : PP, PVDF
P : Plastic (PVC, others)
M : Metal piping (Carbon steal, copper, aluminum, etc.)

5.4. Processing of mounting surface

Using thinner and sand-paper, remove the pitches, rust and uneven surface of the detector mounting piping over the entire mounting area of $(L) + 200\text{mm}$ wide. (Fig. 5-3)

Note) When the piping exterior is wrapped with jute, remove the jute and then perform the above treatment.



Length of frame

Type	L
FLSS1	228mm
FLSS2	348mm
FLW1	510mm
FLD2	320mm
FLD3	530mm


Fig. 5-3

5.5. How to determine the mounting position


When the mounting is Z method, or the sensor is large, carry out the following to determine the mounting position beforehand.

Gauge paper is necessary for this work. (Refer to "7.4. How to make gauge paper".)


- (1) Match the edge of gauge paper with the line at about 100mm from one end of the pipe portion treated for detector mounting, and wind the gauge paper so that the line marked on the paper is parallel with the pipe axis (fix with tape not to allow deviation). At this time, the edge of gauge paper should be aligned.



- (2) Extending the line marked on the gauge paper, mark straight line A on the pipe.




- (3) Mark a line along on edge of the gauge paper. Assume the intersection of the line and the straight line A is A_0 .



V method


Z method

Example) When $L = 200\text{mm}$




- (4) Remove the gauge paper and measure the mounting dimension from A_0 . Then, draw a line which crosses the straight line A (determine the position A_2).

A_0 and A_2 become the mounting positions.



- (4) Measure the circumference of the pipe from the point A_0 , and mark a line (straight line B) between the point B_0 and B_1 obtained at 1/2 of the circumference.

Example) When $L = 100\text{mm}$




- (5) Mark the points B_0 and peel off the gauge paper. Measure the mounting dimension from B_0 to determine B_2 position. At this position, make a line orthogonal to the straight line B.

A_0 and B_2 become the mounting positions.

5.6. Selection of acoustic coupler

Acoustic coupler is a media that eliminates a gap between the detector and the pipe.



There are 4 types of acoustic coupler. Select a suitable one using the following table for reference.


Type	Silicon compound (KE-348W)	Silicon-free grease (HIGH Z)	Silicon grease (G40M)	High temperature grease (KS62M)
Fluid temperature	-40 to +100°C	0 to +60°C	-40 to +100°C	-30 to +250°C
Teflon tube	×	○	○	○

5.7. Cable end treatment

5.7.1. Cable end treatment for FLS, FLD

The end of coaxial cable is treated at the factory prior to delivery.

If the cable needs to be cut before use, the conductor and the shielding wires should be treated using clamp terminals.






Note) When cutting the coaxial cable, make sure that the upstream side and the downstream side are the same in length.

5.7.2. Cable end treatment for FLW

The end of coaxial cable is treated at the factory prior to delivery.

If the cable needs to be cut before use, the conductor, the shielding wires, and the external shielding wire should be treated using clamp terminals.

Clamp terminal	Kind of clamp terminal		
	Name	Flow transmitter side (for M3 screw)	Detector side (for M4 screw)
	External shielding wire (green)	R2-3L	R2-4
	Conductor (White, +)	R1.25-3	R1.25-4
	Shielding wire (Black, G)	R1.25-3	R1.25-4

Note) When cutting the coaxial cable, make sure that the upstream side and the downstream side are the same in length.

5.8. Mounting small-diameter and small size detector (FLSS12, FLSS22)

5.8.1. Frame mounting method



CAUTION

Be careful not to cut your hand with the stainless steel belt when mounting the frame.

- (1) Pass the stainless steel belt through 2 belt holes on the frame as shown in Fig. 5-4.



Fig. 5-4

- (2) As shown in Fig. 5-5, apply the frame on the pipe section subjected to a surface treatment.



Fig. 5-5

- (3) Turn the stainless steel belt around the pipe as shown in Fig. 5-6, and insert the lever.



Fig. 5-6

- (4) Adjust the frame so as to be in parallel with the pipe, and check whether the frame is securely tightened while pulling down the lever. Adjust the frame at the bending position A.




Fig. 5-7

- (5) When the stainless steel belt is long, cut it as shown in Fig. 5-8.



Fig. 5-8

- (6) Fit the lever window securely on the dowel. When the frame is not securely tightened, move the lever upward using blade-edge screwdriver, etc, and readjust the frame at the bending position in (4).



Fig. 5-9

Note) The stainless steel belt can be used repeatedly.

5.8.2. Mounting of sensor unit

- (1) Mount both sensor units spaced at the SPACING value [S= **] (number of graduations on frame) indicated after setting the piping parameters.




Fig. 5-10

- (2) Before mounting the sensor unit into the frame, sufficiently apply silicone filler (or silicone-free grease*) over the entire transmission surface of the sensor unit, taking care not to introduce bubbles. (Fig. 5-11)

*) When using silicon-free grease, pay attention to the fluid temperature range. The fluid temperature range is shown below.

- Silicon compound : -40 to +100°C
- Silicon-free grease : 0 to +60°C

When using silicon-free grease, reapply it on the transmission surface of the sensor unit approximately once every 6 months. (Silicon rubber need not be reapplied.)

- (3) Then insert the sensor unit into the frame, align the slit provided on the pressing fixture of the sensor unit with graduations located on the frame top surface (see Fig. 5-12), and press the sensor unit until the fixture claws are engaged with the frame side square holes. Mount both sensor units so as to be roughly symmetrical with respect to the frame. (Refer to Fig. 5-13)




Fig. 5-11




Fig. 5-12




Fig. 5-13

CAUTION

Mount the sensor units so that their BNC connectors will face outward (Fig. 5-14a). If at least one is mounted opposite, the measurement is impossible (Fig. 5-14b, c). The pressing fixture claws must completely be engaged with square holes provided on sides of the frame. Otherwise, the sensor and pipe will not correctly get in contact with each other, whereby the measurement will be impossible.




Fig. 5-14a



Do not mount the BNC connectors of sensor units in the same direction.

Fig. 5-14b



Do not mount the BNC connectors of sensor units so as to face inward.

Fig. 5-14c

Fig. 5-14

- (4) Engage the signal line with BNC connectors of the sensor units. At this time, do not mistake the upstream and downstream sides for each other. Engage the red BNC connector upstream, and the black BNC connector downstream (see Fig. 5-15).




Fig. 5-15

5.9. Mounting small-diameter and medium size sensor (FLW11, FLW12, FLW41)

5.9.1. Connection of sensor cable



CAUTION

When engaging or disengaging the cover, be sure to wear protective gloves. Otherwise, you may cut a hand.

- (1) Loosen the retaining knobs on the detector using a screwdriver, then remove the cover from the detector.




Fig. 5-16

- (2) Mount the sensors so that the upstream and downstream sensors can be distinguished with each other. Remove the cable clamp.

Note) In case of removing the cable clamp, be sure not to lose the nut.




Fig. 5-17

- (3) Insert the coaxial cable through the cable lead-in port and loosen the terminal screws (G, +).
Note) Connect to the M4 crimp terminal side (Flow transmitter side: M3)




Fig. 5-18

- (4) Connect the cable to the terminal (black to G terminal, red to + terminal).




Fig. 5-19

- (5) Secure the coaxial cable with the cable clamp.




Fig. 5-20

- (6) Remove foreign matters from the terminals, and mold them while terminal block with silicone filler.
 ● Cut off the tip of the silicone filler tube.
 Apply silicone to the terminal block while pressing the head of the tube against the bottom of terminals.
 At this time, care should be taken to prevent entry of air bubbles.




Fig. 5-21

- (7) Put the cover on the detector.





Fig. 5-22

5.9.2. Assembling procedure of the sensor


When the small type sensor (FLW1) is shipped with cables of more than 10m in length, it is delivered, disassembled since cable weight is applied to the stand or piping of the sensor during shipment. Follow the procedure given below.

- (1) Be sure to read the “Cautions” before assembling the parts.
Insert the frame end onto one side of 2 pipes.




After inserting the pipes, tap the frame end with a plastic hammer or the like.

- (2) Loosen the retaining knob on the sensor and insert the pipes.




Insert it in the correct direction.

- (3) Insert another sensor onto the pipes.
Insert it in the correct direction.



- (4) Insert the frame end onto the other side of pipes.
Assembling method is the same as (1).



Note) After assembling the sensor, leave it at room temperature for a day to harden the filler (to obtain the required assembling strength).

5.9.3. Mounting method on the pipe

The small type detector is mounted on pipe with a diameter of $\Phi 50$ to 300 (V method) or $\Phi 200$ to 600 (Z method) for measurements.

5.9.3.1. In case of V method

Mounting the detector using the following procedure.
For mounting, prepare a scale or a slide calipers.

- (1) Loosen the retaining knob A (4 places), slide the detector so as to match the mounting dimension, place a scale on the mounting dimension reference surface C and adjust the dimension, then tighten the retaining knob A.




Fig. 5-23

- (2) Spread silicone filler over the whole transmitting side of the detector. Care should be taken to prevent entry of air bubbles. Clean the surface of the pipe and mount the detector.




Fig. 5-24

- (3) Raise the end of the pipe fitted with the detector, and attach the yellow ring on the chain to the hook.




Fig. 5-25

- (4) Attach the other chain to the other hook of detector, and secure it loosely.




Fig. 5-26

- (5) Pull the red ring and attach it to the hook. Use the same procedure for the other sensor.



Fig. 5-27

- (6) Turn over the frame end so that the sensor makes a close contact with the pipe.




Fig. 5-28

- (7) Press the sensor firmly against the pipe. Ensure that the sensor makes a close contact with the pipe.

5.9.3.2. In case of Z method

Mounting the detector using the following procedure.

- (1) Provide wire rope for the upstream and the downstream detectors.
Make sure that the length of the wire rope is longer than the circumference of the pipe.




Fig. 5-29

- (2) Lay the wire rope around the pipe at the position of the upstream detector. Then hook the mounting spring into the wire rope.



Fig. 5-30

- (3) Spread silicone filler over the whole transmitting side of the detector. Care should be taken to prevent entry of air bubbles.



Fig. 5-31

- (4) Clean the surface of the pipe and mount the detector.




Fig. 5-32

- (5) Press the detector against the pipe. Align the center of the detector with the intersection of the marking line, and the mounting dimension reference surface with the marking line.




Fig. 5-33

- (6) Make sure that the center mark on the detector is aligned with the marking line. Then, connect the coaxial cable to the transmitter.

Note) Do not pull the coaxial cable.
If it is pulled, the detector is shifted which results in incorrect measurements due to poor contact with the pipe.




Fig. 5-34

- (7) After mounting the upstream sensor, mount the downstream sensor in the same mounting dimensions.




Fig. 5-35


5.10. Mounting large size detector (FLW50, FLW51)

5.10.1. Connection of sensor cable


CAUTION

When engaging or disengaging the cover, be sure to wear protective gloves. Otherwise, you may cut a hand.


- (1) Slightly move the sensor cover and remove it using an screwdriver or the like.




- (2) Confirm the mounting position on the pipe
- Align the transmitting direction marks so that they are facing with each other.



- (3) Connect the coaxial cable to the terminals (G, +) and secure the cable with the cable clamp.
- Note) Connect to the M4 crimp terminal side.
(Flow transmitter side: M3)




- (4) Remove foreign matters from the terminals, and mold them while terminal block with silicone filler.
- Cut off the tip of the silicone filler tube. Apply silicone to the terminal block while pressing the head of the tube against the bottom of terminals. At this time, care should be taken to prevent entry of air bubbles. Put the cover on the sensor.




5.10.2. Mounting method on the pipe

- (1) Adjustment of guide plate height
Attach the sensor to the pipe. Make sure that it is parallel with the pipe shaft.




Loosen the guide plate retaining screw, and slide the plate until its edge and the transmitting side are in contact with the pipe surface.
Tighten the retaining screw.

- (2) Setting of wire rope length
Place the sensor on the marked lines and fit the wire rope and fastening spring.




Loosen the wire clip, stretch the wire rope until the overall length of the mounting spring becomes 180mm, and secure the wire clip (free length of the mounting spring is 110mm).
Remove the sensor with the wire rope fixed in place.


- (3) Mounting of sensor
- Clean the sensor transmitting surface and pipe mounting surface.
 - Spread silicone filler over the whole transmitting surface of the sensor.
 - The thickness of silicone filler should be about 3mm.



- Spread the wire rope near the marked lines in the left-right direction, bring the sensor in close contact and fit the wire rope.



- Make sure that the matching mark on the sensor is aligned with the marking line. Also, make sure the transmitting direction marks on the sensor are facing with each other.




- Make sure that the center mark on the detector is aligned with the marking line. Then, connect the coaxial cable to the transmitter.


Note) Do not pull the coaxial cable. If it is pulled, the detector is shifted which results in incorrect measurements due to poor contact with the pipe.

5.11. Mounting small diameter detector (FLD22)

- (1) Loosen the lock nut and slide the sensor so as to meet the mounting dimension (the first decimal place at the displayed mounting dimension is rounded) and then tighten the nut.




- (2) Apply the silicone grease on the transmitting surface of sensor while spreading it evenly.




Turn the element holder counterclockwise to return the sensor.
Clean the surface of the pipe and mount the sensor on the pipe.

- (3) Mount the sensor saddles on the pipe with stainless belt.
Wrap the stainless belt around the pipe previously for easy mounting.



- (4) Make sure that the sensor is mounted in parallel with the piping and that the mounting position is correct. Then, turn the element holder clockwise until the sensor is firmly fitted to the piping.



Stop turning the element holder where the transmitting surface contact the surface of pipe, and thus the element holder will not rotate. Do not turn it excessively.

5.12. Mounting high temperature detector (FLD32)

The high temperature sensor is mounted on pipe with a diameter of $\Phi 50$ to 250 (V method) or $\Phi 150$ to 400 (Z method) for measurements.


5.12.1. Mounting of detector (in case of V method)

Mounting the detector using the following procedure.


CAUTION

Do not perform mounting when the temperature of pipe is high. Otherwise, you may suffer a burn.

- (1) By loosening lock nuts, slide the sensor to fit the mounting size displayed on the converter. Tighten the lock nuts.




- (2) Spread high-temperature grease over the whole transmitting surface of the sensor.




Turn the element holder counterclockwise to return the sensor.
Clean the surface of the pipe and mount the sensor on the pipe.

- (3) Mount the sensor saddles on the pipe with stainless steel belt.



- (4) Make sure that the sensor is mounted in parallel with the piping and that the mounting position is correct. Then, turn the element holder clockwise until the sensor is firmly fitted to the piping.




Stop turning the element holder where the transmitting surface contact the surface of pipe, and thus the element holder will not rotate. Do not turn it excessively.


5.12.2. Mounting of detector (in case of Z method)

Mounting the detector using the following procedure.


- (1) Remove saddle setscrews at 4 locations, and remove a saddle and a sensor unit out of the frame. Also, remove a saddle on the guide rail for high temperature sensor (option).



- (2) Mount the removed sensor unit on the guide rail for high temperature sensor. Fasten the sensor unit with mounting dimension (L).




- (3) Spread high-temperature grease over the whole transmitting surface of the sensor.




Turn the element holder counterclockwise to return the sensor. After cleaning the surface of the pipe, the sensor should be mounted.

- (4) Mount each sensor individually on the marking line.



- (5) Make sure that the sensor is mounted in parallel with the piping and that the mounting position is correct. Then, turn the element holder clockwise until the sensor is firmly fitted to the piping. Stop turning the element holder where the transmitting surface contact the surface of pipe, and thus the element holder will not rotate. Do not turn it excessively.



6. CHECK AND MAINTENANCE

6.1. Daily Check

Visually check the following items.

- Whether flow transmitter cover screws are loose. ⇒ Tighten.
- Whether cable glands are loose. ⇒ Tighten.
- Whether detector mounting band is loose. ⇒ Stretch.
- Whether received wave is abnormal (LED lit red). ⇒ Check whether piping is filled or not. Remove bubbles or foreign matters, if mixed in measurement pipe. Also check if detector mounting and wiring are normal.

6.2. Periodic Inspection

6.2.1. Checking zero point

Stop the fluid flow, fill the measurement pipe fully, and check the zero point.

6.2.2. Reapplying grease

When using grease for the acoustic coupler, reapply it on the transmission surface of the sensor unit approximately once every 6 months.

Note) Silicon rubber need not be reapplied.

6.2.3. How to measure the insulation resistance

CAUTION

Turn off power before opening the flow transmitter cover.


The power terminals (N,L) and the output terminals (Iout, DO1, DO2, DO3) are provided with an arrester as standard.

To measure the insulation resistance between the power terminal and the grounding terminal, and between each output terminal and the grounding terminal, remove the earth plate of the power terminal block and the ground wire of the output terminal as shown by the following figure.

If the communication board (option) is provided, remove it before measuring.

The insulation resistance performance of the equipment is 100 M Ω /500 V DC.

Be sure to return the earth plates and ground wire in position after the measurement is completed.



6.3. How to replace the fuse


CAUTION

- Be sure to turn off the power before replacing the fuse.

Fuse specifications

- (1) AC power supply (100V and 200V): 5.2mm (diameter) × 20mm (long), 250V, 0.5A.
As represented by Fuji Terminal Industry Co., Ltd. FGMB: 250V, 0.5A.
- (2) DC power supply: 5.2mm (diameter) × 20mm (long), 250V, 1A.
As represented by Fuji Terminal Industry Co., Ltd. FGMB: 250V, 1A.

- (1) Opening the cover after turning off power.
Loosen 4 screws from the flow transmitter front, and open the cover.
- (2) Replace the fuse.
Detach the fuse holder from the power supply board, and replace the fuse. Then, return the fuse holder in place.
- (3) Closing the cover.
Close the cover, and tighten 4 screws.



CAUTION

- Turn on power only after closing the cover.

6.4. How to replace the relay

DO3 is a relay contact, whose service life is 200,000 times (under rated load).
Replace it before the end of its life estimating the number of contact operations.
Card relay type: RB104-DY (made by Fuji Electric)

[How to replace]


- (1) Opening the cover after turning off power.
- (2) As shown by the following photo, pull out the card relay from socket.
- (3) Set a new card relay into the socket. Push it enough to engage the card relay claws.
- (4) Close the cover and turn on the power.
- (5) Set the maintenance mode to "STATUS OUTPUT", and check the relay "ON" and "OFF" actions.



CAUTION

- Be sure to turn off the cover before opening the cover. A high voltage is inside.

Relay removing procedures




Relay contact

Push up the card relay bottom.



Push the card relay top from socket.



Pull out the card relay from socket.

6.5. How to replace the LCD

The nominal service life of the LCD is 7 years. The contrast gradually deteriorates with time. Replace it about 5 years after starting its use.


[How to replace]

- (1) Opening the cover after turning OFF power.
- (2) Remove the flat cable connector.
- (3) Loosen 6 screws from the LCD unit.
- (4) Mount a new LCD unit (see parts list), inserting the operation keys and LED properly into the cover holes so as not to be pushed nor pinched by the cover.
- (5) Engage the flat cable connector. (Insert it securely all the way.)
- (6) Close the cover and turn on the power.
- (7) Check that the LCD display and key operation are normal.








CAUTION

- Be sure to turn off the cover before opening the cover. A high voltage is inside.




























6.6. ERROR AND REMEDY

6.6.1. Display error

State	Probable cause
 Nothing is displayed.	<ul style="list-style-type: none"> ● Power supply is not turned on. ● Lower power supply voltage ● Fuse is blown out. ● LCD error ⇒ Refer to "6.6.7. Remediating a hardware fault". ● Reverse polarity of DC power supply
 Upper side appears black.	<ul style="list-style-type: none"> ● Lower power supply voltage ● Reverse polarity of DC power supply ● LCD error ⇒ Refer to "6.6.7. Remediating a hardware fault".
 Irrational display	<ul style="list-style-type: none"> ● Hardware error ⇒ Refer to "6.6.7. Remediating a hardware fault".
 Pale display	<ul style="list-style-type: none"> ● Ambient temperature is low (-20°C or lower) ⇒ Increase temperature. ● LCD has reached the end of its service life. ⇒ Replace the LCD.
 Entire display is blackish.	<ul style="list-style-type: none"> ● Ambient temperature is high (50°C or higher) ⇒ Decrease temperature.
LCD characters are skipped. LED does not come on	<ul style="list-style-type: none"> ● Refer to "6.6.1.1. Checking the LCD/LED" for LCD/LED. The dots on the LCD are missing or the LED does not come on. ⇒ Refer to "6.6.7. Remediating a hardware fault".
LED is displayed in red.	<ul style="list-style-type: none"> ● Received wave is abnormal. ⇒ Refer to "6.6.1.2. Checking the LED lit in red".


6.6.1.1. Checking the LCD/LED

Follow the procedure shown below to check possible display errors.

Key operation	Description	Display
	Press the  key for 4 times to display "MAINTENANCE MODE".	
		
	Press the  key once to display "RAS INFORMATION".	
		
	Press the  key for 12 times to display "LCD/LED CHECK".	
		
	Press the  key once.	
		
	Every time the  key is pressed, the display is switched in the order shown below.	
		
	LCD: OFF completely LED: Lit in green LCD: Darkened LED: Lit in red If dots on the LCD are missing or the LED does not come on, the LCD/LED may have failed.	
 	Obtain a measurement-mode display using the  and the  keys.	

6.6.1.2. Checking the LED lit in red

Check the LED lit in red, following the procedure shown below.




6.6.1.3. Checking the RAS information

When the red LED lights up, check the error contents according to the RAS information.

Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
 	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000

If the display is abnormal, 1 is set.
Move the cursor to 1 by the key,
and press the key to display the
status contents. Pressing the
key again displays the troubleshooting.

Configuration of the RAS information



RAS information	Status	Troubleshooting
E1: Device error 1	Backup memory failure	See "6.6.7. Remediating a hardware fault".
E1: Device error 2	Abnormality of measuring circuit	Turn the power off then on again. If the instrument does not recover properly, refer to "6.6.7. Remediating a hardware fault".
E2: Data collection error	Ultrasonic send/receive signals cannot be collected.	
E2: Window scanning	The ultrasonic receiving signal waveform is being detected.	Move the mounting position of the detector, and remount the detector.
E2: No received signal	No ultrasonic receiving signal waveform	Repair or replace the signal cable. Transmitter circuit failure or detector failure ⇒ See "6.6.7. Remediating a hardware fault".
E2: Received signal error	The status of received waveform is poor.	Check the air bubbles or foreign objects. Check the receive sensitivity. ⇒ Move the mounting position of the detector, and remount the detector.
E2: Received signal range over	Receiving signal waveform is outside the appropriate range.	Check the piping data. Check the detector mounting dimensions.
E2: Calculation failure	The value of detected measurement data is abnormal.	Check the piping data. Check the receive sensitivity. ⇒ Move the mounting position of the detector, and remount the detector.
E4: Range over	Analog output and total output exceed the range.	Check the range data and the totalize setting.

6.6.2. Displaying the data in maintenance mode

Follow the procedure shown below to check possible display errors.

Key operation	Description	Display
	Press the key for 4 times to display "MAINTENANCE MODE".	MAINTENANCE MODE
	Press the key once to display "RAS INFORMATION".	RAS INFORMATION 0000000000000000
	Press the key for 13 times to display "DATA DISPLAY".	DATA DISPLAY
	Press the key.	T0 C: 89 usec WinC: 80 usec
	<ul style="list-style-type: none"> Displays the transit time and the window value calculated from the piping setting. 	
	Press the key once.	T1: 0.000 usec T2: 0.000 usec
	<ul style="list-style-type: none"> Displays the measurement value of transit time, T1 (forward time), and T2 (reverse time) from the piping setting. 	
	Press the key once.	T0: 0.000 usec DT: 0.00 nsec
	<ul style="list-style-type: none"> Displays the measurement value of average transit time, T0, and transit time difference, DT. 	
	Press the key once.	Ta: 0.0000 usec θf: 0.000°
	<ul style="list-style-type: none"> Displays the calculated value of pass time of the substances other than fluid, Ta, and angle of incidence of the fluid, θ. 	
	Press the key once.	Cf: 0.0 m/s Re: 0
	<ul style="list-style-type: none"> Displays the calculation value of sound velocity in fluid, Cf, and Reynolds number, Re. 	
	Press the key once.	K: 1.3333 V: 0.000 m/s
	<ul style="list-style-type: none"> Displays correction coefficient of flow velocity distribution, K, and flow velocity, V. 	
	Press the key once.	AGC U: 0.00 % AGC D: 0.00 %
	<ul style="list-style-type: none"> Displays the intensity of received signals. The larger the value, the larger the intensity of received signals. Normal measurement values fall in 35% or more. If the display appears as 0%, no signals are being received. Ultrasonic waves may not be transmitted because of insufficient water volume or rust of piping. 	
	Press the key once.	P/H U: 6143 P/H D: 6143
	<ul style="list-style-type: none"> Displays the peak value of received signal waveform. Normal values stably fall within the range from 5528 to 6758. If the value fluctuates significantly, objects that constitute barriers against ultrasonic wave transmission such as air bubbles or foreign matter may be contained in the fluid. Stop the flow and check if normal value is resumed. If so, there is a possibility that air bubbles are contained. 	
	Press the key once.	TRG U: 25.00% TRG D: 25.00%
	<ul style="list-style-type: none"> Displays the detection level value of received signal waveform. 	
	Press the key or the key to display the measurement mode.	

6.6.3. Keying is abnormal

Status	Probable cause
No response is made to key input.	● Hard failure ⇒ Refer to "6.6.7. Remediating a hardware fault" .
Certain key is not responded. Action is not as defined.	

6.6.4. Error in measured value

Status	Probable cause	Troubleshooting
The reading appears with “-” (minus).	<ul style="list-style-type: none"> ● Connection between main unit and sensor units (upstream, downstream) are inverted. 	<p>→ Connect properly.</p>
Measured value fluctuates though flow rate is constant.	<ul style="list-style-type: none"> ● Straight pipe length is inadequate. ● Pump, valve or others which disturb the flow are located nearby. ● Pulsation exists actually. 	<p>→ Move the sensor to the place where the length of 10D can be assured on upstream side and 5D on downstream side.</p> <p>→ Mount the instrument with a clearance of 30D or more.</p> <p>→ Set the damping to increase the response time.</p>
Measured value remains the same though flow rate is changing. (LED lit in red)	<p>Measured value is held because ultrasonic wave cannot be propagated into a pipe.</p> <p>1. Incomplete installation</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <ul style="list-style-type: none"> ● Error in piping specifications ● Sensor is mounted on welding. ● Error in sensor mounting dimensions ● Error in silicon appliance at the time of mounting the sensor ● Error in connection of the sensor cable. </div> <p>→</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>Upon checking, remove the sensor, apply silicone filler, and slightly off position the sensor.</p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>Sensor mounting is poor</p> <ul style="list-style-type: none"> ● Mounting dimension ● The sensor is coming off the pipe. </div> <p>→</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <ul style="list-style-type: none"> ● Mount the sensor in parallel with pipe, allowing correct sensor unit spacing. ● Mount the sensor properly so that it is kept in close contact with the pipe. </div> <p>2. Problem on pipe or fluid</p> <p>○ Pipe not filled with fluid</p> <p>→</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>Locate a place which is completely filled on the same piping line, and shift the sensor there.</p> <ul style="list-style-type: none"> ● Attach the sensor to the lowest place on the pipeline. </div> <p>○ Bubbles included in the fluid</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>[Bubbles are introduced if reading is normal when flow is stopped.]</p> </div> <p>→</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>Eliminate ingress of bubbles.</p> <ul style="list-style-type: none"> ● Raise the level of the pump well. ● Check the shaft seal of the pump. ● Retighten the flange of negative pressure pipe. ● Arrange so that fluid doesn't fall into the pump well. </div> <div style="border: 1px solid black; padding: 5px;"> <p>Move the sensor to the location where air bubbles have not entered.</p> <ul style="list-style-type: none"> ● Inlet side of the pump ● Upstream side of the valve </div>	<p>(Continued on next page.)</p>

Status	Probable cause	Troubleshooting
(Continued from the previous page.)	<ul style="list-style-type: none"> ○ High turbidity [Turbidity is higher than those of sewage and return sludge.] → ○ Pipe is old and scale is attached on inner side. → ○ Lining is thick. [Because of mortar lining or the like, thickness is a few ten mm or more.] → ○ Lining is peeled. [There is a gap between the lining and the pipe.] → ○ Sensor is mounted on bend pipe or tapered pipe. → 3. Effect of external noise → <ul style="list-style-type: none"> ● There is a radio broadcasting station nearby. ● Measurement conducted near a passage of vehicles or electric cars. 4. Hard failure → 	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <ul style="list-style-type: none"> ● Move sensor to a place of smaller diameter on the same pipeline. ● Move the sensor to other places or to different piping. </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>Mount the sensor on straight pipe.</p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <ul style="list-style-type: none"> ● Reduce the length of main unit sensor cable to a minimum. ● Ground the main unit and piping. </div> <div style="border: 1px solid black; padding: 5px;"> <p>Refer to “6.6.7. Remediying a hardware fault”.</p> </div>
Measured value not zero when fluid stops flowing.	<ul style="list-style-type: none"> ● Fluid forms a convection inside the pipe. → ● Zero point adjustment → ● Pipe is not completely filled or is empty when water is at a standstill (LED lit red). → 	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>Normal</p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <ul style="list-style-type: none"> ● Readjust the zero point after fluid has completely stopped flowing. </div> <div style="border: 1px solid black; padding: 5px;"> <p>Normal</p> </div>
Error in measured value	<ul style="list-style-type: none"> ● Input piping specifications differ from the actual ones. → ● Scales exist on wall of old pipe. → ● Insufficient linear pipe length (10D or more for upstream and 50D or more for downstream) → ● Pipe is not filled with fluid or sludge is deposited in the pipe. → 	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>A difference of 1% in inner diameter causes an error of about 3%. <ul style="list-style-type: none"> ● Input the correct specifications. ● Input scale as lining. </p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>Find another mounting place (upstream of disturbing objects). [No disturbing objects in flow within 30D upstream without pump, valve, combined pipe, etc.]</p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <ul style="list-style-type: none"> ● Mount the sensor at different angles with respect to the cross section of pipe to fine the location where mean value is obtainable. The mount the sensor at that location. </div> <div style="border: 1px solid black; padding: 5px;"> <p>Occurs particularly where sectional area is small. <ul style="list-style-type: none"> ● Move sensor to a vertical pipe. </p> </div>

6.6.5. Error in analog output


Status	Probable cause	Troubleshooting
Current output is not matched.	Range setting is wrong.	→ ● Set the range correctly.
Not 4mA when measurement value is 0.	Analog output is maladjusted.	→ ● Perform analog output calibration.
Output is 0mA.	Break of wiring	
Output rises beyond 20mA.	“OVER FLOW” appears on the LCD.	→ Range over ● Recommence setting of range data of analog output.
The output becomes lower than 4mA.	“UNDER FLOW” appears on the LCD.	→ Back flow ● Set upper/lower stream properly.
Indication is changed but analog output remains the same.	The output load is 1 kΩ or more.	→ ● It must be less than 1 kΩ.
Indication does not agree with analog output.	Analog output is maladjusted.	→ ● Perform analog output calibration.
Analog output doesn't change even after it has been adjusted.	Hard failure	→ ● Contact us.

6.6.6. Checking received waveforms

The unit has high-voltage part. Be sure to ask our service personnel for the work described below.

6.6.6.1. How to connect the oscilloscope

Open the cover, and connect an oscilloscope to the check pin on the printed board according to the following figure. The unit has high-voltage part. Do not touch the parts other than those specified below.





Oscilloscope

6.6.6.2. Checking sending/receiving


Monitor the waveform, and check the status of received waveform.

a) Normal status



Relationship between the received waveform and the sampling window


Pipe inside echoic wave (generated only in case of V method mounting).
In mounting by the Z method, there is no echoic wave.



Magnified view of signals


The received waveform controls the peak to be approximately 1.5Vp-p.

Startup of signals is not good



Cause of the poor startup signals


- (1) Incorrect detector mounting, dimensions (sensor mounting dimension, outer diameter, etc) and detector mounting angle



⇒ Mount the detector properly.

- (2) Interference from acoustic wave (It is likely to happen when the outer diameter is set longer than the actual length.)
⇒ Make a setting of the acoustic wave of the fluid type to be 20 to 50m/s lower, and remount the detector again.
Note) 1400m/s is set for water.


b) Noise on the one side



Waveform with noise on the one side


<Cause>	<Check>
Dedicated cable on the one side is abnormal.	Measure the insulation resistance.
Polarity of connected terminals is inverted.	Check the connection
Sensor on the one side is abnormal.	Peel off the detector and check the sensitivity
Detector bonding surface is peeling.	Peel off the detector and temporarily place it by grease, etc.
Dedicated cable is disconnecting.	Check the continuity.
Poor contact.	

c) There is white noise all around.



Waveform with the overall noise


d) Pulsed noise is observed.



Waveform with pulsed noise on the signal line

Measurement can be performed if the noise level is smaller than the received waveform level ($0.75V_{0-p}$).

<Cause>	<Check>
Noise is placed on the power line.	Check the power line using an oscilloscope, and install a noise-cut transformer.
Noise is placed on the grounding line (panel earth, etc).	Check the power line using an oscilloscope, and remove the ground wire.
Dedicated cable is picking the inductive noise.	Move the flow transmitter near the detector and perform confirmation. Keep the dedicated cable apart from the power cable.
The distance between the detector and the flow transmitter is long, and dedicated cable length is long.	Perform grounding according to the following figure.
Insufficient sensitivity Signal power (AGC_U, AGC_D) 35% or less	Change the detector. FLS__2, FLW12→FLW11 FLW51→FLW50



6.6.7. Remediating a hardware fault

If the hardware is found faulty upon interventions in Section 6.6.1 to Section 6.6.6 above, specify details of anomaly to us.

7. Appendix

7.1. Specifications

Operational specifications/System configuration

• System configuration:

The system is composed of a detector (Type: FLS/FLW/FLD) and a flow transmitter (Type: FSV), realizing single-path system.

• Application:

Uniform liquid in which ultrasonic waves can propagate.

Air bubble quantity:

0 to 12vol% (diameter of 50A, water, velocity of 1m/s)

Turbidity of fluid:

10000°C. (mg/L) or less

Type of flow: Well-developed turbulent or laminar flow in a filled pipe.

• Applicable flow pipe:

Detector	Piping diameter (inner diameter)	Applicable piping material	Mounting method	Fluid temperature range
Widespread equipment	FLSS12	Φ25 to Φ100mm	V method	-20 to 100°C
		Φ50 to Φ100mm		
	FLSS22	Φ50 to Φ225mm		
		Φ50 to Φ225mm		
General equipment	FLD22	Φ13 to Φ100mm	V method	-40 to 100°C
	FLW1	Φ50 to Φ300mm	V method	-40 to 80°C
	FLW4	Φ200 to Φ1200mm	V method or Z method	
	FLW5	Φ200 to Φ6000mm	V method or Z method	
	FLD32	Φ50 to Φ400mm	V method or Z method	-40 to 200°C

Note 1) Select FLW11, FLW41 or FLW5 if the pipe is made of PP or PVDF. The wall thickness of PP pipe is 15 mm or less, and that of PVDF pipe is 9 mm or less.

Note 2) Select FLW11, FLW41 or FLW5 for pipes made of materials that do not allow ultrasonic to pass through easily such as cast iron, lining, or old steel pipes.

Lining material:

Tar epoxy, mortar, rubber, etc

* If lining is peeled, measurement may be unavailable.

Straight pipe length:

10D for upstream and 5D for downstream (D: internal pipe diameter)

Refer to Conditions on straight pipe for details.

Note 3) When using silicon-free grease for the acoustic coupler, the fluid temperature range becomes 0 to 60°C regardless of detector.

- Velocity range: 0 to ±0.3.....±32m/s
- Power supply: 100 to 240V AC, +10%/-15%, 50/60Hz or 20 to 30V DC
- Signal cable: Coaxial cable (standard: 5m, Maximum: 300m)
60m max for widespread type detector (FLS), 300m max. for others
Allowable temperature limit: 80°C

• Installation environment:

Non-explosive environment without direct sunlight, corrosive gas and heat radiation

• Ambient temperature:

Flow transmitter: -20 to +55°C

Detector : -20 to +80°C

• Ambient humidity: 95% RH or less

• Grounding: Class D grounding (100Ω)

• Arrestor: Surge absorbers for outputs and power supply incorporated as standard

Performance specifications

• Accuracy rating:

Sensor type	Diameter (inner diameter)	Applicable piping material	Velocity	Accuracy
Widespread type	FLSS12	Plastic	2 to 32m/s	2.0% of rate
			0 to 2m/s	0.04m/s
			2 to 32m/s	1.0% of rate
	FLSS22	Metal piping	0 to 2m/s	0.02m/s
			2 to 32m/s	2.0% of rate
			0 to 2m/s	0.04m/s
General type	FLD22	Plastic, metal piping	2 to 32m/s	2.5% of rate
			0 to 2m/s	0.05m/s
			2 to 32m/s	1.5% of rate
	FLW12 FLD32 FLW51	Φ50 to Φ300 or less	2 to 32m/s	1.0% of rate
			0 to 2m/s	0.02m/s
			1 to 32m/s	1.0% of rate
	FLW11 FLW41 FLW50	Φ300 to Φ6000	0 to 1m/s	0.01m/s
			2 to 32m/s	1.5% of rate
			0 to 2m/s	0.03m/s
		Φ300 to Φ6000	1 to 32m/s	1.5% of rate
			0 to 1m/s	0.015m/s
			0 to 1m/s	0.015m/s

- Response time: 0.5 sec (standard mode)
0.2 sec by setting (High speed response mode)
- Power consumption: 15VA or less (AC power supply)
6W or less (DC power supply)

Functional specifications

- Analog signal: 4 to 20mA DC (1 point)
Load resistance: 1kΩ
- Contact signal: Contact output: +total, -total, alarm, acting range, flow switch or total switch
Relay contact (insulation, with socket, built-in arrestor)
 - Number of outputs: 1 point
 - Normal: Open/close selectable
 - Contact capacity 240AC or 30V DC, 1A
 - Output frequency: 1P/s max.
(Pulse width: 50, 100, 200ms)
- Transistor contact (insulation, open collector, built-in arrestor)
 - Number of outputs: 2 points
 - Normally: ON/OFF selectable
 - Contact capacity 30V DC, 0.1A
 - Output frequency: 1000P/s max.
(Pulse width: 5, 10, 50, 100, 200ms)
- Contact input: 1 point (no-voltage contact) / Zero point adjustment and totalize reset are available for allocation
- Serial communication (option): Equivalent to RS-232c or RS-485, insulation, built-in arrestor
Number of connectable units:
1 unit (RS-232c) / up to 31 units (RS-485): MODBUS
Communication speed: 9600, 19200, 38400bps
Parity: None/odd/even selectable
Stop bit: 1 bit/2 bits selectable
Transmission distance:
1.5m max.(RS-232c) / 1km max.(RS-485)
Data: Velocity, flow rate, +total, -total, status, etc.
- Display device: 2 color LED (Normal state: Green, Error state: Red)
LCD display, 16 digits 2 lines, provided with back light
- Display language: Japanese (Katakana)/English/French/German/Spanish selectable
- Flow velocity/flow rate indication: Instantaneous velocity, instantaneous flow rate display
(The flow in reverse direction is displayed with minus "-.")
Numeric value:
8 digits (decimal point is corresponding to 1 digit)
Unit:
Flow velocity: m/s
Flow rate: L/s, L/min, L/h, L/d, kL/d, ML/d, m³/s, m³/min, m³/h, m³/d, km³/d, Mm³/d

- Total indication: Display of forward or reverse total (reverse is displayed in minus)
Numeric value:
8 digits (decimal point is corresponding to 1 digit)
Unit: mL, L, m³, km³, Mm³
- Setup function: Setting can be performed by 4 keys (ESC, △, ▷, ENT) on the front face of the flow transmitter.
- Zero point adjustment: Set zero/Clear available
- Damping: 0 to 100sec (every 0.1sec) configurable for analog output and display
- Low flow rate cutting: 0 to 5 [m/s] in terms of flow velocity
- Alarm: Hardware fault/process fault can be tied to digital output
- Output burnout: Analog output:
Flow rate total: Hold/count selectable
Burnout timer: 0 to 100sec (every 1 sec)
- Bi-directional range: Forward and reverse ranges configurable independently
Hysteresis: 0 to 20% of working range
Working range applicable to digital output
- Auto-2 ranges: Forward 2 ranges configurable independently
Hysteresis: 0 to 20% of working range
Working range applicable to digital output
- Flow switch: Lower and upper switching points configurable independently
Acting point applicable to digital output
- Total switch: Total switching upper point configurable
Acting point applicable to digital output

Physical specifications

- Enclosure protection:
Flow transmitter: IP66
Detector: FLS: IP65 (With waterproof BNC connector provided)
FLW (general type):
IP67 (Silicon compound is filled on the terminal part after wiring.)
FLW (submergible):
IP68 (Durable in flood for several weeks)
- Mounting method: Flow transmitter: Mounted on wall or 2B pipe.
Detector: Clamped on pipe surface
- Acoustic coupler: Silicon compound, silicone grease or silicon-free grease
(Note) Acoustic coupler is the media that eliminates a gap between the detector and pipe.

Kind of acoustic coupler:

Kind	Silicon compound (KE-348W)	Silicone grease (G40M)	Silicon-free grease (HIGH Z)	High-temperature grease (KS62M)
Fluid temperature	-40 to +100°C	-40 to +100°C	0 to +60°C	-30 to +250°C
Teflon tube	×	○	○	○

- Material: Flow transmitter: aluminum alloy
Detector:

Detector	Sensor housing	Sensor cover	Guide rail
FLSS1	PBT	-	SUS304
FLSS2	PBT	-	SUS304+PBT
FLD22	PBT	-	Aluminum alloy + Plastic
FLW1	PBT	SUS304	SUS304 + Plastic
FLW4 FLW5	PBT	SUS304	-
FLD32	SUS304	-	SUS304 + Aluminum alloy

- Signal cable: FLY3 (Applicable detector: FLS):
• Structure:
Heat-resisting high-frequency coaxial cable (3D2V)
• External sheath: Black flame-resistant vinyl
• Outline: Approx. 5.0mm
• Terminal treatment:
M3 amplifier terminal (Flow Transmitter side), BNC connector (detector side)
FLY8, FLY9 (Applicable detector: FLW, FLD):
• High-frequency coaxial cable (double shielded)
• External sheath: Black flame-resistant vinyl
• Outline: Approx. 7.3mm
• Terminal treatment:
M3 amplifier terminal (Flow Transmitter side), M4 amplifier terminal (detector side)
Note that, BNC connector is provided for FLD22 and FLD32 detector side.
• Weight: Approx. 90g/m
- Dimensions: Flow transmitter: H170 × W142 × D70mm
Detector:
H50 × W228 × D34mm (FLSS1)
H50 × W348 × D34mm (FLSS2)
H420 × W53 × D90mm (FLD22)
H500 × W80 × D40mm (FLW1)
H72 × W93 × D62mm (FLW4)
H104 × W93 × D62mm (FLW5)
H530 × W52 × D205mm (FLD32)
- Weight: Flow transmitter: 1.5kg
Detector:
0.3kg (FLSS1)
0.4kg (FLSS2)
0.6kg (FLD22)
1.0kg (FLW1)
0.4kg (FLW4)
1.4kg (FLW5)
1.6kg (FLD32)

Loader software for PCs

- Equipped as standard.
- Applicable PC: PC/AT-compatible machine
 - The operation on PC98 series (NEC) cannot be guaranteed.
 - Major function: Performs various parameter setting/change of the main unit
 - OS: Windows 2000/XP
 - Required memory: 125MB or larger
 - Disk drive: Windows 2000/XP-capable CD-ROM
 - Hard disk capacity: Free capacity of 52MB or larger required.

Note) PC loader communication cable (type ZZP*FSVTK4J1236) is separately required for RS-232c for serial communication.


Note) USB-RS-232c Converter

PCs that do not support RS-232c serial interface is required for a converter to connect a PC to the main unit.
USB-RS-232c Converter is used in combination with a PC loader communication cable described above.
<Recommended item>
USB-CVRS9 (Sunwa Supply Inc. product)


7.2. OUTLINE DIAGRAM

Flow transmitter (Type: FSV□□Y□1-S)


* Pipe mount (option)




* Wall mount





Detector (Type: FLSS□2)




Detector (Type: FLW1□)




Detector (Type: FLW41)




External connection diagram




Detector (Type: FLW5□)



Detector (Type: FLD22)



Detector (Type: FLD32)



7.3. ORDERING INFORMATION

1. Type of detector
2. Type of flow transmitter
3. Type of signal cable
4. Tag No. (When tag plate is specified)
5. Parameter setting list (When parameter setting is specified)

Company name: _____ Branch: _____
 Name of the contact person: _____ TEL: _____
 Measuring fluid: _____

Parameter setting list

Setting items		Initial value	Setting value	Setting items		Initial value	Setting value	
ID No		0000		Total mode		Stop		
Language		English		Pulse value		0m ³		
Measurement condition	System unit	Metric		Total output	Total preset	0m ³		
	Flow unit	m ³ /h			Pulse width	50.0msec		
	Total unit	m ³			Burnout (total)	Hold		
	Outer diameter	60.00mm			Burnout timer	10sec		
	Pipe material	PVC			DO1 Output type (Note1)	Not used		
	Wall thickness	4.00mm			DO1 Output operation	Active ON		
	Lining material	No lining		DO2 Output type	Not used			
	Lining thickness	-		DO2 Output operation	Active ON			
	Kind of fluid	Water		DO3 Output type	Not used			
	Viscosity	1.0038×10 ⁻⁶ m ² /s		DO3 Output operation	Active ON			
	Sensor mount	V method		D11 Input type	Not used			
	Sensor type	FLS_12		D11 Input operation	Active ON			
	Transmit. velocity	80Vpp		Operation mode	Standard			
	Output condition	Damping	5.0sec		Communication	Communication mode	RS-232C	
Cut off		0.150m ³ /h		Baud rate		9600bps		
Display		Content of 1st line	Velocity (m/s)			Parity	Odd	
		Decimal point position of 1st line	****.***			Stop bit	1 bit	
		Content of 2nd line	Flow Rate (m ³ /h)			Station No.	1	
		Decimal point position of 2nd line	****.***					
Analog output		Range type	SINGLE					
		Full scale 1	15.000m ³ /h					
		Full scale 2	0.000m ³ /h					
		Hysteresis	10.00%					
		Burnout (current)	HOLD					
		Burnout timer	10sec					
		Output limit low	-20%					
		Output limit high	120%					
Rate limit	0.000m ³ /h							
Rate limit timer	0sec							

Note 1) When total pulse output has been selected for DO1, DO2 or DO3 specify total pulse value and total pulse width so that conditions 1 and 2 shown below are satisfied.

Condition 1:

$$\frac{\text{Full scale} \times 1 \text{ [m}^3/\text{s]}}{\text{Pulse value [m}^3]} \leq \begin{cases} 100[\text{Hz}] & (\text{In case of DO1, DO2}) \\ 1[\text{Hz}] & (\text{In case of DO3}) \end{cases}$$


Condition 2:

$$\frac{\text{Full scale} \times 1 \text{ [m}^3/\text{s]}}{\text{Pulse value [m}^3]} \leq \frac{100}{2 \times \text{Pulse width [ms]}}$$

*1) The range of FULL SCALE 1 or FULL SCALE 2, whichever is larger, is the object in case of automatic 2-range, forward and reverse range, forward and reverse automatic 2-range.

7.4. How to make gauge paper

- (1) Provide a sheet of paper (or vinyl) having the length of $4D$ and width of 200 mm (D if possible) or longer, with long sides parallel to each other.



- (2) Draw a line that intersects with the long sides at right angles at a place about 100 mm from one end.



7.5. Piping data

Stainless steel pipe for pipe arrangement (JIS G3459-2004)

Nominal diameter		Outer diameter mm	Thickness						
			Schedule 5S	Schedule 10S	Schedule 20S	Schedule 40	Schedule 80	Schedule 120	Schedule 160
A	B		Thickness mm	Thickness mm	Thickness mm	Thickness mm	Thickness mm	Thickness mm	Thickness mm
15	1/2	21.7	1.65	2.1	2.5	2.8	3.7	-	4.7
20	3/4	27.2	1.65	2.1	2.5	2.9	3.9	-	5.5
25	1	34.0	1.65	2.8	3.0	3.4	4.5	-	6.4
32	1 1/4	42.7	1.65	2.8	3.0	3.6	4.9	-	6.4
40	1 1/2	48.6	1.65	2.8	3.0	3.7	5.1	-	7.1
50	2	60.5	1.65	2.8	3.5	3.9	5.5	-	8.7
65	2 1/2	76.3	2.1	3.0	3.5	5.2	7.0	-	9.5
80	3	89.1	2.1	3.0	4.0	5.5	7.6	-	11.1
90	3 1/2	101.6	2.1	3.0	4.0	5.7	8.1	-	12.7
100	4	114.3	2.1	3.0	4.0	6.0	8.6	11.1	13.5
125	5	139.8	2.8	3.4	5.0	6.6	9.5	12.7	15.9
150	6	165.2	2.8	3.4	5.0	7.1	11.0	14.3	18.2
200	8	216.3	2.8	4.0	6.5	8.2	12.7	18.2	23.0
250	10	267.4	3.4	4.0	6.5	9.3	15.1	21.4	28.6
300	12	318.5	4.0	4.5	6.5	10.3	17.4	25.4	33.3
350	14	355.6	-	-	-	11.1	19.0	27.8	35.7
400	16	406.4	-	-	-	12.7	21.4	30.9	40.5
450	18	457.2	-	-	-	14.3	23.8	34.9	45.2
500	20	508.0	-	-	-	15.1	26.2	38.1	50.0
550	22	558.8	-	-	-	15.9	28.6	41.3	54.0
600	24	609.6	-	-	-	17.5	34.0	46.0	59.5
650	26	660.4	-	-	-	18.9	34.0	49.1	64.2

Polyethylene pipe for city water (JIS K6762-2004)

Nominal diameter (mm)	Outer diameter (mm)	1st type (Soft pipe)		2nd type (Hard pipe)	
		Thickness (mm)	Weight (kg/m)	Thickness (mm)	Weight (kg/m)
13	21.5	3.5	0.184	2.5	0.143
20	27.0	4.0	0.269	3.0	0.217
25	34.0	5.0	0.423	3.5	0.322
30	42.0	5.5	0.595	4.0	0.458
40	48.0	6.5	0.788	4.5	0.590
50	60.0	8.0	1.210	5.0	0.829

Galvanized steel pipe for city water SGPW (JIS G3442-2004)

How to call pipe		Outer diameter (mm)	Thickness (mm)
(A)	(B)		
15	1/2	21.7	2.8
20	3/4	27.2	2.8
25	1	34.0	3.2
32	1 1/4	42.7	3.5
40	1 1/2	48.6	3.5
50	2	60.5	3.8
65	2 1/2	76.3	4.2
80	3	89.1	4.2
90	3 1/2	101.6	4.2
100	4	114.3	4.5
125	5	139.8	4.5
150	6	165.2	5.0
200	8	216.3	5.8
250	10	267.4	6.6
300	12	318.5	6.9

Asbestos cement pipe for city water (JIS A5301-1971)

Nominal diameter (mm)	1st type		2nd type		3rd type		4th type	
	Thickness of connected part (mm)	Outer diameter of connected part (mm)	Thickness of connected part (mm)	Outer diameter of connected part (mm)	Thickness of connected part (mm)	Outer diameter of connected part (mm)	Thickness of connected part (mm)	Outer diameter of connected part (mm)
50	10	70	-	-	-	-	-	-
75	10	95	-	-	-	-	-	-
100	12	124	10	120	9	118	-	-
125	14	153	11	147	9.5	144	-	-
150	16	182	12	174	10	170	-	-
200	21	242	15	230	13	226	11	222
250	23	296	19	288	15.5	281	12	274
300	26	352	22	344	18	336	14	328
350	30	410	25	400	20.5	391	16	382
400	35	470	29	458	23	446	18	436
450	39	528	32	514	26	502	20	490
500	43	586	35	570	28.5	557	22	544
600	52	704	42	684	34	668	26	652
700	-	-	49	798	39	778	30	760
800	-	-	56	912	44	888	34	868
900	-	-	-	-	49	998	38	976
1000	-	-	-	-	54	1108	42	1084
1100	-	-	-	-	59	1218	46	1192
1200	-	-	-	-	65	1330	50	1300
1300	-	-	-	-	73	1496	57	1464
1500	-	-	-	-	81	1662	63	1626

Polyethylene pipe for general use (JIS K6761-2004)

Nominal diameter	Outer diameter (mm)	1st type (Soft pipe)	2nd type (Hard pipe)
		Thickness (mm)	Thickness (mm)
13	21.5	2.7	2.4
20	27.0	3.0	2.4
25	34.0	3.0	2.6
30	42.0	3.5	2.8
40	48.0	3.5	3.0
50	60.0	4.0	3.5
65	76.0	5.0	4.0
75	89.0	5.5	5.0
100	114	6.0	5.5
125	140	6.5	6.5
150	165	7.0	7.0
200	216	-	8.0
250	267	-	9.0
300	318	-	10.0

Hi vinyl chloride pipe (conduit size)

Nominal diameter of pipe	Outer diameter	Pipe thickness
28	34.0	3.0
35	42.0	3.5
41	48.0	3.5
52	60.0	4.0
65	76.0	4.5
78	89.0	5.5

Vertical type cast iron pipe (JIS G5521)

Nominal diameter D	Pipe thickness T		Actual outer diameter D1
	Normal pressure pipe	Low pressure pipe	
	75	9.0	
100	9.0	-	118.0
150	9.5	9.0	169.0
200	10.0	9.4	220.0
250	10.8	9.8	271.6
300	11.4	10.2	322.8
350	12.0	10.6	374.0
400	12.8	11.0	425.6
450	13.4	11.5	476.8
500	14.0	12.0	528.0
600	15.4	13.0	630.8
700	16.5	13.8	733.0
800	18.0	14.8	836.0
900	19.5	15.5	939.0
1000	22.0	-	1041.0
1100	23.5	-	1144.0
1200	25.0	-	1246.0
1350	27.5	-	1400.0
1500	30.0	-	1554.0

Hi vinyl chloride pipe (city water pipe size)

Nominal diameter	Outer diameter	Pipe thickness
13	18.0	2.5
20	26.0	3.0
25	32.0	3.5
30	38.0	3.5
40	48.0	4.0
50	60.0	4.5
75	89.0	5.8
100	114.0	7.0
125	140.0	7.5
150	165.0	8.5

Hard vinyl chloride pipe (JIS K6741-2004)

Type Nominal (mm)	VP		VU	
	Outer diameter	Thickness	Outer diameter	Thickness
13	18	2.2	-	-
16	22	2.7	-	-
20	26	2.7	-	-
25	32	3.1	-	-
30	38	3.1	-	-
40	48	3.6	48	1.8
50	60	4.1	60	1.8
65	76	4.1	76	2.2
75	89	5.5	89	2.7
100	114	6.6	114	3.1
125	140	7.0	140	4.1
150	165	8.9	165	5.1
200	216	10.3	216	6.5
250	267	12.7	267	7.8
300	318	15.1	318	9.2
350	-	-	370	10.5
400	-	-	420	11.8
450	-	-	470	13.2
500	-	-	520	14.6
600	-	-	630	17.8
700	-	-	732	21.0
800	-	-	-	-

Coated steel pipe for city water PTPW (JIS G3443-1968)

Nominal diameter (A)	Outer diameter (mm)	Thickness (mm)
80	89.1	4.2
100	114.3	4.5
125	139.8	4.5
150	165.2	5.0
200	216.3	5.8
250	267.4	6.6
300	318.5	6.9
350	355.6	6.0
400	406.4	6.0
450	457.2	6.0
500	508.0	6.0
600	609.6	6.0
700	711.2	6.0
800	812.8	7.1
900	914.4	7.9
1000	1016.0	8.7
1100	1117.6	10.3
1200	1219.2	11.1
1350	1371.6	11.9
1500	1524.0	12.7

Carbon steel pipe for pipe arrangement (JIS G3452-2004)

How to call pipe		Outer diameter (mm)	Thickness (mm)
(A)	(B)		
15	1/2	21.7	2.8
20	3/4	27.2	2.8
25	1	34.0	3.2
32	1 1/4	42.7	3.5
40	1 1/2	48.6	3.5
50	2	60.5	3.8
65	2 1/2	76.3	4.2
80	3	89.1	4.2
90	3 1/2	101.6	4.2
100	4	114.3	4.5
125	5	139.8	4.5
150	6	165.2	5.0
175	7	190.7	5.3
200	8	216.3	5.8
225	9	241.8	6.2
250	10	267.4	6.6
300	12	318.5	6.9
350	14	355.6	7.9
400	16	406.4	7.9
450	18	457.2	7.9
500	20	508.0	7.9

Coated steel pipe for city water STW (JIS G3443-2007)

Nominal diameter (A)	Outer diameter (mm)	Symbol for type				Symbol for type			
		STW 30	STW 38	STW 41		STW 290	STW 370	STW 400	
				Nominal thickness				Nominal thickness	
		Thickness (mm)	Thickness (mm)	A	B	Thickness (mm)	Thickness (mm)	A	B
80	89.1	4.2	4.5	-	-	4.2	4.5	-	-
100	114.3	4.5	4.9	-	-	4.5	4.9	-	-
125	139.8	4.5	5.1	-	-	4.5	5.1	-	-
150	165.2	5.0	5.5	-	-	5.0	5.5	-	-
200	216.3	5.8	6.4	-	-	5.8	6.4	-	-
250	267.4	6.6	6.4	-	-	6.6	6.4	-	-
300	318.5	6.9	6.4	-	-	6.9	6.4	-	-
350	355.6	-	-	6.0	-	-	-	6.0	-
400	406.4	-	-	6.0	-	-	-	6.0	-
450	457.2	-	-	6.0	-	-	-	6.0	-
500	508.0	-	-	6.0	-	-	-	6.0	-
600	609.6	-	-	6.0	-	-	-	6.0	-
700	711.2	-	-	7.0	6.0	-	-	7.0	6.0
800	812.8	-	-	8.0	7.0	-	-	8.0	7.0
900	914.4	-	-	8.0	7.0	-	-	8.0	7.0
1000	1016.0	-	-	9.0	8.0	-	-	9.0	8.0
1100	1117.6	-	-	10.0	8.0	-	-	10.0	8.0
1200	1219.2	-	-	11.0	9.0	-	-	11.0	9.0
1350	1371.6	-	-	12.0	10.0	-	-	12.0	10.0
1500	1524.0	-	-	14.0	11.0	-	-	14.0	11.0
1600	1625.6	-	-	15.0	12.0	-	-	15.0	12.0
1650	1676.4	-	-	15.0	12.0	-	-	15.0	12.0
1800	1828.8	-	-	16.0	13.0	-	-	16.0	13.0
1900	1930.4	-	-	17.0	14.0	-	-	17.0	14.0
2000	2032.0	-	-	18.0	15.0	-	-	18.0	15.0
2100	2133.6	-	-	19.0	16.0	-	-	19.0	16.0
2200	2235.2	-	-	20.0	16.0	-	-	20.0	16.0
2300	2336.8	-	-	21.0	17.0	-	-	21.0	17.0
2400	2438.4	-	-	22.0	18.0	-	-	22.0	18.0
2500	2540.0	-	-	23.0	18.0	-	-	23.0	18.0
2600	2641.6	-	-	24.0	19.0	-	-	24.0	19.0
2700	2743.2	-	-	25.0	20.0	-	-	25.0	20.0
2800	2844.8	-	-	26.0	21.0	-	-	26.0	21.0
2900	2946.4	-	-	27.0	21.0	-	-	27.0	21.0
3000	3048.0	-	-	29.0	22.0	-	-	29.0	22.0

Centrifugal nodular graphite cast iron pipe for city water (A type) (JWWA G-105 1971)

Nominal diameter	Pipe thickness			Actual outer diameter
	T			
D	1st type pipe	2nd type pipe	3rd type pipe	D ₁
75	7.5	-	6.0	93.0
100	7.5	-	6.0	118.0
150	7.5	-	6.0	169.0
200	7.5	-	6.0	220.0
250	7.5	-	6.0	271.6
300	7.5	-	6.5	332.8
350	7.5	-	6.5	374.0
400	8.5	7.5	7.0	425.6
450	9.0	8.0	7.5	476.8
500	9.5	8.5	7.0	528.0

Centrifugal nodular graphite cast iron pipe for city water (K type) (JWWA G-105 1971)

Nominal diameter	Pipe thickness			Actual outer diameter
	1st type pipe	2nd type pipe	3rd type pipe	
D	1st type pipe	2nd type pipe	3rd type pipe	D ₁
400	8.5	7.5	7.0	425.6
450	9.0	8.0	7.5	476.8
500	9.5	8.5	8.0	528.0
600	11.0	10.0	9.0	630.8
700	12.0	11.0	10.0	733.0
800	13.5	12.0	11.0	836.0
900	15.0	13.0	12.0	939.0
1000	16.5	14.5	13.0	1041.0
1100	18.0	15.5	14.0	1144.0
1200	19.5	17.0	15.0	1246.0
1350	21.5	18.5	16.5	1400.0
1500	23.5	20.5	18.0	1554.0

Arc welded large-diameter stainless steel pipe for pipe arrangement (JIS G3468-2004)

Nominal diameter		Outer diameter (mm)	Nominal thickness			
			Schedule 5S	Schedule 10S	Schedule 20S	Schedule 40S
A	B		Thickness mm	Thickness mm	Thickness mm	Thickness mm
150	6	165.2	2.8	3.4	5.0	7.1
200	8	216.3	2.8	4.0	6.5	8.2
250	10	267.4	3.4	4.0	6.5	9.3
300	12	318.5	4.0	4.5	6.5	10.3
350	14	355.6	4.0	5.0	8.0	11.1
400	16	406.4	4.5	5.0	8.0	12.7
450	18	457.2	4.5	5.0	8.0	14.3
500	20	508.0	5.0	5.5	9.5	15.1
550	22	558.8	5.0	5.5	9.5	15.9
600	24	609.6	5.5	6.5	9.5	17.5
650	26	660.4	5.5	8.0	12.7	-
700	28	711.2	5.5	8.0	12.7	-
750	30	762.0	6.5	8.0	12.7	-
800	32	812.8	-	8.0	12.7	-
850	34	863.6	-	8.0	12.7	-
900	36	914.1	-	8.0	12.7	-
1000	40	1016.0	-	9.5	14.3	-

Ductile iron specials (JIS G5527-1998)

Nominal diameter (mm)	Pipe thickness (mm)
75	8.5
100	8.5
150	9.0
200	11.0
250	12.0
300	12.5
350	13.0
400	14.0
450	14.5
500	15.0
600	16.0
700	17.0
800	18.0
900	19.0
1000	20.0
1100	21.0
1200	22.0
1350	24.0
1500	26.0
1600	27.5
1650	28.0
1800	30.0
2000	32.0
2100	33.0
2200	34.0
2400	36.0

Dimensions of centrifugal sand mold cast iron pipe (JIS G5522)

Nominal diameter D	Pipe thickness (T)			Actual outer diameter D ₁
	High pressure pipe	Normal pressure pipe	Low pressure pipe	
75	9.0	7.5	-	93.0
100	9.0	7.5	-	118.0
125	9.0	7.8	-	143.0
150	9.5	8.0	7.5	169.0
200	10.0	8.8	8.0	220.0
250	10.8	9.5	8.4	271.6
300	11.4	10.0	9.0	322.8
350	12.0	10.8	9.4	374.0
400	12.8	11.5	10.0	425.6
450	13.4	12.0	10.4	476.8
500	14.0	12.8	11.0	528.0
600	-	14.2	11.8	630.8
700	-	15.5	12.8	733.0
800	-	16.8	13.8	836.0
900	-	18.2	14.8	939.0

Dimensions of centrifugal sand mold cast iron pipe (JIS G5523 1977)

Nominal diameter (mm)	Pipe thickness (T)		Actual outer diameter D ₁
	High pressure pipe	Normal pressure pipe	
75	9.0	7.5	93.0
100	9.0	7.5	118.0
125	9.0	7.8	143.0
150	9.5	8.0	169.0
200	10.0	8.8	220.0
250	10.8	9.5	271.6
300	11.4	10.0	322.8

Cast iron pipe for waste water (JIS G5525-1975)

Nominal diameter	Pipe thickness	Actual internal diameter	Actual outer diameter
	T	D ₁	D ₂
50	6.0	50	62
65	6.0	65	77
75	6.0	75	87
100	6.0	100	112
125	6.0	125	137
150	6.0	150	162
200	7.0	200	214

Hard vinyl chloride pipe for city water (JIS K6742-1975)

Nominal diameter	Outer diameter	Thickness
13	18	2.5
16	22	
20	26	3.0
25	32	3.5
30	38	3.5
40	48	4.0
50	60	4.5
75	89	5.9
100	114	7.1
150	165	9.6

Arc welded carbon steel pipe STPY (JIS G3457-2005)

Unit: kg/m

Nominal diameter		Thickness (mm)	6.0	6.4	7.1	7.9	8.7	9.5	10.3	11.1	11.9	12.7	13.1	15.1	15.9
(A)	(B)														
350	14	355.6	51.7	55.1	61.0	67.7									
400	16	406.4	59.2	63.1	69.9	77.6									
450	18	457.2	66.8	71.1	78.8	87.5									
500	20	508.0	74.3	79.2	87.7	97.4	107	117							
550	22	558.8	81.8	87.2	96.6	107	118	129	139	150	160	171			
600	24	609.6	89.3	95.2	105	117	129	141	152	164	175	187			
650	26	660.4	96.8	103	114	127	140	152	165	178	190	203			
700	28	711.2	104	111	123	137	151	164	178	192	205	219			
750	30	762.0		119	132	147	162	176	191	206	220	235			
800	32	812.8		127	141	157	173	188	204	219	235	251	258	297	312
850	34	863.6				167	183	200	217	233	250	266	275	315	332
900	36	914.4				177	194	212	230	247	265	282	291	335	352
1000	40	1016.0				196	216	236	255	275	295	314	324	373	392
1100	44	1117.6						260	281	303	324	346	357	411	432
1200	48	1219.2						283	307	331	354	378	390	448	472
1350	54	1371.6									399	426	439	505	532
1500	60	1524.0									444	473	488	562	591
1600	64	1625.6											521	600	631
1800	72	1828.8											587	675	711
2000	80	2032.0												751	791

Stainless steel sanitary pipe (JIS G3447-2004)

Nominal	Outer diameter (mm)	Thickness (mm)	Internal diameter (mm)
1.0S	25.4	1.2	23.0
1.25S	31.8	1.2	29.4
1.5S	38.1	1.2	35.7
2.0S	50.8	1.5	47.8
2.5S	63.5	2.0	59.5
3.0S	76.3	2.0	72.3
3.5S	89.1	2.0	85.1
4.0S	101.6	2.0	97.6
4.5S	114.3	3.0	108.3
5.5S	139.8	3.0	133.8
6.5S	165.2	3.0	159.2

PVDF-HP

	SDR33 S16 PN10	SDR21 S10 PN16	SDR17 S8 PN20
Outer diameter (mm)	Thickness (mm)	Thickness (mm)	Thickness (mm)
16		1.5	1.5
20		1.9	1.9
25		1.9	1.9
32		2.4	2.4
40		2.4	2.4
50		3.0	3.0
63	2.5	3.0	
75	2.5	3.6	
90	2.8	4.3	
110	3.4	5.3	
125	3.9	6.0	
140	4.3	6.7	
160	4.9	7.7	
180	5.5	8.6	
200	6.2	9.6	
225	6.9	10.8	
250	7.7	11.9	
280	8.6	13.4	
315	9.7	15.0	
355	10.8		
400	12.2		
450	13.7		

Heat-resistant hard vinyl chloride pipe PVC-C
(JIS G6776-2004)

Nominal diameter	Outer diameter (mm)	Thickness (mm)	Weight (kg/m)
13	18.0	2.5	0.180
16	22.0	3.0	0.265
20	26.0	3.0	0.321
25	32.0	3.5	0.464
30	38.0	3.5	0.561
40	48.0	4.0	0.818
50	60.0	4.5	1.161

Polyethylene pipe for city water service

(Japan Polyethylene Pipes Association for Water Service standard PTC K 03:2006)

Nominal diameter	Outer diameter (mm)	Thickness (mm)	Inner diameter (mm)	Weight (kg/m)
50	63.0	5.8	50.7	1.074
75	90.0	8.2	72.6	2.174
100	125.0	11.4	100.8	4.196
150	180.0	16.4	145.3	8.671
200	250.0	22.7	201.9	16.688

(a) Velocity of sound subject to change f temperature of water (0 to 100°C)

T °C	V m/s	T °C	V m/s	T °C	V m/s	T °C	V m/s
0	1402.74						
1	1407.71	26	1499.64	51	1543.93	76	1555.40
2	1412.57	27	1502.20	52	1544.95	77	1555.31
3	1417.32	28	1504.68	53	1545.92	78	1555.18
4	1421.98	29	1507.10	54	1546.83	79	1555.02
5	1426.50	30	1509.44	55	1547.70	80	1554.81
6	1430.92	31	1511.71	56	1548.51	81	1554.57
7	1435.24	32	1513.91	57	1549.28	82	1554.30
8	1439.46	33	1516.05	58	1550.00	83	1553.98
9	1443.58	34	1518.12	59	1550.68	84	1553.63
10	1447.59	35	1520.12	60	1551.30	85	1553.25
11	1451.51	36	1522.06	61	1551.88	86	1552.82
12	1455.34	37	1523.93	62	1552.42	87	1552.37
13	1459.07	38	1525.74	63	1552.91	88	1551.88
14	1462.70	39	1527.49	64	1553.35	89	1551.35
15	1466.25	40	1529.18	65	1553.76	90	1550.79
16	1469.70	41	1530.80	66	1554.11	91	1550.20
17	1473.07	42	1532.37	67	1554.43	92	1549.58
18	1476.35	43	1533.88	68	1554.70	93	1548.92
19	1479.55	44	1535.33	69	1554.93	94	1548.23
20	1482.66	45	1536.72	70	1555.12	95	1547.50
21	1485.69	46	1538.06	71	1555.27	96	1546.75
22	1488.63	47	1539.34	72	1555.37	97	1545.96
23	1491.50	48	1540.57	73	1555.44	98	1545.14
24	1494.29	49	1541.74	74	1555.47	99	1544.29
25	1497.00	50	1542.87	75	1555.45	100	1543.41

Note) T: Temperature, V: Velocity

(b) Sound velocity and density of various liquids

Name of liquid	T °C	ρ g/cm ³	V m/s
Acetone	20	0.7905	1190
Aniline	20	1.0216	1659
Alcohol	20	0.7893	1168
Ether	20	0.7135	1006
Ethylene glycol	20	1.1131	1666
n-octane	20	0.7021	1192
o-xylol	20	0.871	1360
Chloroform	20	1.4870	1001
Chlorobenzene	20	1.1042	1289
Glycerin	20	1.2613	1923
Acetic acid	20	1.0495	1159
Methyl acetate	20	0.928	1181
Ethyl acetate	20	0.900	1164
Cyclohexane	20	0.779	1284
Dioxane	20	1.033	1389
Heavy water	20	1.1053	1388
Carbon tetrachloride	20	1.5942	938
Mercury	20	13.5955	1451
Nitrobenzene	20	1.207	1473
Carbon bisulfide	20	1.2634	1158
Chloroform	20	2.8904	931
n-propyl alcohol	20	0.8045	1225
n-pentane	20	0.6260	1032
n-hexane	20	0.654	1083
Light oil	25	0.81	1324
Transformer oil	32.5	0.859	1425
Spindle oil	32	0.905	1342
Petroleum	34	0.825	1295
Gasoline	34	0.803	1250
Water	13.5	1.	1460
Sea water (salinity: 3.5%)	16	1.	1510

Note) T: Temperature, ρ : Density, V: Velocity

(c) Sound velocity of pipe material

Material	V m/s
Iron	3230
Steel	3206
Ductile cast iron	3000
Cast iron	2460
Stainless steel	3206
Copper	2260
Lead	2170
Aluminium	3080
Brass	2050
Hi vinyl chloride	2640
Acrylic	2644
FRP	2505
Mortar	2500
Tar epoxy	2505
Polyethylene	1900
Teflon	1240

Note) V: Velocity

(d) Dynamic viscosity coefficient of various liquids

Name of liquid	T °C	ρ g/cm ³	V m/s	v ($\times 10^{-6}$ m ² /s)
Acetone	20	0.7905	1190	0.407
Aniline	20	1.0216	1659	1.762
Ether	20	0.7135	1006	0.336
Ethylene glycol	20	1.1131	1666	21.112
Chloroform	20	1.4870	1001	0.383
Glycerin	20	1.2613	1923	11.885
Acetic acid	20	1.0495	1159	1.162
Methyl acetate	20	0.928	1181	0.411
Ethyl acetate	20	0.900	1164	0.499
Heavy water	20	1.1053	1388	1.129
Carbon tetrachloride	20	1.5942	938	0.608
Mercury	20	13.5955	1451	0.114
Nitrobenzene	20	1.207	1473	1.665
Carbon bisulfide	20	1.2634	1158	0.290
n-pentane	20	0.6260	1032	0.366
n-hexane	20	0.654	1083	0.489
Spindle oil	32	0.905	1324	15.7
Gasoline	34	0.803	1250	0.4 to 0.5
Water	13.5	1.	1460	1.004 (20°C)

Note) T: Temperature, ρ : Density, V: Velocity, v : Dynamic viscosity coefficient

Fuji Electric Systems Co., Ltd.

Head Office

Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome,
Shinagawa-ku, Tokyo 141-0032, Japan
<http://www.fesys.co.jp/eng>

Instrumentation Div.

International Sales Dept.

No.1, Fuji-machi, Hino-city, Tokyo 191-8502, Japan
Phone: 81-42-585-6201, 6202 Fax: 81-42-585-6187
<http://www.fic-net.jp/eng>
